



No.: BCTC/RF-EMC-005 Page: 191 of 321 / / / Edition: B<sub>1</sub>2







No.: BCTC/RF-EMC-005 Page: 192 of 321 / / / / Edition: Bi2



Center 5.775 GHz #Res BW 820 kHz

**Occupied Bandwidth** 

Transmit Freq Error

x dB Bandwidth

75.688 MHz

-77.225 kHz

84.69 MHz

Report No.: BCTC2405788331-2E


CF Step 12.000000 MHz

Freq Offset

Span 120 MHz Sweep 1.333 ms

99.00 %

-26.00 dB





#VBW 2.4 MHz

x dB

**OBW Power** 









No.: BCTC/RF-EMC-005 Page: 194 of 321 / / / / Edition: B;2









No.: BCTC/RF-EMC-005 Page: 195 of 321 / / / / Edition: B;2







No.: BCTC/RF-EMC-005 Page: 196 of 321 / / / / Edition: Bi2



## 10. Maximum Conducted Output Power

## 10.1 Block Diagram Of Test Setup

#### 10.2 Limit

## According to FCC §15.407

The maximum conduced output power should not exceed:

Frequency Band(MHz)	Limit
5150~5250	1W
5250~5350	0.25W
5500~5700	0.25W
5725~5850	1W

#### 10.3 Test Procedure

Maximum conducted output power may be measured using a spectrum analyzer/EMI receiver or an RF power meter.

## 1. Device Configuration

If possible, configure or modify the operation of the EUT so that it transmits continuously at its maximum power control level (see section II.B.).

- a) The intent is to test at 100 percent duty cycle; however a small reduction in duty cycle (to no lower than 98 percent) is permitted if required by the EUT for amplitude control purposes. Manufacturers are expected to provide software to the test lab to permit such continuous operation.
- b) If continuous transmission (or at least 98 percent duty cycle) cannot be achieved due to hardware limitations (e.g., overheating), the EUT shall be operated at its maximum power control level with the transmit duration as long as possible and the duty cycle as high as possible.
- 2. Measurement using a Spectrum Analyzer or EMI Receiver (SA)

Measurement of maximum conducted output power using a spectrum analyzer requires integrating the spectrum across a frequency span that encompasses, at a minimum, either the EBW or the 99-percent occupied bandwidth of the signal.1 However, the EBW must be used to determine bandwidth dependent limits on maximum conducted output power in accordance with § 15.407(a).

- a) The test method shall be selected as follows: (i) Method SA-1 or SA-1 Alternative (averaging with the EUT transmitting at full power throughout each sweep) shall be applied if either of the following conditions can be satisfied:
- The EUT transmits continuously (or with a duty cycle ≥ 98 percent).
- Sweep triggering or gating can be implemented in a way that the device transmits at the maximum power control level throughout the duration of each of the instrument sweeps to be averaged. This condition can generally be achieved by triggering the instrument's sweep if the duration of the sweep (with the analyzer configured as in Method SA-1, below) is equal to or shorter than the duration T of each transmission from the EUT and if those transmissions exhibit full power throughout their durations.

No.: BCTC/RF-EMC-005 Page: 197 of 321 / / / / Edition: Bi2



- (ii) Method SA-2 or SA-2 Alternative (averaging across on and off times of the EUT transmissions, followed by duty cycle correction) shall be applied if the conditions of (i) cannot be achieved and the transmissions exhibit a constant duty cycle during the measurement duration. Duty cycle will be considered to be constant if variations are less than ± 2 percent.
- (iii) Method SA-3 (RMS detection with max hold) or SA-3 Alternative (reduced VBW with max hold) shall be applied if the conditions of (i) and (ii) cannot be achieved.
- b) Method SA-1 (trace averaging with the EUT transmitting at full power throughout each sweep): (i) Set span to encompass the entire emission bandwidth (EBW) (or, alternatively, the entire 99% occupied bandwidth) of the signal.
- (ii) Set RBW = 1 MHz.
- (iii) Set VBW ≥ 3 MHz.
- (iv) Number of points in sweep ≥ 2 Span / RBW. (This ensures that bin-to-bin spacing is ≤ RBW/2, so that narrowband signals are not lost between frequency bins.)
- (v) Sweep time = auto.
- (vi) Detector = RMS (i.e., power averaging), if available. Otherwise, use sample detector mode.
- (vii) If transmit duty cycle < 98 percent, use a video trigger with the trigger level set to enable triggering only on full power pulses. Transmitter must operate at maximum power control level for the entire duration of every sweep. If the EUT transmits continuously (i.e., with no off intervals) or at duty cycle ≥ 98 percent, and if each transmission is entirely at the maximum power control level, then the trigger shall be set to "free run".
- (viii) Trace average at least 100 traces in power averaging (i.e., RMS) mode.
- (ix) Compute power by integrating the spectrum across the EBW (or, alternatively, the entire 99% occupied bandwidth) of the signal using the instrument's band power measurement function with band limits set equal to the EBW (or occupied bandwidth) band edges. If the instrument does not have a band power function, sum the spectrum

## 10.4 EUT Operating Conditions

The EUT was configured for testing in a typical fashion (as a customer would normally use it). The EUT has been programmed to continuously transmit during test. This operating condition was tested and used to collect the included data.

No.: BCTC/RF-EMC-005 Page: 198 of 321 / / / Edition: B2



# 10.5 Test Result

Temperature:	26 ℃	Relative Humidity:	54%
Pressure:	101KPa	Test Voltage:	DC 12V
Test Mode:	5180-5240MHz		

Condition	Mode	Frequency	Cond	lucted Power	r (dBm)	Limit	Vordiet
Condition	Mode	(MHz)	Ant A	Ant B	Total	(dBm)	Verdict
NVNT	а	5180	8.28	8.85	/	30	Pass
NVNT	а	5200	8.28	8.66	/	30	Pass
NVNT	а	5240	7.39	7.76	/	30	Pass
NVNT	n20	5180	7.24	6.61	9.95	30	Pass
NVNT	n20	5200	7.22	6.94	10.09	30	Pass
NVNT	n20	5240	7	6.87	9.95	30	Pass
NVNT	n40	5190	6.4	6.9	9.67	30	Pass
NVNT	n40	5230	5.68	5.55	8.63	30	Pass
NVNT	ac20	5180	7.73	6.82	10.31	30	Pass
NVNT	ac20	5200	7.23	6.77	10.02	30	Pass
NVNT	ac20	5240	7.24	7.1	10.18	30	Pass
NVNT	ac40	5190	6.46	7.04	9.77	30	Pass
NVNT	ac40	5230	5.89	5.87	8.89	30	Pass
NVNT	ac80	5210	4.24	4.44	7.35	30	Pass
NVNT	ax20	5180	6.54	7.2	9.89	30	Pass
NVNT	ax20	5200	6.4	6.15	9.29	30	Pass
NVNT	ax20	5240	6.94	6.74	9.85	30	Pass
NVNT	ax40	5190	6.45	6.49	9.48	30	Pass
NVNT	ax40	5230	5.87	5.75	8.82	30	Pass
NVNT	ax80	5210	2.21	4.17	6.31	30	Pass

#### Note:

For power measurements.

The Array gain=0 for NANT≤4

So the directional gain foe Power measurements is 5.05 dBi

Page: 199 of 321 No.: BCTC/RF-EMC-005



Temperature:	26 ℃	Relative Humidity:	54%
Pressure:	101KPa	Test Voltage:	DC 12V
Test Mode:	5260-5320MHz		

Candition	ondition Mode Frequency Conducted I		lucted Power	r (dBm)	Limit	Va vali at	
Condition	wode	(MHz)	Ant A	Ant B	Total	(dBm)	Verdict
NVNT	а	5260	7.9	8.6	1	24	Pass
NVNT	а	5280	7.01	7.79	1	24	Pass
NVNT	а	5320	7.5	7.26	1	24	Pass
NVNT	n20	5260	6.67	7.77	10.27	24	Pass
NVNT	n20	5280	7.4	6.98	10.21	24	Pass
NVNT	n20	5320	6.76	6.32	9.56	24	Pass
NVNT	n40	5270	5.82	5.57	8.71	24	Pass
NVNT	n40	5310	6.42	6.59	9.52	24	Pass
NVNT	ac20	5260	7.55	7.54	10.56	24	Pass
NVNT	ac20	5280	7.76	7.24	10.52	24	Pass
NVNT	ac20	5320	7.72	6.44	10.14	24	Pass
NVNT	ac40	5270	6.56	5.79	9.20	24	Pass
NVNT	ac40	5310	6.07	6.14	9.12	24	Pass
NVNT	ac80	5290	4.51	5.7	8.16	24	Pass
NVNT	ax20	5260	6.79	7.53	10.19	24	Pass
NVNT	ax20	5280	7.3	7.36	10.34	24	Pass
NVNT	ax20	5320	7.08	6.68	9.89	24	Pass
NVNT	ax40	5270	5.69	5.88	8.80	24	Pass
NVNT	ax40	5310	5.57	5.89	8.74	24	Pass
NVNT	ax80	5290	3.49	6.74	8.42	24	Pass

#### Note:

For power measurements.

The Array gain=0 for NANT≤4 So the directional gain foe Power measurements is 5.05 dBi

Page: 200 of 321 No.: BCTC/RF-EMC-005



Temperature:	26 ℃	Relative Humidity:	54%
Pressure:	101KPa	Test Voltage:	DC 12V
Test Mode:	5500-5700MHz		

Condition	Mode	Frequency	Conducted Power (dBm)			Limit	Vordi at
Condition	Mode	(MHz)	Ant A	Ant B	Total	(dBm)	Verdict
NVNT	а	5500	6.35	3.19	/	24	Pass
NVNT	а	5580	7.62	4.58	/	24	Pass
NVNT	а	5700	8.93	5.51	/	24	Pass
NVNT	n20	5500	5.02	1.98	6.77	24	Pass
NVNT	n20	5580	6.34	3.38	8.12	24	Pass
NVNT	n20	5700	7.71	4.27	9.33	24	Pass
NVNT	n40	5510	4.6	1.37	6.29	24	Pass
NVNT	n40	5550	4.45	2.05	6.42	24	Pass
NVNT	n40	5670	7.64	3.94	9.18	24	Pass
NVNT	ac20	5500	5.1	1.63	6.71	24	Pass
NVNT	ac20	5580	6.26	3.57	8.13	24	Pass
NVNT	ac20	5700	7.96	4.61	9.61	24	Pass
NVNT	ac40	5510	4.31	1.19	6.03	24	Pass
NVNT	ac40	5550	4.78	1.91	6.59	24	Pass
NVNT	ac40	5670	6.05	3.79	8.08	24	Pass
NVNT	ac80	5530	3	0.13	4.81	24	Pass
NVNT	ax20	5500	4.27	1.22	6.02	24	Pass
NVNT	ax20	5580	5.86	3.36	7.80	24	Pass
NVNT	ax20	5700	6.9	3.85	8.65	24	Pass
NVNT	ax40	5510	3.96	0.78	5.67	24	Pass
NVNT	ax40	5550	4.33	1.84	6.27	24	Pass
NVNT	ax40	5670	6.6	3.84	8.45	24	Pass
NVNT	ax80	5530	5.09	-1.05	6.04	24	Pass

#### Note:

For power measurements.
The Array gain=0 for NANT≤4
So the directional gain foe Power measurements is 5.05 dBi

No.: BCTC/RF-EMC-005 Page: 201 of 321 / / / Edition: B 2



Temperature:	26 ℃	Relative Humidity:	54%
Pressure:	101KPa	Test Voltage:	DC 12V
Test Mode:	5745-5825MHz		

Condition	Mode Frequency Conducted Power (dBm)		Limit	Verdict			
Condition	wode	(MHz)	Ant A	Ant B	Total	(dBm)	verdict
NVNT	а	5745	5.49	4.23	1	30	Pass
NVNT	а	5785	4.28	2.51	1	30	Pass
NVNT	а	5825	3.24	1.4	1	30	Pass
NVNT	n20	5745	4.06	3.02	6.58	30	Pass
NVNT	n20	5785	3.51	0.91	5.41	30	Pass
NVNT	n20	5825	1.88	0.39	4.21	30	Pass
NVNT	n40	5755	2.94	2.67	5.82	30	Pass
NVNT	n40	5795	1.81	0.89	4.38	30	Pass
NVNT	ac20	5745	4.45	2.81	6.72	30	Pass
NVNT	ac20	5785	2.92	1.22	5.16	30	Pass
NVNT	ac20	5825	2.1	0.58	4.42	30	Pass
NVNT	ac40	5755	2.6	2.46	5.54	30	Pass
NVNT	ac40	5795	1.9	1.07	4.52	30	Pass
NVNT	ac80	5775	1.52	0.82	4.19	30	Pass
NVNT	ax20	5745	3.64	2.56	6.14	30	Pass
NVNT	ax20	5785	2.7	0.98	4.93	30	Pass
NVNT	ax20	5825	1.42	-0.65	3.52	30	Pass
NVNT	ax40	5755	2.26	2.14	5.21	30	Pass
NVNT	ax40	5795	0.98	0.79	3.90	30	Pass
NVNT	ax80	5775	1.58	1.63	4.62	30	Pass

# Note:

For power measurements.
The Array gain=0 for NANT≤4
So the directional gain foe Power measurements is 5.05 dBi

Page: 202 of 321 No.: BCTC/RF-EMC-005



#### 11. Out Of Band Emissions

# 11.1 Block Diagram Of Test Setup

EUT	SPECTRUM
	ANALYZER

#### 11.2 Limit

According to FCC §15.407(b)

Undesirable emission limits. Except as shown in paragraph (b)(7) of this section, the maximum emissions outside of the frequency bands of operation shall be attenuated in accordance with the following limits: (1) For transmitters operating in the 5.15-5.25 GHz band: All emissions outside of the 5.15-5.35 GHz band

shall not exceed an e.i.r.p. of -27 dBm/MHz.

- (2) All emissions shall be limited to a level of -27 dBm/MHz at 75 MHz or more above or below the band edge increasing linearly to 10 dBm/MHz at 25 MHz above or below the band edge, and from 25 MHz above or below the band edge increasing linearly to a level of 15.6 dBm/MHz at 5 MHz above or below the band edge, and from 5 MHz above or below the band edge increasing linearly to a level of 27 dBm/MHz at the band edge.
- (3) For transmitters operating in the 5.47-5.725 GHz band: All emissions outside of the 5.47-5.725 GHz band shall not exceed an e.i.r.p. of −27 dBm/MHz.
- (4) For transmitters operating in the 5.725-5.85 GHz band(i) All emissions shall be limited to a level of -27 dBm/MHz at 75 MHz or more above or below the band edge increasing

## 11.3 Test Procedure

- 1. Check the calibration of the measuring instrument using either an internal calibrator or a known signal from an external generator.
- 2. Position the EUT without connection to measurement instrument. Turn on the EUT and connect its antenna terminal to measurement instrument via a low loss cable. Then set it to any one measured frequency within its operating range, and make sure the instrument is operated in its linear range.
- 3. Set RBW of spectrum analyzer to 1 MHz with a convenient frequency span.
- 4. Measure the highest amplitude appearing on spectral display and set it as a reference level. Plot the graph with marking the highest point and edge frequency.
- 5. Repeat above procedures until all measured frequencies were complete.

## 11.4 EUT Operating Conditions


The EUT was configured for testing in a typical fashion (as a customer would normally use it). The EUT has been programmed to continuously transmit during test. This operating condition was tested and used to collect the included data

No.: BCTC/RF-EMC-005 Page: 203 of 321 / / / / Edition: Bi2




# 11.5 Test Result

Note: A(B) Represent the value of antenna A and B, The worst data is Antenna A, only shown Antenna A. Plot. Antenna A: 5180-5240MHz



No.: BCTC/RF-EMC-005 Page: 204 of 321 / / / / Edition: Bi2







Freq Offset 0 Hz




No.: BCTC/RF-EMC-005 Page: 206 of 321 / / / / Edition: B;2

STATUS

1.118 dBm -48.945 dBm -45.353 dBm



Freq Offset 0 Hz




No.: BCTC/RF-EMC-005 Page: 207 of 321 / / / Edition: B<sub>1</sub>2

STATUS

47.240 dBm 45.419 dBm




Freq Offset 0 Hz



No.: BCTC/RF-EMC-005 Page: 208 of 321 / / / / Edition: B<sub>1</sub>2






No.: BCTC/RF-EMC-005 Page: 209 of 321 / / / / Edition: B;2



Freq Offset 0 Hz






<u>Auto</u>

Mar

Freq Offset 0 Hz











Note: A(B) Represent the value of antenna A and B, The worst data is Antenna A, only shown Antenna A. Antenna A: 5260-5230MHz



No.: BCTC/RF-EMC-005 Page: 213 of 321 / / / / Edition: B;2




0 Hz





Freq Offset 0 Hz




No.: BCTC/RF-EMC-005 Page: 215 of 321 / / / / Edition: B<sub>1</sub>2



<u>Auto</u>

Mar

Freq Offset 0 Hz




No.: BCTC/RF-EMC-005 Page: 216 of 321 / / / Edition: B<sub>1</sub>2

STATUS

-48.598 dBm -44.895 dBm



Start 5.2700 GHz #Res BW 1.0 MHz Report No.: BCTC2405788331-2E



#VBW 3.0 MHz

Stop 5.4700 GHz 1.000 ms (1001 pts)

STATUS

**CF Step** 20.000000 MHz


Freq Offset 0 Hz

Mar

<u>Auto</u>



Freq Offset 0 Hz




No.: BCTC/RF-EMC-005 Page: 218 of 321 / / / Edition: B<sub>1</sub>2

STATUS

-2.677 dBm -45.977 dBm -44.619 dBm



Freq Offset 0 Hz





STATUS

5.296 dBm -47.894 dBm -44.674 dBm

5.315 4 GHz 5.350 0 GHz 5.472 2 GHz








No.: BCTC/RF-EMC-005 Page: 220 of 321 / / / / Edition: B;2




Freq Offset 0 Hz



No.: BCTC/RF-EMC-005 Page: 221 of 321 / / / / Edition: B<sub>1</sub>2




Note: A(B) Represent the value of antenna A and B, The worst data is Antenna A, only shown Antenna A. Antenna A: 5500-5700MHz



No.: BCTC/RF-EMC-005 Page: 222 of 321 / / / / Edition: B;2



Freq Offset 0 Hz



No.: BCTC/RF-EMC-005 Page: 223 of 321 / / / / Edition: B.2

STATUS

48.329 dBm 43.912 dBm




Freq Offset 0 Hz





Freq Offset 0 Hz



No.: BCTC/RF-EMC-005 Page: 225 of 321 / / / / Edition: B<sub>1</sub>2

STATUS

3.448 dBm -45.906 dBm -44.471 dBm



<u>Auto</u>

Mar

Freq Offset 0 Hz




No.: BCTC/RF-EMC-005 Page: 226 of 321 / / / Edition: B<sub>1</sub>2

STATUS

1.074 dBm -45.599 dBm -43.592 dBm



Freq Offset 0 Hz





<u>Auto</u>

Mar


Freq Offset 0 Hz



No.: BCTC/RF-EMC-005 Page: 228 of 321 / / / / Edition: B;2



Start 5.6300 GHz #Res BW 1.0 MHz Report No.: BCTC2405788331-2E



No.: BCTC/RF-EMC-005 Page: 229 of 321 / / Edition: B2

#VBW 3.0 MHz

Stop 5.8300 GHz 1.000 ms (1001 pts)

STATUS

**CF Step** 20.000000 MHz


Freq Offset 0 Hz

Mar

<u>Auto</u>




Freq Offset 0 Hz



No.: BCTC/RF-EMC-005 Page: 230 of 321 / / / Edition: B<sub>1</sub>2




Note: A(B) Represent the value of antenna A and B, The worst data is Antenna A, only shown Antenna A. Antenna A: 5745-5825MHz



No.: BCTC/RF-EMC-005 Page: 231 of 321 / / / / Edition: B;2





No.: BCTC/RF-EMC-005 Page: 232 of 321 / / / / Edition: B;2





No.: BCTC/RF-EMC-005 Page: 233 of 321 / / / / Edition: B;2




Freq Offset 0 Hz



Page: 234 of 321 No.: BCTC/RF-EMC-005 Edition: B.2



Freq Offset 0 Hz



Page: 235 of 321 No.: BCTC/RF-EMC-005 Edition: B.2



Freq Offset 0 Hz

