


# POCKET EGG

## USER GUIDE



## Function Description

### Function Introduction


#### Blue Light: Clear Bluetooth Pairing ID

Long press the button for 3 seconds

Execute clearing ID

Green and Red flashing  
(Please wait 11-20 seconds when clearing ID)


Clear successful: Blue Light flashes 3 times  
Clear failed: Red Light flashes 3 times



#### Green Light: Beep on / off

Long press the button for 3 seconds


Beep on: Green Light flashes 3 times  
Beep off: Red Light flashes 3 times



#### Purple Light: Vibration on / off


Long press the button for 3 seconds

Vibration on: Purple Light flashes 3 times  
Vibration off: Red Light flashes 3 times



### How to switch the function

1. Short press the button to switch functions.



2. When you power on Pocket Egg:  
- Blue light (Clear Bluetooth pairing ID): ON  
- Beep ON  
- Vibration: ON



Press and hold the button when the power is off.




Turn on the power switch, and red light will flash 3 times. It will shut down the beep and vibration function.

3. It will automatically leave the function setting when it stands by for 5 seconds.

## Pairing Connection


1. Turn on your mobile Bluetooth.



2. Tap the Main Menu.



3. Tap Settings.




4. Select Pokémon Go Plus in setting page. POCKET EGG will start to pair automatically.



Unpaired ID ▶ Green Light flashes  
Paired ID ▶ Blue Light flashes



5. Waiting for pairing. When the Pokémon Go Plus icon turns on, it means pairing is successful.



## Others

### Power / Connection / Other status

Situation	LED	Beep / Vibration
Low Power	Red flashing	×
Waiting for connection	Green flashing (unpaired) Blue flashing (paired)	- 0~3 minutes: Beep and vibrate for 3 times for every 15 seconds. - 3~10 minutes: Beep and vibrate for 3 times for every 30 seconds.
Out of internet	Red intermittent	- Stop warning after 10 minutes.
Items are full	Green	- Beep and vibrate for 8 times for every 1 seconds. - Stop after 3 cycles.
Out of Pokéball	Red flashing 3 times	
Pokémon up to maximum / Far away from Pokéstop	Red	

When you are playing Pokémon Go, there will be no beep and vibration.

### How long it can be used with different battery (Suggested)

AA Battery type	mAh	Days (8hrs/day)	Days (24hrs/day)
Heavy Duty	1100	≈ 30	≈ 12
Alkline Battery	2700	≈ 90	≈ 30

Note: It may be different according to practical battery's situation.



#### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- -

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.