

<h3>Product Overview</h3> <p>1</p>	<h3>What's in the Box</h3> <table border="1"> <tr><td>E03 Earbuds</td><td>x 2</td></tr> <tr><td>E03 Charging Case</td><td>x 1</td></tr> <tr><td>Type-C USB Cable</td><td>x 1</td></tr> <tr><td>User Manual</td><td>x 1</td></tr> </table> <h3>How to Pair</h3> <p>1, Open the charging box, the earphones are out of the warehouse, the left and right ears are automatically turned on and the TWS team is automatically formed. After the team is successfully formed, the host the red and white lights flash alternately and slowly, and the slave flashes once for 5 seconds.</p> <p>2</p>	E03 Earbuds	x 2	E03 Charging Case	x 1	Type-C USB Cable	x 1	User Manual	x 1	<p>2, Select "E03" under bluetooth menu successful.</p> <p>3</p> <p>3, Congratulations that your "E03" earphone has been successfully connected. You can take it out and use it alone, or you can use two earphones together to enjoy music. The indicator light goes out when you play music.</p> <p>4, When you use it again, you only need to take the headset out of the charging box, the headset can automatically connect back to the last connection device of.</p> <p>5</p> <p>5, Connect to a New Device When you want to connect to a new device, disconnect this connection, the earbuds will turn to pairing mode.</p>	<h3>Touch Control</h3> <table border="1"> <tr> <th>Mode</th> <th>Action</th> <th>Result</th> </tr> <tr> <td>Music Mode</td> <td>Play / Pause</td> <td>Double click L or R ●●</td> </tr> <tr> <td></td> <td>Previous / Next</td> <td>Press the left ear for 1s / Press the right ear for 1s ●</td> </tr> <tr> <td>Phone Mode</td> <td>Answer / End call</td> <td>Double click L or R ●●</td> </tr> <tr> <td></td> <td>Refuse to answer a call</td> <td>Long press 1S to reject ●</td> </tr> <tr> <td>Game mode</td> <td>Normal mode / no delay mode</td> <td>Four-click L or R ●●●●</td> </tr> </table> <p>* Note: 1. L Earphones have different functions, whether it is in monoaural mode or TWS mode, the left and right ears have different functions. Single ears have only half of the functions. 2. Support Siri, Google Assistant, Alexa, etc.</p> <p>6</p>	Mode	Action	Result	Music Mode	Play / Pause	Double click L or R ●●		Previous / Next	Press the left ear for 1s / Press the right ear for 1s ●	Phone Mode	Answer / End call	Double click L or R ●●		Refuse to answer a call	Long press 1S to reject ●	Game mode	Normal mode / no delay mode	Four-click L or R ●●●●	<h3>FCC Radiation Exposure Statement</h3> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <h3>Federal Communication</h3> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that which the receiver is connected. -Consult the dealer or an experienced radio/ TV technician for help. <h3>FCC Caution</h3> <p>Any Changes or modifications not expressly approved by the party set forth for an uncontrolled environment. Responsible for compliance could void the user's authority to operate the equipment.</p> <p>10</p>	<h3>Name and content of harmful substances in products</h3> <table border="1"> <thead> <tr> <th rowspan="2">Component Name</th> <th colspan="6">Harmful Substance</th> </tr> <tr> <th>Lead (Pb)</th> <th>Mercury (Hg)</th> <th>Cadmium (Cd)</th> <th>Hexavalent Chromium (Cr(VI))</th> <th>Polybrominated biphenyls (PBBs)</th> <th>Polybrominated diphenyl ethers (PBDEs)</th> </tr> </thead> <tbody> <tr> <td>Printed Circuit Assembly</td> <td>X</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> <tr> <td>Small structural parts such as casing</td> <td>X</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> </tbody> </table> <p>This table has been prepared in accordance with the provisions of SJ/T 11364.</p> <p>○ : It means that the content of the harmful substance in all homogeneous materials of the part is below the limit specified in GB/T 26572.</p> <p>X : It means that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit specified in GB/T 26572.</p> <p>Components marked with an "X" on the form are those for which the substitution of hazardous substances is not possible due to the global level of technological development.</p> <p>Printed Circuit Board Assemblies*: including printed circuit boards and their components, electronic components, and so on. Depending on the model, the product you purchase may not contain all of the above components.</p> <p>Electrical and electronic products sold in the People's Republic of China must be marked as such logo, the number inside the logo represents the product under normal use, Environment led.</p> <p>11</p>	Component Name	Harmful Substance						Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBs)	Polybrominated diphenyl ethers (PBDEs)	Printed Circuit Assembly	X	○	○	○	○	○	Small structural parts such as casing	X	○	○	○	○	○	<h3>Warranty statement</h3> <p>Disclaimer There are no warranties, representations or other implications of any kind that this manual or one of them contains, specifically and information mentioned here for reference only and are enhanced to change without notice.</p> <p>WARRANTY NOTICE: The following warranty in this document is included in this document: If the product is returned for repair within the warranty period from the date of production of the product, the manufacturer will repair the product free of charge; after repair or replacement of the product, the manufacturer will continue to provide the product for a minimum of 3 months. Purchase date is based on the date of sale. The date of the receipt is not determined, the warranty period from the date of production of the product according to thirteen days. (13) The manufacturer will continue to provide the product for a minimum of 3 months. Purchase date is based on the date of sale. The date of the receipt is not determined, the warranty period from the date of production of the product according to thirteen days.</p> <p>To apply for warranty, please contact the product service line and follow our instructions. To claim the warranty, you will need to provide a valid invoice that is accurate, complete and legally filed. The above warranty does not apply to the following cases: 1. over the three pack validity period; 2. Altered warranty card, product code does not match the product itself.</p> <p>12</p> <p>3. One to mislead, abuse or improper transportation, one, maintenance or storage of the case Failure or damage; 4. Failure or damage caused by force majeure (each an earthquake, war, fire, etc.) or accident. Bad; 5. Zipper, tower buckle damage due to excessive force; 6. Unwinding or tearing due to overloading; 7. Any damage caused by sharp objects; 8. Products that show signs of burning or feeding; 9. Damage caused by unauthorized disassembly or alteration; 10. Aging, discoloration, wear and tear, cracking and other wear and tear that occur during normal use of the product.</p> <h3>Warranty statement</h3> <p>11. This warranty is void if the original identification label of the product is altered or destroyed. The completeness and accuracy of the product and accompanying materials are not warranted. On-site inspection and diagnosis are not warranted. The above warranty are the entirety of our product warranty, which apply only in mainland China. Nothing in this document affects consumer rights that cannot be excluded or limited under the law. After-sales service: 0755-22674600 Email: earbus@ear-bus.com</p> <p>13</p>
E03 Earbuds	x 2																																																										
E03 Charging Case	x 1																																																										
Type-C USB Cable	x 1																																																										
User Manual	x 1																																																										
Mode	Action	Result																																																									
Music Mode	Play / Pause	Double click L or R ●●																																																									
	Previous / Next	Press the left ear for 1s / Press the right ear for 1s ●																																																									
Phone Mode	Answer / End call	Double click L or R ●●																																																									
	Refuse to answer a call	Long press 1S to reject ●																																																									
Game mode	Normal mode / no delay mode	Four-click L or R ●●●●																																																									
Component Name	Harmful Substance																																																										
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBs)	Polybrominated diphenyl ethers (PBDEs)																																																					
Printed Circuit Assembly	X	○	○	○	○	○																																																					
Small structural parts such as casing	X	○	○	○	○	○																																																					

<h3>Charging the charging case</h3> <p>Fully charged, four lights are always on</p> <p>100-70% ----- 3 lights are always on 70-50% ----- 2 lights are always on 50-25% ----- 1 light is always on 25-0% ----- 1 light flashes</p> <h3>Charge the headset</h3> <p>100-70% ----- 4 lights are always on 70-50% ----- 3 lights are always on 50-25% ----- 2 lights are always on 3-0% ----- 1 light is always on</p> <h3>Factory data reset</h3> <p>Try to reset as following instructions when two earbuds are unable to connect:</p> <ol style="list-style-type: none"> Take out the earbuds from the charging case, keep the L & R white light flash together for 5 minutes, and the earbuds turn off. The L & R earbuds do the following operations in turn. Put the earbud into the charging case, close the charging case and open again. The light of the earbud flash slowly. After double tap the earbud, the light changes to flash quickly. Double tap again, the light will always on for one second. Factory data reset is complete! Take out the earbud to keep TWS pairing mode. Then the L & R earbuds will TWS pairing successfully, the light flash will turn <p>7</p>	<p>to flash slowly together, the earbuds turn to pairing mode.</p> <h3>FAQ</h3> <ol style="list-style-type: none"> How to enter binaural stereo mode from monoaural mode a. When you only use the right ear, take out the left ear from the charging box and automatically enter the binaural stereo mode. Music is sent from the left and right earphones simultaneously. b. When you only use the left ear, take out the right ear from the charging box and automatically enter the binaural stereo mode. Music is sent from the left and right earphones simultaneously. How to enter monoaural mode from binaural mode stereo mode. a. When you put your right earbud into the charging case, the left earbud will continue playing music. b. When you put your left earbud into the charging case, the right earbud will continue playing music. The earbuds cannot reconnect to my device automatically. a. a. Make sure that the Bluetooth of the mobile phone is turned on, take out the compartment, and restart the headset. b. If the white light of the left and right ears is always on, it means that the headset has been connected to other mobile phones. Turn off the Bluetooth of the mobile phone connected to the headset. The red and white lights of the master flash alternately and slowly, and the white lights of the slave flash once every 5s. The headset automatically enters the pairing mode, and then uses the current just search for the connection on your phone. c. Directly restore the headset to the factory settings, use the current mobile <p>8</p>	<p>phone to search for the connection before the mobile phone to search for the connection again. 4. If the left and right earphones cannot be connected, please put the left and right earphones into the charging box, take out the charging box and the left and right earphones will automatically team up with TWS and flash synchronously to enter the pairing mode. If the above operation does not work, please try to restore the factory settings. 5. No sound from left/ right earbud. Please put your earbuds into the charging case, and then take out them again. If still not solve this problem, please carry out restoring the factory settings (Page 7), and then put your earbuds into charging case and then take out them again. 6. Can't turn on my earbuds a. Put the headset back into the charging compartment and make sure that the headset is in the compartment without shaking b. Close the cover and charge the charging compartment. After charging for a period of time, try to activate the headset again.</p> <h3>FCC Compliance Statement</h3> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>9</p>	<h3>FCC Radiation Exposure Statement</h3> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <h3>Federal Communication</h3> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that which the receiver is connected. -Consult the dealer or an experienced radio/ TV technician for help. <h3>FCC Caution</h3> <p>Any Changes or modifications not expressly approved by the party set forth for an uncontrolled environment. Responsible for compliance could void the user's authority to operate the equipment.</p> <p>10</p>	<h3>Name and content of harmful substances in products</h3> <table border="1"> <thead> <tr> <th rowspan="2">Component Name</th> <th colspan="6">Harmful Substance</th> </tr> <tr> <th>Lead (Pb)</th> <th>Mercury (Hg)</th> <th>Cadmium (Cd)</th> <th>Hexavalent Chromium (Cr(VI))</th> <th>Polybrominated biphenyls (PBBs)</th> <th>Polybrominated diphenyl ethers (PBDEs)</th> </tr> </thead> <tbody> <tr> <td>Printed Circuit Assembly</td> <td>X</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> <tr> <td>Small structural parts such as casing</td> <td>X</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> </tbody> </table> <p>This table has been prepared in accordance with the provisions of SJ/T 11364.</p> <p>○ : It means that the content of the harmful substance in all homogeneous materials of the part is below the limit specified in GB/T 26572.</p> <p>X : It means that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit specified in GB/T 26572.</p> <p>Components marked with an "X" on the form are those for which the substitution of hazardous substances is not possible due to the global level of technological development.</p> <p>Printed Circuit Board Assemblies*: including printed circuit boards and their components, electronic components, and so on. Depending on the model, the product you purchase may not contain all of the above components.</p> <p>Electrical and electronic products sold in the People's Republic of China must be marked as such logo, the number inside the logo represents the product under normal use, Environment led.</p> <p>11</p>	Component Name	Harmful Substance						Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBs)	Polybrominated diphenyl ethers (PBDEs)	Printed Circuit Assembly	X	○	○	○	○	○	Small structural parts such as casing	X	○	○	○	○	○	<h3>Warranty statement</h3> <p>Disclaimer There are no warranties, representations or other implications of any kind that this manual or one of them contains, specifically and information mentioned here for reference only and are enhanced to change without notice.</p> <p>WARRANTY NOTICE: The following warranty in this document is included in this document: If the product is returned for repair within the warranty period from the date of production of the product, the manufacturer will repair the product free of charge; after repair or replacement of the product, the manufacturer will continue to provide the product for a minimum of 3 months. Purchase date is based on the date of sale. The date of the receipt is not determined, the warranty period from the date of production of the product according to thirteen days. (13) The manufacturer will continue to provide the product for a minimum of 3 months. Purchase date is based on the date of sale. The date of the receipt is not determined, the warranty period from the date of production of the product according to thirteen days.</p> <p>To apply for warranty, please contact the product service line and follow our instructions. To claim the warranty, you will need to provide a valid invoice that is accurate, complete and legally filed. The above warranty does not apply to the following cases: 1. over the three pack validity period; 2. Altered warranty card, product code does not match the product itself.</p> <p>12</p>	<p>3. One to mislead, abuse or improper transportation, one, maintenance or storage of the case Failure or damage; 4. Failure or damage caused by force majeure (each an earthquake, war, fire, etc.) or accident. Bad; 5. Zipper, tower buckle damage due to excessive force; 6. Unwinding or tearing due to overloading; 7. Any damage caused by sharp objects; 8. Products that show signs of burning or feeding; 9. Damage caused by unauthorized disassembly or alteration; 10. Aging, discoloration, wear and tear, cracking and other wear and tear that occur during normal use of the product.</p> <h3>Warranty statement</h3> <p>11. This warranty is void if the original identification label of the product is altered or destroyed. The completeness and accuracy of the product and accompanying materials are not warranted. On-site inspection and diagnosis are not warranted. The above warranty are the entirety of our product warranty, which apply only in mainland China. Nothing in this document affects consumer rights that cannot be excluded or limited under the law. After-sales service: 0755-22674600 Email: earbus@ear-bus.com</p> <p>13</p>
Component Name	Harmful Substance																																
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBBs)	Polybrominated diphenyl ethers (PBDEs)																											
Printed Circuit Assembly	X	○	○	○	○	○																											
Small structural parts such as casing	X	○	○	○	○	○																											

<h3>用户指南</h3>	<h3>产品简介</h3> <p>1</p>	<h3>包装内容</h3> <table border="1"> <tr><td>OMTHING E03 耳机</td><td>x 2</td></tr> <tr><td>OMTHING E03 充电盒</td><td>x 1</td></tr> <tr><td>Type-C USB 充电线</td><td>x 1</td></tr> <tr><td>用户指南</td><td>x 1</td></tr> </table> <h3>如何配对</h3> <p>1, 打开充电盒, 耳机弹出, 左右耳自动开机并自动TWS组队, 组队成功后, 主机红白灯交替慢闪, 从机5s闪一下。</p> <p>2, 在手机蓝牙列表里选择新的设备“E03”连接, 即可配对成功。</p> <p>3, 恭喜你的“E03”耳机已经连接成功, 你可以单独拿出使用, 也可以两个耳机一起使用欣赏音乐, 播放音乐时指示灯熄灭。</p> <p>4, 再次使用的时候, 你只需要把耳机拿出充电盒, 耳机可以自动回连上次连接的设备。</p> <p>5, 连接新设备 如需连接新设备, 只需要断开已连接设备蓝牙, 耳机自动进入配对模式, 新设备搜索蓝牙列表连接即可使用。</p> <p>6</p>	OMTHING E03 耳机	x 2	OMTHING E03 充电盒	x 1	Type-C USB 充电线	x 1	用户指南	x 1	<h3>常见问题</h3> <ol style="list-style-type: none"> 如何从单耳模式进入双耳模式立体声模式 a. 当你只是用右耳时, 从充电盒取出左耳, 自动进入双耳模式立体声模式, 音乐同步从左右耳机发出。 b. 当你只是用左耳时, 从充电盒取出右耳, 自动进入双耳模式立体声模式, 音乐同步从左右耳机发出。 如何从双耳模式立体声模式进入单耳模式。 a. 把右耳机放入充电盒, 自动切换为单耳模式, 只有左耳播放音乐。 b. 把左耳机放入充电盒, 自动切换为单耳模式, 只有右耳播放音乐。 耳机无法自动回连你的手机时。 a. 确定手机蓝牙是否打开, 拿出盒, 让耳机重新开机。 b. 如果左右耳白灯常亮, 说明耳机已经连接其他手机。关掉已经连接耳机的手机的蓝牙, 主机红白灯交替慢闪, 从机白灯5s闪一次, 耳机自动进入配对模式, 然后用当前手机搜索连接即可。 c. 直接让耳机恢复出厂设置, 用当前手机重新搜索连接前手机重新搜索连接。 如果左右耳机无法连接, 请把左右耳机放入充电盒, 拿出充电盒左右耳机自动TWS组队并同步闪烁, 进入配对模式。如果以上操作无效, 请尝试恢复出厂设置。 如果耳机无声音 尝试重新连接耳机, 来改善此问题。 把耳机放入充电盒, 重新打开, 如果无法改善此问题, 请尝试恢复出厂设置。 <p>8</p>	<h3>安全规则</h3> <h3>使用规则</h3> <ol style="list-style-type: none"> 请勿以任何理由拆除或改装耳机, 则可能导致耳机故障, 些都不在保修范围。 请勿将设备放入水中浸泡, 否则会造成设备严重损坏, 由此造成的财产损失制造商不予以保修。 请勿将设备置于温度过高或过低(75°C以上或者-40°C以下)的环境中。 请避免靠近儿童或动物的眼睛使用设备指示灯。 本产品内含细小零件, 请勿吞食以免发生窒息危险, 不适合三岁以下儿童使用。 请勿在雷暴天气下使用该设备, 雷暴可能导致设备工作不正常, 并增加触电危险。 若长期使用请将电源关闭, 避免电池过放损坏。 <h3>电池警告</h3> <ol style="list-style-type: none"> 此产品内置锂电池, 禁止拆解、撞击、挤压或者投入火中。 请勿置于高温环境中, 或暴露在强烈的日照下, 以免爆炸。 若出现严重膨胀, 请勿继续使用。 按照当地法规处理电池, 不要当家庭垃圾处理。 除非使用手册里有说明, 否则用户不得自行取出或者更换产品的电池。进行此类操作存在危险可能会损坏产品。 <p>9</p>	<h3>触摸控制</h3> <table border="1"> <tr> <th>Mode</th> <th>Action</th> <th>Result</th> </tr> <tr> <td>音乐模式</td> <td>播放/暂停</td> <td>双击L或R ●●</td> </tr> <tr> <td></td> <td>上一曲/下一曲</td> <td>左耳长按1S / 右耳长按1S ●</td> </tr> <tr> <td>来电模式</td> <td>接听电话/挂断电话</td> <td>双击L或R ●●</td> </tr> <tr> <td></td> <td>拒接电话</td> <td>长按1S拒接 ●</td> </tr> <tr> <td>游戏模式</td> <td>正常模式/无延迟模式</td> <td>四击L或R ●●●●</td> </tr> </table> <p>*备注: 1. L/R耳机功能不相同, 无论是单耳模式还是TWS模式, 左右耳功能不同, 单耳使用只有一半的功能。 2. 支持Siri, Google Assistant, Alexa等语音助手。</p> <p>5</p>	Mode	Action	Result	音乐模式	播放/暂停	双击L或R ●●		上一曲/下一曲	左耳长按1S / 右耳长按1S ●	来电模式	接听电话/挂断电话	双击L或R ●●		拒接电话	长按1S拒接 ●	游戏模式	正常模式/无延迟模式	四击L或R ●●●●	<h3>开机</h3> <ul style="list-style-type: none"> -耳机从盒内拿出, 耳机自动开机。 <h3>关机</h3> <ul style="list-style-type: none"> -耳机放入充电盒, 耳机自动关机。 <h3>当第二个电话进来时</h3> <ul style="list-style-type: none"> -双击接听新的来电并保留原有通话; -长按1S拒接第二个电话; -接听第二个电话后, 双击保留当前电话并切换到另一个电话, 三击挂断当前电话。 <h3>充电</h3> <p>耳机放回充电盒。</p> <h3>为耳机充电</h3> <p>当耳机低电量时, 耳机会播报低电量提示提醒充电, 耳机放入充电盒后, 耳机自动关机并且充电, 充电红灯长亮, 耳机满电灯不亮。</p> <p>6</p>
OMTHING E03 耳机	x 2																															
OMTHING E03 充电盒	x 1																															
Type-C USB 充电线	x 1																															
用户指南	x 1																															
Mode	Action	Result																														
音乐模式	播放/暂停	双击L或R ●●																														
	上一曲/下一曲	左耳长按1S / 右耳长按1S ●																														
来电模式	接听电话/挂断电话	双击L或R ●●																														
	拒接电话	长按1S拒接 ●																														
游戏模式	正常模式/无延迟模式	四击L或R ●●●●																														
<h3>为充电盒充电状态</h3> <p>充满电, 四个灯常亮 100-70% ----- 3个灯常亮 70-50% ----- 2个灯常亮 50-25% ----- 1个灯常亮 25-0% ----- 1个灯闪烁</p> <h3>为耳机充电状态</h3> <p>100-70% ----- 4个灯常亮 70-50% ----- 3个灯常亮 50-25% ----- 2个灯常亮 3-0% ----- 1个灯常亮</p> <h3>恢复出厂设置</h3> <p>当两个耳机无法组队或蓝牙连接时, 尝试按下面说明恢复出厂设置。</p> <ol style="list-style-type: none"> 耳机从仓内取出, 手动长按8s把耳机关机。 长按8s后, 松手耳机会重新开机, 红白灯常亮1S, 之后会红白灯交替快闪, 恢复出厂设置成功。 另一只耳机重复以上步骤。 红白灯交替快闪, TWS耳机开始组队, 组队成功后, 主机红白灯交替慢闪, 从机5s闪一下。 <p>7</p>	<h3>保修声明</h3> <p>8. 有烧损或水浸迹象的产品; 9. 因擅自拆改导致的损坏; 10. 产品正常使用过程中发生的老化、褪色、磨损、破裂和其他损耗。 11. 如产品原有标识被更改或损毁, 本保证将失效。产品及随附物料的齐备和外观完好不属于保证范围, 您应在接收产品时当场检验并对任何不符提出异议。</p> <p>以上保证是我们就产品做出的全部保证, 且仅在中國大陸地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。</p> <p>售后服务电话: 0755-22674600 邮箱: earbus@ear-bus.com</p> <p>12</p>	<h3>保修声明</h3> <p>免责声明 本使用手册没有任何形式的担保、立场表达或其他暗示, 本使用手册所提到的产品、规格及信息仅供参考, 内容亦会随时更新于网页, 恕不另行通知。</p> <p>保修声明: 就本文件附随的产品做如下保证: 如产品在您购买日起十二(12)个月(“保修期”)内, 在正常使用情况下因质量瑕疵发生损坏, 能修理的免费修理; 经厂家确认无法修理的, 免费更换; 修理或更换后的产品, 在剩余保修期(最短不少于30天)内继续享有保修。购买日以销售发票日期为准; 如无发票确定购买日, 则保修期自产品生产日期起按十三(13)个月计算。</p> <p>如申请保修, 请先致电产品服务热线, 并按我们指示的方式执行。申请保修时, 您需要提供准确、完整和清晰填写的有效销售发票。</p> <p>以上保证不适用于下列情况: 1. 超过三包有效期的; 2. 涂改保修卡、产品编码与产品本体不符; 3. 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏; 4. 因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏; 5. 拉扯、塔扣因受力过大而损坏; 6. 因超载过重造成的脱线或撕裂; 7. 任何因尖锐物体造成的损坏;</p> <p>13</p>	<h3>产品中有有害物质名称及含量</h3> <table border="1"> <thead> <tr> <th rowspan="2">部件名称</th> <th colspan="5">有害物质</th> </tr> <tr> <th>铅(Pb)</th> <th>汞(Hg)</th> <th>镉(Cd)</th> <th>六价铬(Cr(VI))</th> <th>多溴联苯(PBBs) 多溴二苯醚(PBDE)</th> </tr> </thead> <tbody> <tr> <td>印刷电路组件</td> <td>X</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> <tr> <td>外壳等小结构件</td> <td>X</td> <td>○</td> <td>○</td> <td>○</td> <td>○</td> </tr> </tbody> </table> <p>本表格依据SJ/T 11364的规定编制。 ○ : 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。 X : 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。</p> <p>表单标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。</p> <p>印刷电路板组件*: 包括印刷电路板及其零部件, 电子元器件等, 根据产品型号不同, 您所购买的产品可能不会含有以上所有部件</p> <p>10</p>	部件名称	有害物质					铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBBs) 多溴二苯醚(PBDE)	印刷电路组件	X	○	○	○	○	外壳等小结构件	X	○	○	○	○	<h3>保修声明</h3> <p>14</p>	<h3>保修声明</h3> <p>15</p>	<h3>保修声明</h3> <p>16</p>			
部件名称	有害物质																															
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBBs) 多溴二苯醚(PBDE)																											
印刷电路组件	X	○	○	○	○																											
外壳等小结构件	X	○	○	○	○																											