#### SAFETY INSTRUCTIONS

The product has an inbuilt battery. To prevent it from leaking, heating up or catching fire, follow these instructions:

- 1. Use the USB cable included to charge the product.
- Do not leave the product connected to power for an extended period after the charging process is complete.
- Keep the product away from fire and other heat sources and do not expose it to high temperatures, such as in an overheated car, for an extended period.
- 4.Do not expose the product to impacts; do not puncture, crush, or bend it etc.
- 5. Do not disassemble or open the product. Do not attempt to service it yourself.

Warning: flashing lights may trigger epileptic seizures.

#### FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may

cause undesired operation. Warning: Changes or modifications not expressly approved by the

party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B

digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates uses and can radiate radio frequency energy and, if not installed

and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference

will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following


Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

# BT2630 WIRELESS SPEAKER



#### DEAR CUSTOMER,

Thank you for choosing KINGREE . Read the instructions carefully to optimally make use of your new device.


#### IN THE BOX

- BT2630 Speaker
- Charging cable
- 3.5 mm AUX cableInstructions

#### SPECIFICATIONS

- · Bluetooth 5.1:10 m range
- Battery capacity: 1200 mAh
- Play time: 4 h
- · Charging time: 3 h
- · Output power: 6W (2x 3 W)
- Frequency range: 100 Hz 20 kHz
- · Impedance: 4 Ohm
- · Charging port: USB-C
- Dimensions: 21 x 13.2 x 12.6 cm
- · Weight: 610g

#### PRODUCT OVERVIEW



Button	Function
(%)	Power on/off: press and hold for 3 seconds Play/pause: press once Answer/end a call: press once Redial the last number: press twice
M	Turn lights on/off, select the light mode: press repeatedly Select the playback mode (Bluetooth, TF card, AUX): press and hold
$\bigcirc$	Volume up: press repeatedly     Skip to next track: press and hold
$\bigcirc$	Volume down: press repeatedly     Skip to previous track: press and hold

#### CHARGING

Use the charging cable provided to connect the speaker to a compatible wall charger, computer etc. During charging, the LED indicator will be solid red. When the speaker is fully charged, the LED turns off.

#### BLUETOOTH PAIRING

Turn on the speaker. It will automatically go into pairing mode and its lights will be solid blue.

Make sure your phone (or other compatible device) has the Bluetooth function on. Select "Sound-E" from your phone's list of available Bluetooth devices. When connected to a device, the speaker's lights will alternate between 3 colors, or between 7 colors during audio streaming.

Once paired to a device, the speaker will automatically connect to it when turned on, provided the device is within its range and has its Bluetooth function on.

### AUX MODE

Bluetooth is the speaker's default mode. Plug in a 3.5 mm AUX cable and the speaker will automatically go into AUX mode. You can play music from the device connected via audio cable. Remove the cable and the speaker will go back to Bluetooth mode.

## TF-CARD MODE

Bluetooth is the speaker's default mode. Insert a TF card and the speaker will automatically play the audio tracks on the card (supported audio formats: mp3, wav). Remove the card and the speaker will go back to Bluetooth mode.

#### LIGHT SETTINGS

While in Bluetooth pairing mode, the speaker's lights will be blue. When connected to a Bluetooth device, the lights will alternate between 3 colors. During Bluetooth audio streaming, in AUX and TF-card mode, the lights will alternate between 7 colors. Press the mode-selection button repeatedly to choose among the two light modes available or to turn the lights on/off.

## **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.