



Keep Calm When Dealing With Problems

PROBLEMS	CAUSES	SOLUTIONS
Remote Control fails	The remote control might disconnect. The polarity symbols on the battery don't match the symbols inside the battery compartment. The power of remote control might not be sufficient.	Connect the remote control. Check the polarity symbols of the battery and ensure they match the symbols inside the battery compartment. Replace with new batteries. Turn on the remote control.
Unable to control	The battery of the drone might be depleted. The drone might fly in strong winds.	Measure the drone's battery is well connected. Strong winds might prohibit the flight.
The drone fails to ascend	The motor might turn slowly. The drone might not be fully charged.	Push the accelerator to speed up. Fully charge the drone.
The drone responds too fast	The accelerator might be pushed back too fast.	Gradually pull back the accelerator to ensure steady landing.
Out of control	The drone might fly out of the effective control distance.	Slowly frequencies delivered within 30 meter are not identical.

FCC Statement

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

www.jrc-tech.com