



材质：100g书纸，折页




User Manual

Rechargeable Wireless Keyboard and Mouse



Package Contents

- 1 x 2.4GHz Wireless Keyboard
- 1 x 2.4GHz Wireless Mouse
- 1 x 2.4GHz USB Receiver
- 1 x Type-C Charging Cable
- 1 x User Manual




-1-

Attention

- When the keyboard and mouse will not be used for a long time, it is recommended to turn them off to prolong the service life of the batteries.
- Do not use liquid to clean the keyboard directly. Clean the keyboard with a soft cloth dipped with alcohol or similar volatile disinfectant.

Indicator Light



- Keyboard Battery Status Indicator**
Solid red: The keyboard is charging.
Solid green: The keyboard is fully charged.
Flash red: The battery is low (Please charge the keyboard).
- Caps Lock Indicator**
The caps lock indicator will be green when Caps Lock is activated.
- Numeric Indicator**
The numeric indicator will be green when Num Lock is activated.
- Power Indicator**
The power indicator will be green for 2s then go out when the keyboard has been turned on successfully.
- Power Switch**
Slide the power switch to the right to turn on or to the left to turn off the keyboard.

-2-


Model:URKM-10

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Thank you for your trust!




Need some help:
support@uhurumobility.com
For more products:
www.uhurumobility.com

Pairing Steps

Step 1. Take out the 2.4GHz USB receiver from the storage slot on the bottom of the mouse.

Step 2. Insert the 2.4GHz USB receiver into a USB port of the computer.



Step 3. Slide the power switches of the keyboard and mouse to ON position. The keyboard and mouse will simultaneously connect to the laptop/PC within 3s.

If connection failed, please follow the steps below:

Keyboard re-pairing:

Step 1. Turn on the keyboard, press "Esc + Q" keys simultaneously, and the power indicator will flash quickly.

Step 2. Insert the 2.4GHz USB receiver into a USB port of the computer within 10s, and get the keyboard close to the receiver within 30cm (0.98 feet).

-3-

Mouse re-pairing:

Step 1. Turn off the mouse and plug out the 2.4GHz USB receiver.

Step 2. Hold down the "Wheel button + Right button" simultaneously for 3s, and then turn on the mouse.

Step 3. Insert the 2.4GHz USB receiver into a USB port of the computer within 10s, and get the mouse close to the receiver within 30cm (0.98 feet).

Power Saving Mode

If no order is given to the keyboard and mouse, the keyboard and mouse will automatically enter power saving mode.

When you want to use the keyboard or mouse again, press any key, and the keyboard or mouse will automatically connect to the device.

Keys and Functions

When you need to use the shortcut keys, press the "Fn" key in the same row.

MAC:

Esc	Brightness-	Brightness+	Mute	Volume-	Volume+
Previous track	Play/Pause	Next track	Home	Search for	

Windows:

Esc	Brightness- (Win 10)	Brightness+ (Win 10)	Mute	Volume-	Volume+
Previous track	Play/Pause	Next track	Web browser	Search for	

-4-

Keyboard Specifications

Battery Capacity: 300mAh
Standby Time: 45 days
Continuous Working Time: 35 hours
Connection Range: within 10 meters
Keyboard Life: 3 million keystrokes

Mouse Specifications

Battery Capacity: 300mAh
Standby Time: 45 days
DPI: 800-1200(Default)-1600
Connection Range: within 10 meters
Mouse Life: 3 million clicks

Troubleshooting

If you are unable to connect to the device.

- Make sure that the power switch has been turned on.
- Make sure that the 2.4GHz USB receiver is inserted into a USB port of the device (such as a laptop).
- Make sure that the battery of the device has sufficient power.
- Make sure that the keyboard is within the operational range.

If the keyboard doesn't work, or there is typing delay.

- Make sure there is no 2.4GHz device (such as a router) nearby which may interfere with the connection.
- Make sure that the battery of the keyboard has power.
- Make sure there is no all-metal chassis which may shield the signal.
- The computer is running too many tasks and the CPU memory is full, so it cannot handle the signal from the receiver.

-5-

If the mouse doesn't work, or there is obvious delay.

- Kindly check the battery of the mouse.
- If your computer is connected to a wired mouse at the same time, please unplug it, or it may cause the work drive conflicts.
- Make sure that your mouse is not used on materials (such as glass) with good light-transmitting property (Because the mouse uses diodes for positioning, glass and other materials will make positioning inaccurate and delayed).

If the command keys in Mac or the win keys in Windows are unable to use.

- Press "Fn + Q" keys simultaneously, then the cmd keys in you Mac will work.
- Press "Fn + W" keys simultaneously, then the win keys in you Windows will work.

If the shortcut keys function is not available.

- Press the "Fn" key in the same row to lock/unlock the shortcut keys function.
- When the shortcut keys function is turned off, press the "Fn" key and the corresponding function key simultaneously.
- When the shortcut keys function is turned on, press the corresponding function key for direct use.

Note:

- The F1-F12 keys function is not available for iPad with MacOS system.
- The brightness control shortcut keys function is not available for Windows 7 system.

-6-