

Remote control directions

Remote Control Function Operation


1. Power Switch (Power button) : Click Power Switch for 1st time, turn on, default 1st gear; Click Power Switch for 2nd time, power off.
2. Natural wind function (the branch shape) : In any position, click the button for 1st time, open natural wind; click on the button for 2nd time, close natural wind; restore the current gear.
3. Gear increase (+ shape) : When the fan is in first gear state, click the + button to increase one gear until the highest gear does not increase any more.
4. Gear reduction (- shape): When the fan is in four gears, click the - button to reduce one gear until the lowest gear is no longer reduced.
5. Timing selection (clock shape) : Click Timing key for 1st time, timer 1h; Click Timing key for 2nd time, timer 2hrs; Click Timing key for 3rd times, timer 4hrs; Click Timing key for 4th times, timer 8hrs; Click Timing key for 5th times, Turn off the Timer (Restore current working status).
6. Rotating Function (Circular arrow shape): In any position, click this button for the 1st time to enable shaking head, click this button for the 2nd time to close shaking head.

Remote control usage method



Please pull out the power isolation card before using the remote control, then the remote control can be used normally. When not in use for a long time, insert the isolation card back to avoid battery damage

Product Component



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.