


## Annex A.6 Band Edge

# 1. GSM\_GSM850


## 1.1. GSM Band Edge(NTNV)(Channel:128)

Start Frequency (MHz)	Stop Frequency (MHz)	RBW (MHz)	Detector	Frequency (MHz)	Power (dBm)	Limit (dBm)	Verdict	Sweep Point
820	823	0.1	RMS	822.985	-54.12	-13	Pass	401
823	824	0.003	RMS	823.98	-28.26	-13	Pass	401
824	824.5	0.01	RMS	824.215	13.5	35	Pass	401



## 1.2. GSM Band Edge(NTNV)(Channel:251)


Start Frequency (MHz)	Stop Frequency (MHz)	RBW (MHz)	Detector	Frequency (MHz)	Power (dBm)	Limit (dBm)	Verdict	Sweep Point
848.5	849	0.01	RMS	848.815	13.68	35	Pass	401
849	850	0.003	RMS	849.02	-26.36	-13	Pass	401
850	855	0.1	RMS	850	-53.83	-13	Pass	401



## 2. GSM\_PCS


### 2.1. GSM Band Edge(NTNV)(Channel:512)

Start Frequency (MHz)	Stop Frequency (MHz)	RBW (MHz)	Detector	Frequency (MHz)	Power (dBm)	Limit (dBm)	Verdict	Sweep Point
1845	1849	1	RMS	1849	-42.04	-13	Pass	41
1849	1850	0.003	RMS	1849.975	-30.02	-13	Pass	401
1850	1851	0.01	RMS	1850.223	10.78	35	Pass	401



## 2.2. GSM Band Edge(NTNV)(Channel:810)

Start Frequency (MHz)	Stop Frequency (MHz)	RBW (MHz)	Detector	Frequency (MHz)	Power (dBm)	Limit (dBm)	Verdict	Sweep Point
1909	1910	0.01	RMS	1909.785	11.08	35	Pass	401
1910	1911	0.003	RMS	1910.03	-29.49	-13	Pass	401
1911	1915	1	RMS	1911	-42.41	-13	Pass	41



END