




# DreamSky FM-AM Radio with Bluetooth

## Instruction Manual

Model: DS226




Thank you for purchasing DreamSky FM-AM Radio with Bluetooth.

To ensure the best product performance, please read this user manual in detail and retain it for future reference.

Questions? Contact Customer Service Center at:

✉ [info@dreamsky4u.com](mailto:info@dreamsky4u.com)

## Overview



1. **⏻/SLEEP**: press to turn on the radio; press to select sleep timer; hold to turn off the radio
2. Power/Sleep Timer Indicator
3. **TUNING**: to change the radio station
4. **VOLUME**: to adjust the volume
5. **FM AM**: to switch between Bluetooth, FM, AM
6. Earphone Jack
7. AC 7.5V INPUT
8. Antenna
9. Battery Compartment

## Safety Precautions

- Remove the batteries if the unit is not to be used for a long time or is used only from an AC power source to avoid possible battery leakage.
- Do not expose this unit to rain, moisture, dripping, splashing or sources of heat.
- Do not place objects filled with liquids, such as vases on this unit.
- Do not repair this unit by yourself. Refer servicing to qualified service personnel.
- Avoid cuts, scratches, or poor connections in the AC adapter.
- Avoid excessive bending, pulling, or splicing of the cord.
- Do not unplug the AC adapter by pulling on the cord.
- Do not operate this unit on AC power in a bathroom.



**PLEASE DISPOSE OF OLD OR DEFECTIVE BATTERIES IN AN ENVIRONMENTALLY SAFE WAY AND IN ACCORDANCE WITH YOUR LOCAL LAWS AND REGULATIONS.**

### BATTERY SAFETY:

- Clean the battery contacts and those of the device prior to battery installation.
- Remove batteries from equipment which is not to be used for an extended period.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the device.
- Dispose of used batteries properly.
- Danger of explosion if battery is incorrectly replaced.
- Only batteries of the same or equivalent type as recommended are to be used.
- DO NOT incinerate used batteries.

- DO NOT dispose of batteries in fire, as batteries may explode or leak.
- DO NOT mix old and new batteries or types of batteries (alkaline/standard).
- DO NOT use rechargeable batteries.
- DO NOT recharge non-rechargeable batteries.
- DO NOT short-circuit the supply terminals.
- DO NOT use the battery if the cover is peeled off.
- DO NOT heat or expose to flame.
- DO NOT leave the battery in a car exposed to direct sunlight for a long period of time with doors and windows closed.

## Specifications

### Radio frequency range:

FM: 87.0 MHz - 108.0 MHz

AM: 520 KHz - 1710 KHz

Power source: AC: 7.5V/0.2A. 60Hz;


DC: C Alkaline Batteries \* 4 (Not include)

Dimensions (L x W x H): 8.6" x 2.4" x 4.9"

## Power Supply

- Connecting AC power supply cord (7.5V/0.2A, 110V voltage applicable)


The included AC power supply cord is for use with this unit only. Do not use it with other equipment.



- Using dry cell batteries (alkaline batteries)

Unplug the AC power supply cord from the household AC outlet and the AC INPUT socket on the unit.

1. Open the battery compartment cover.
2. Insert 4 C batteries into the battery compartment following the polarity (+/-) diagram inside.



## Tune in Radio

1. Press the **⏻/SLEEP** button to turn on the radio.
2. Toggle the switch to select the AM, FM band.




AM band




FM band

3. Rotate the **TUNING** knob to select the radio channel.



4. Rotate the **VOLUME** knob to adjust the volume.



Turn OFF the Radio

Hold the **⏻/SLEEP** button to turn off the radio.




Sleep Timer

With sleep timer, the device will turn off automatically after a specified time interval.


1. Press **⏻/SLEEP** button to activate the sleep count down timer when the device is ON.
2. Press **⏻/SLEEP** button repeatedly to cycle through the available durations for sleep timer (30 Minutes – 1 Hour – 2 Hours – Endless).

Bluetooth Mode

1. Press **⏻/SLEEP** button to turn on the device and toggle the switch to Bluetooth mode



2. Turn on your audio source's Bluetooth and select "DS226" from the Bluetooth menu.




3. Rotate the VOLUME knob or adjust your audio source's volume for a proper sound.




**Note:** To connect with new device, you need to disconnect last device if it is nearby.

Adjust the Antenna

**FM:** pull out the telescopic antenna and adjust its length and angle for optimum reception.




**AM:** the unit is equipped with a built-in ferrite antenna, so try various directions for optimum reception.



Earphone Jack

Plug in your earphone to listen to the radio.



Note: Earphone is not provided

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 0cm during normal operation.

After Sales Service

If you encounter problems when using this DreamSky FM-AM Radio with Bluetooth, please contact us by email:

✉ [info@dreamsky4u.com](mailto:info@dreamsky4u.com)

Our Warranty

- 90-day money back guarantee
- 366-day free replacement

Troubleshooting

Q: No power

- A:
- Batteries dead or incorrectly inserted
  - AC power connection loose
  - Outlet not working

Q: No sound

- A:
- Volume of device or bluetooth's source not adjusted
  - Headphones connected to the unit

Q: Poor radio reception

A: Weak radio signal, extend/incline and turn the telescopic antenna for best reception