


Instructions

Peakeep Wireless Charging Alarm Clock

(Model: MHP-2021)



QUESTIONS? Contact: sales@us-myehome.com

Please well preserve this sheet,
keeping it from damage or loss.


Package Content

- 1 pc wireless charger alarm clock
- 1 pc wall AC adaptor (9V 2A)
- 1 pc instructions
- 1 pc warranty card

Start the Clock


This clock is powered by AC adapter attached. Please plug AC adaptor into power outlet to get the clock started.

This clock is not batteries operated. There is a compartment at the bottom of the clock, 2 AAA batteries can be loaded to save clock settings in case of AC power outage.



Wireless Charger Function

First, please confirm your cell phone is wireless chargeable. Then put cell phone on top of the wireless charger part (circle part), phone face upward, make sure cell phone COVERS the CIRCLE, then indicator turns yellow light which means charging or fully charged.



Note: Remove case thicker than 5 mm while charging.

Charging Indicator

The indicator has 2 display mode.

(1) **Yellow light stays on:** it means the wireless charger function is working. It usually takes 3-5 hours to get cellphone fully charged, please check your cellphone if it is fully charged.

(2) **Yellow light keeps flashing:** it might mean the cellphone is not placed correctly, please adjust the position of your cellphone until the indicator stays on; If your cellphone doesn't have wireless charging function, please remove your cellphone.

Please be aware that any electronic or magnetic device without wireless charging function (like remote controller, lamp etc.) put on the clock also will make the yellow light keep flashing.

Time Setting

- Hold for 2s. Hour digit starts flashing.
- Release [TIME SET], press [+] / [-]
- Press once. Minute digit starts flashing.
- Press [+] / [-]
- Press once to exit and save.

Note:
If no button is activated within 10 seconds, it will automatically revert to the normal time display.

Alarm Setting

① Hold for 2s. Alarm hour digit & 📍 starts flashing.



② Release [ALARM SET], press [+] / [-]



③ Press once. alarm minute digit & 📍 starts flashing.



④ Press [+] / [-]



⑤ Press once to exit and save.



Note:
1. In alarm-setting mode, "📍" symbol keeps flashing.
2. In non-setting mode, press the [ALARM SET] button to check the adjusted alarm time.
3. Alarm sound will last for 2 minutes if no action taken.

Turning Alarm On / Off

In normal time display, press the [AL.ON/OFF] button to totally disable the alarm, the alarm symbol disappears from the screen, meaning no alarm.



Alarm On



Alarm Off

Reset the Alarm for the Next Day

When alarm goes off, press any of the 4 buttons ([TIME SET], [ALARM SET], [+], [-]) to stop the alarm for the day and it will go off again at the same time the next day.

Snooze Mode

When alarm sounds, touch the [SNOOZE] sensing area to enter the snooze mode, the alarm symbol will flash on the display and alarm will sound again 9 minutes later. Snooze function can be repeated again and again as your demand.




Converting Regular/Military Time

In normal time display mode, press [12/24 HR] button to convert time format in Regular Time (12-hour) or Military Time (24-hour).

Note:
Regular time (12-hour): AM 12:00-11:59 PM 12:00- PM 11:59
Military time (24-hour): 0:00-23:59


Display Brightness Setting

Slide the [DIMMER] button to adjust the display brightness (0%-100%).




Alarm Volume Setting

Slide the [VOLUME] button to adjust the alarm volume (15-90 dB).



USB Charging (5V 1A)

There is a USB output port at the side of the clock to charge your device like cellphone etc.



USB cable not included

Our Warranty

90-day money back guarantee

366-day free replacement

✉ sales@us-myehome.com



FCC statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.