

Warning

1. Don't deep in water and avoid dropping.
2. Don't expose headset to extreme temperature, moisture or electric shock.
3. Don't attempt to open the unit for any reason, don't attempt to manipulate any electrical components in the unit.
4. Don't attempt to use it internal components have been exposed to liquid.

Label Position

NOTE : LABEL is too large to be printed on the product, so it is printed in the packaging box and instruction manual

SHENZHENSHI ANNSO TECHNOLOGY CO.,LTD
 Product Name : Bluetooth headset
 Mode: S500
 FCC ID: 2AZC2-S500
 Input:DC 3.7V 0.333Wh by battery
Made in China

6

Technical Specifications

Chip	QCC3020
Wireless Version	V5.0
Profiles	HSP HFP A2DP AVRCP
Battery Capacity	90mAh
Talk Time	14 Hours
Play Time	15 Hours
Charging Time	2 Hours
Standby Time	320 Hours
Weight	0.46 oz
Connection Range	33 ft/10 m


Bluetooth V5.0	
Modulation	GFSK
Operation frequency	2402MHz-2480MHz
Max Peak Output Power	8.2 dBm
Channel number	40
Channel separation	2MHz
Antenna type	Ceramic Antenna
Antenna gain	1.1 dB

7

What's in the box



Wireless Headset



3 x Ear Tips



Micro USB Cable



Carrying Case

8

Wireless Headset User Manual



Model: S500

FCC ID:2AZC2-S500

Overview



- ① Indicator Light
- ② Multi-function Button(MFB)
- ③ Micro USB Port
- ④ Volume Up
- ⑤ Volume Down
- ⑥ Microphone

2

The Basics

Power ON/OFF	Hold the MFB for 3 seconds
Answer a call	Tap the MFB
End a call	Tap the MFB to end current call
Reject a call	Hold the MFB for 2 seconds
Call back last call	Double-tap the MFB
Volume up/down	Tap the volume+/-
Next Song	Hold the volume- for 2 seconds
Prev Song	Hold the volume+ for 2 seconds
Mute ON/OFF	Hold the volume+/- for 3 seconds
Voice assistant	Hold the MFB for 2 seconds
Reconnect	The headset will auto reconnect to the last connected device once power on

3

Pairing

1. How to pair?



- ① Hold the MFB for 5 seconds, the indicator flashes BLUE and RED.



- ② Switch on phone's Bluetooth.



- ③ Select "S500", connect it.

4

2. Pair with 2 phones

- ① Pair the headset with your phone A.
- ② Switch off your phone A's Bluetooth.
- ③ Pair the headset with your phone B.
- ④ Switch on your phone A's Bluetooth, connect the headset to your phone A manually.

Charge

1. Charge the Bluetooth headset with came USB cable.
2. Make sure it's fully charged before the first use.
3. To preserve battery lifespan, please be sure the headset is fully charged every 45 days.

5

FCC STATEMENT:

1.This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm between the radiator & your body