





BBQ GO

Smart Wireless BBQ Thermometer

FAQ

1. Why the probes display inaccurate temperature? Such as 572F or the screen displays '-----'?

Answer: First please check the probes whether firmly inserted in the unit and you may hear a click sound. Customers really need push it hard in. Then change probes to insert in different ports to check if the probe itself has problem. Please make sure your probes firmly inserted, otherwise will display '-----' even if the cell phone pair with Bluetooth successfully.



2. Can I put this unit in high temperature places?

Answer: No, it can't. The plastic back magnet temperature should not over 80°C/176°F. Otherwise the unit will melt. Probe temperature range: 32°F ~ 572°F; (Short-time measurement); 32°F ~ 482°F (continuous monitoring)

3. Why cell phone can not search the app?

Answer: Please open your phone's GPS if your phone is Android system.

4. Why I need a 4 number pin code? What's correct steps to pair with cell phone?

Answer: This unit no need for pin code. Here are two solutions:

First, for some customers who have used our Inkbird other thermometers before, you have to delete the previous record, then to pair with this product. Because one cell phone can only connect one unit at one time.

Second, the correct procedure is activate your Bluetooth on your phone firstly, turn the device on, open the BBQGO APP and press the start button to search, which may take about 4 seconds to search the device signal, then short press the power button on the unit to connect.

5. Can one unit be linked up to multiple phones or one phone connected with multiple units?

Answer: One phone can only connect with one unit at one time.

6. Are the probes and wires waterproof?

Answer: No. Only the meat ends are waterproof.



7. Does this unit have low/high temperature alarm function?

Answer: Yes

8. Is there any graphing or save of previous cook data?

Answer: It can only display the current cooking data. Which can't be saved or download.

Get to know the device



Inkbird 150 feet Bluetooth thermometer IBT-6XS with 6 probes has rechargeable battery, magnet and readable rotation screen. The battery can last 40-60 hours once fully charged. The 6 probes can help you monitor the temperature of your meat at the same time. And it has high and low alarm setting. This unit can free you to have fun with your families or friends when doing barbecue. It's also a perfect choice for the gift.

Charge the device

This device use a built-in non-detachable lithium battery, usable charging and power supply. Please note that:



Download the APP

Search the keyword "bbq go" in Appstore or Google Play, or scan the following QR code with your phone. Download and install it for free.


Make sure your phone meets the requirements: Please open your phone's GPS before paired with the unit if your phone is Android system. iPhone 4S, and later models; iPod touch 5th, iPad 3rd generations and later models, all iPad mini; Android devices running version 4.4 or later, with blue-tooth 4.0 module.



Install the probes

The device will keep scanning the sockets when its power is switched on, the Probe Indicators will blink one by one from 1 to 6 where probes are plugged in.

Then insert the probes into the food, make sure the front tip of the probe is in the center of the food to get accurate temperature.



How to pair this unit with your phone?


1 Press and hold the power button of the screen for 3 seconds to power it on.

2 Attention here, please don't use the Bluetooth to search signal directly. Otherwise it will need pin code. Actually we don't need pin code. Open your Phone's Bluetooth first, then open your BBQGO app and use the app to search signal. Press the Start icon, it will scanning. Please short press the button of the screen on your device once your phone find the signal. Then connect successfully.

Once paired the device with your phone, you don't need to do it again, unless you change to other phones.

Enjoy your barbecue time

Choose the food type and preference for the food where each probe is inserted, the app and the device will display its current and target temperature. When the food is ready, the app and the device will alarm.



The user interface of the app may be changed when upgraded. Please follow the instructions in the app.


Power ON/OFF

Power ON:
Press and hold the power button for 3 seconds.

Power OFF:
• Press and hold the power button for 3 seconds.
• Auto-off after 8 hours out of connection with phone.

Warning

1. Please don't put this unit in high temperature place more than 176°F. Otherwise the plastic will melt.
2. The heat resistance varies in different components of the probe, DO NOT put the probes directly in the fire frame.
3. And probes are NOT dishwasher safe.
4. Please DO NOT put the teflon cable and the connecting part (between the sensor and teflon cable) into the water.



Teflon cable with stainless steel mesh (Length: about 120cm / 3.9ft)

App Store is a service mark of Apple Inc.
Google Play is a service mark of Google Inc.

FCC ID: 2AZDE-IB-IBT02

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference
(2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.