

EN
AD

S8 Pro

User Manual

Thanks for using our wireless electronic products. For a good user experience, please read the manual carefully before using the products. Notice: To avoid unnecessary troubles, please do not disassemble these products by yourself and use the standard charger to charge.

1

Product Overview

- Choose the ear cap that suits you.

2

Make sure that the ear caps face down and put the earbuds into the ear in the angle shown as the picture on the right.

- After putting on the earbuds, gently rotating the earbuds to a comfortable and secure position shown as picture 3 on the right. Now the earbuds are put on correctly!

Error demonstration

Do not wear the earbuds like the way shown as the picture on the right

-

3

First time using

- Tear off the insulating film.
- Put the earbuds into the charging case to charge.

4

- Take out from case, the indicator will turn to Red and Blue alternately.

Warm notice If the earbuds are not turned on or there is no sound come out, please put them back in the charging case again to make sure that they are in the charging state before taking them out for use (red/blue light flash alternately)

Red/Blue Flash

Indicator off

- The indicator of one earbud will go off and another will flash red and blue light alternately. (In pairing mode)

5

- Turn on the Bluetooth function on your phone and search for **【S8 Pro】** and connect it.

Warm notice

- △ If indicators of both earbuds keep flashing red and blue, Click either earbud's power switch twice. Then the indicator of one earbud will flash red and blue alternately, another will go off. (in pairing mode)
- △ If you want to switch the Bluetooth connection to another device, please disable the Bluetooth function in the previously connected device OR delete the pairing name of "S8 Pro" from the original device. Then the pairing name of "S8 Pro" can be searched in new device and connected successfully.

6

Button control

MFB Power Switch

Left Earbud Right Earbud

7

- 1x Accept L/R Earbud
 - Hold Decline L/R Earbud
 - Hold Reject L/R Earbud
 - 3x Voice assistant L/R Earbud
 - 2x Previous track L Earbud
 - 2x Next track R Earbud
 - Hold Volume- L Earbud
 - Hold Volume+ R Earbud
 - 1x Play / Pause L/R Earbud

Warm notice
For any single earbud, when it is in standalone mode, you can't use it to play the previous song or decrease the volume.

8

Siri and other Voice Assistant

L/R Earbud

IOS and part of the Android users can triple click the left or right power switch to turn on the voice assistant.

The voice assistant will be automatically activated depends in different OS in mobile system.

9

Restore factory setting

L&R Earbud

- Please turn off the Bluetooth of the mobile phone and the earbud light will flash red / blue. Quickly press the power button of the earbud four times.

- Please delete all paired records on the phone and re-search **【S8 Pro】** after clear the pairing and reconnect.

10

Earbuds indicator

Status	Light
Turn on	The blue light flashes for 1 second
Turn off	The red light flashes for 1 second
Search earbuds	Red and blue light flash alternately
Music play	No light
Low battery	Red light of earbud flashes once every 6s
Charging	Red light on
Full battery	Red light off

11

Charging case indicator

Status	Indicator
Low Battery	Red light flashes
Charging	Red light on
Full Battery	Green light on
Charging for case	Red light on
Charging for earbuds	Red light on
Low Battery	Red light flashes

Charging case
Please use a charger with an output voltage of DC5V/1A to charge the charging case. You can also use a computer USB or other USB interface charger to charge (Must choose a charger certified by a regular manufacturer)

12

Parameter specification

Version	V5.2+EDR
Support	A2DP,AVRCP,HFP,HSP
Transmission distance	10m
Frequency range	2.402GHz~2.480GHz
Hi-fi equipment	Φ6mm*2
Impedance	16Ω
Standby time	70 hours
Talk time	5 hours
Listening time	6 hours
Earbud battery capacity	55 mAh
Charging time	1.5 hour
Charging case battery capacity	400mAh
Charging case charging time	About 1.5 hours
Weight(single earbud)	4.7 g

13

Signal transmission distance shown as below:

≤10m Signals is in normal transmission.

>10m Signals will be interrupted.

Notice:

- If the charging case is out of power, it may cause the earbuds to fail to shut down and remain connected to the phone even when they are placed in the charging case. So please remember to charge the charging case in time.
- If moisture remains at the audio output hole, the sound may become fuzzy or completely inaudible. This is completely normal. In this case, please remove the earplugs and shake the audio output hole down several times to allow water to flow out or let it air dry for 1-2 hours, then the sound quality will become normal.

14

Attentions

The Charging cable is not waterproof
The Charging case is not waterproof
Do not use hot water to disinfect the product

If there is water droplet on the surface, please wipe it with a dry cloth before putting them back into the charging case to avoid damaging the device.

Tip:

- If the product is dirty, please do not rinse it directly with water or use boiling water to soak and disinfect it. It is recommended to wipe the earbuds with an alcohol cloth or a wet paper towel.
- If the product falls into the water accidentally, please pick it up in time and dry it with natural wind or dry it in the sun for two hours before using it. (Otherwise it will affect the sound quality, thus fail to give you a better using experience)

15

Battery Warning !

There is a built-in lithium battery in this product. To avoid explosion, do NOT expose the product to strong sunlight, fire or throw it into fire.

16

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

17