



Xanland

User Manual


Dog Training Collar




Model: P9

Thanks for purchasing our products. For optimum performance and safety, please read this manual carefully before operating the Dog Training Collar and keep this manual for future reference.

Product Introduction



Screen



Package Content



Remote Transmitter



Receiver Collar



Test Light



Collar



Contact Points



Conductive Silicone Caps



USB Charging Cable



Wrist Strap

Product Specification

Product Name	Dog Training Collar
Model	P9
Charging Voltage	Input Voltage: AC100-240V Output Voltage: DC5V 1000mA
Battery	Li-Polymer Battery
Remote/Receiver Charging Time	1-2 Hours
Remoting Distance	Normal Environment: 1800ft Open Space: 3000ft
Function	Beep, Vibrate, Shock, Lighting


How to Install the Contact Points and Conductive Silicone Caps

1. Select the correct length of contact points and conductive silicone caps for your dog.

- For thick-haired dogs, use 2 longer contact points and conductive silicone caps.
- For short-haired dogs, use 2 shorter contact points and conductive silicone caps.


2. Insert the contact points into the ports of the receiver and tighten them clockwise.


3. Install the silicone caps on the contact points to protect your dog's skin from direct contact with the metal electrode.







How to Operate the Transmitter and Receiver

1. Press any button to activate the Transmitter.





2. Press  button once, the green light flashes once and the receiver beeps once, indicating the receiver is on.




3. Press    button once to send a vibration, beep, shock command to Receiver Collar.




4. Press  button once, the red light flashes twice and the receiver beeps twice, indicating the receiver is off.





How to Adjust the Shock Level and Vibration Level

1. Press  button once until the shock symbol flashes, then press "+" "-" button to adjust the shock level from 1-16.


2. Press  button once until the vibration symbol flashes, then press "+" "-" button to adjust the vibration Level from 1-8.

Note:


- To avoid hurting your dog, please always start at the lowest level of Shock and Vibration. The appropriate level can be found when the dog reliably responds to the vibration/shock.**
- Do not hold   for a long time to avoid physical or psychological harm to the dog.**

How to Use the Collar Correctly


1. Unfasten the nylon belt and remove the slide buckle.




2. Thread the nylon belt through the Receiver.




3. Thread the nylon belt through the slide buckle.



4. Thread the nylon belt through the side release buckle.



5. Thread the excess nylon belt through the slide buckle to make sure your collar is securely fastened.




How to Put the Collar on Your Dog

1. With your dog standing, center the contact points underneath your dog's neck.








2. If your dog has thick fur, please use a comb to separate the fur at the electrodes to enable them to reach the skin.



3. The contact points must be in direct contact with the dog's neck skin. The tightness is best if one finger can be inserted between the collar and neck.




How to Pair the Remote Transmitter with Receiver

1. Turn on the Receiver.
2. Press and hold  button until the green light flashes and the receiver beeps three times.
3. Press  /  /  /  button on the transmitter, then pairing is completed.

Three Dog System

1. If the Transmitter is paired with more than one Receiver, press the **CH** button to select the Receiver you want to control.



2. If Dog B or Dog C Receiver does not respond. Pairing may be required.
3. "All" Modes: Press **CH** button four times, the symbols of DOG A, DOG B, and DOG C will be displayed simultaneously. At this point, the transmitter can control all three dogs at once.

NOTE:

There is only one Receiver Collar in the package. If you would like to add more Receiver Collars to your training system, please purchase the same model.

How to Use Test Light Tool

1. Make sure the Transmitter and Receiver Collar are paired.
2. Put the test light tool vertically on the 2 contact points.
3. Press ⚡ button on the Transmitter, then the test light will flash.
4. Turn the Receiver Collar off.



Note: The higher Shock level is, the brighter the test light will be.




Keypad Lock Function

Press 🔒 button for 3s to turn on/off the keypad lock function.


Lighting Function

1. Press 🔦 button to turn the LED light on.
2. With the LED light on, press once to switch to Strobe mode.
3. Click again to turn the LED light off.




How to Charge the Transmitter and Receiver

1. Use the USB cable included to connect both the Transmitter and Receiver.



2. Plug the USB cable into an adapter (not included) or a power bank.



3. Fully charge the two units before first use.

Note:

1. When the Transmitter is charging, the LED indicator will turn red. When fully charged, the LED indicator will turn green and the screen will display four bars of power.
2. When the Receiver is charging, the LED indicator will turn red. When fully charged, the LED indicator will turn green.
3. When the battery is less than 5%, the indicator will turn red and blink.

To Maximize the Distance

The remote range depends on the way of the Transmitter being held. For best results, keep the Transmitter in a vertical position away from your body and above your head.



Maximum Range



Typical Range



Minimum Range

Note:

Avoid touching the antenna, as the range may decrease substantially.

Trouble Shooting

Q: My dog does not respond when I press a button.

- A:
1. Make sure the Receiver Collar has been turned on.
 2. If the range has reduced compared to the first time you used, please check the battery status of the Transmitter or Receiver.
 3. Verify if the remote range is affected by weather, terrain, vegetation or other factors.
 4. Test the Receiver with the Test Light to confirm if the shock function works.
 5. Increase the vibration/shock level.
 6. Make sure the Contact Points of the receiver are placed snugly against your dog's skin.

Q: The Receiver collar is not responding to the Transmitter.

- A:
1. Check if the Receiver is on.
 2. Check if the Transmitter is fully charged.
 3. Check if the Receiver is paired.
 4. Check if the keyboard lock is released.

Q: How often should I charge the device if I don't use it regularly.

- A: Please charge the device every 3 months to extend its battery life. It only takes two hours to fully charge the two devices.

Warning

1. Do not use the product on dogs under 6 months of age.
2. Do not use the product when your dog is in heat, pregnant or in poor health.
3. Do not allow children or anyone who has never trained a dog to use this product.
4. Do not disassemble the product at will.
5. If your dog reacts with fear during training, check if the shock/vibration level is too high for your dog.
6. Use "shock" as little as possible and strengthen verbal commands when necessary. Don't over-correct your dog's behavior.
7. Before using the product, your pet should be able to recognize basic obedience commands, such as "sit" or "stay".
8. Do not operate the device at temperatures of 104°F and above, which may degrade battery performance.
9. Do not put the collar on your dog for more than 12 hours as it may cause a rash or irritate your dog's skin.
10. When you are not training the dog, please set the product to keypad-lock mode or remove the collar from the dog's neck.

For More Information and Help, Please Visit



info@xanland.net



[Xanland](#)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.