刀模线不印刷

单号: Y20220115001 型号: 63030BT 尺寸: 160x110mm(展开) 印刷材质及要求: 80g书纸,正反面单色印刷,<mark>虚线是折线</mark>,2折页


正面印刷



SPECIFLCATION:

Speaker Output: 3W Battery capacity: 400mAh Material: ABS

FUNCTION KEYS:



ON/OFF:

Hold the power button about 2-3 seconds, turn on the power, and turn on the Bluetooth indication, During the play, hold the power button about 3 seconds, and the Bluetooth speakers turn off.

背面印刷

BLUETOOTH CONNECTION:

Use cell phone or other device search Bluetooth pairing name "SHELL SHOWER SPEAKER" to connect.

PRODUCT DESCRIPTION

MAKING PHONE CALLS VIA A BLUETOOTH COMPATIBLE DEVICE:

Once the Bluetooth compatible device has been paired with speaker, phone calls can be made.

- **STEP 1:** Using the Bluetooth compatible device, dial the number to be called and select the Bluetooth/hands-free option. The speaker and its built-in microphone will now act as a hands-free device.
- STEP 2: To answer or disconnect a call, press "......"
- STEP 4: Pressing "
 "twice will redial the last number called from the Bluetooth compatible device.

MUSIC BEHAVIOR:

a. Press ON/OFF button to pause/play the music

CHARGING:

Connect the charging cable to speaker's Micro USB port, insert the other end to a adapter in $\mathsf{SV}(\mathsf{not}\ \mathsf{include}).$

A red light is on when charging, and will switch off when full charge is reached.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.

- - Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- - Consult the dealer or an experienced radio/TV technician for help.