



shenqiwei®

ITEM NO.2010B

HIGH SPEED TOP RACING
SPRINTERS
R/C
ACING
HIGH SPEED

(Instructions)


Please read the instructions carefully before operating the toy.
Please keep this instruction sheet for future reference.

Prepare

1. Tear off the sticker, open the transparent cover in the direction of the arrow.



3. Use a phillips screwdriver unscrew the screws at the bottom of the car by the direction of the arrow, remove the race car.




5. Press any button and the indicator light is on, this proves that the battery installed correctly.



Indicator light

Charge


1. As shown in the figure, turn on the battery cover, take out the charge plug.



2. Insert the charging plug into the charging port under the car, the indicator light is on, indicating that it is charging.

Notice:


The car can be charged only when the switch of car in the OFF position.




Charging plug

3. When the charging light goes off, The mini racer is fully charged.

Charging light




Content




Mini racer x1




Transmitter x1



Manual x1




Antenna x1



2. As shown, use a phillips screwdriver to unscrew the screws between controller and car with the direction of the arrow, take out the car with the base.

4. Open the battery cover and insert 2*AA batteries with correct polarity
*The remote control can only use alkaline batteries. Do not use other types of batteries.



6. Insert and tighten the antenna to the antenna hole on the transmitter as illustration showed.



Operate

1. Extend the transmitter's antenna for better signal reception.

2. Remote control button functions:

(1) After pressing the remote control button, the indicator light will light up, and the car will act accordingly.

(2) When pressing the forward/backward button, the car can go forward/backward.

(3) When pressing the forward/backward

button and the left/right button at the same time, the car can turn left/right.

Indicator light


Forward

Backward



Charging light

Turn left

Turn right



3. Adjust the trimmer on the bottom front of the car to adjust the straight-line performance of the car.



Trimmer

Caution:

- The car itself uses 1.2V 1/4AAA NI-MH rechargeable built-in battery, the remote control uses 2*1.5V AA batteries (not included);
- The racing car has super power. When driving at high speed, it cannot brake suddenly due to inertia. Please specially pay attention when in use.
- If the car slows down obviously during running, it may be due to lack of power, please charge the car following the instruction.
- When the battery of the remote control is dead, the indicator light turns dim. The car cannot be charged, please replace the new battery for remote control.
- Pay attention to the charging plug and charging position when charging.
- When not in use for a long time, please take out the battery of the controller and turn the power of the racing switch to "OFF" location.
- Non-rechargeable batteries shall not be charged. Rechargeable batteries should only be charged under adult supervision.
- New and old batteries or different types of batteries must not be mixed.
- The rechargeable battery should be removed from the toy before charging. Exhausted batteries should be removed from the toy;
- Batteries should be inserted with correct polarity to avoid installation errors.
- The supply terminals are not to be short-circuited.
- Unpack under adult supervision.
- Please keep the above information for future reference.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.