


1. Skizze Pen Driver Downloads

- ① Download from Microsoft Store
- 2 Download from <u>www.skizze.cn</u>


2.Components Overview

Please read the main components and their corresponding functions before using.



3.Use a super-power pen

- 1. Installation is successful, input user ID, pen tip verification is successful, Bluetooth is connected automatically, and pen is enabled.
- 2. Installation successful, input user ID, pen tip verification successful, confirm to enable pen
- 3. Click on the key, the pen tip indicator is white, and the pen enters the starting state.
- 4. The pen tip indicator is white, and the pen is connected with the touch device.
- 5. Writing, PPT demonstration, flying squirrel function in the air began to use



Remarks: Use conditions of super-energy pen:

- 1. Only Windows 101709and above are supported;
- 2. The touch screen system supports Bluetooth (the device has its own Bluetooth function or an external Bluetooth dongle);
- 3. The touch screen supports fine nibs.

4. Windows Ink writing

Set up The function setting interface for shortcut key click and double click is as follows:




Press the rubber key long enough to erase the handwriting.

5.Status of Smart Pen

Operation and status description of On/Off button

Button Name	Operation	Function	Nib Indicator Status
On/Off & Shortcut	Click Once	Power on	3 times white blink
	Pressand Hold	Power off	4 times green blink


Notes: Click once to check the pen's connection status when power on



NibIndicatorStatus	Battery Condition

6. Charging

Blink in red	Low Battery	
Red on	Charging	
Green on	Fully Charged	



7、ReplaceNib



The nib is a consumable item, if the nib is worn during use, please replace it as shown above.

Remark:

The package contains two spare nibs, if you want more extra, please purchase on authorized website.

The smart pen contains precision components. Do not disassemble when replacing the pen nib.

8. Safety information

Please read the safety precautions carefully before using this smart pen:

⚠ Power cord security

When charging, please put the smart pen in a proper position

⚠ Do not try to repair

Do not attempt to disassemble, repair, or change any part of the product to avoid risk to you.

If the after-sales service technician finds that the smart pen has traces of damage, your product will lose its warranty.

The smart pen contains tiny structural parts. Keep your smart pen away from children.

⚠ Cleaning

Use a damp cloth to clean the appearance of the smart pen. Avoid touch the charging interface with aerosols, solvents, abrasives, etc.

⚠ Battery

Smart pen contains sensitive electronic components, such as batteries, which can be damaged or cause personal injury if dropped, squeezed, or exposed to liquids.

The smart pen device is not removable. Do not replace the battery yourself, resulting in overheating or personal injury. Battery replacement is done by designated after-sales service personnel.

Do not use the smart pen in a place that is wet, dusty, or near a magnetic field to prevent the pen from malfunctioning.

Store the smart pen at -20 $^{\circ}$ C ~45 $^{\circ}$ C . If the temperature is too high or too low, it may cause equipment malfunction.

Do not place the smart pen near fire or heat sources such as electric heaters, water heaters, candles, and other places that are prone to high temperatures.

2. Name and content of harmful substances in products

Harmful substances	Components	
	РСВ	Accessory
Pb	×	×
Нg	0	0
Cd	0	0
Cr (VI)	0	0
PBB	0	0
PBDE	0	0

O: Indicates that the content of harmful substance in all homogeneous materials of the part is below the limit requirement specified in GB/T 26572.

×: Indicates that the content of the harmful substance in at least one of the homogeneous materials of the part exceeds the limit requirement specified in GB/T 26572-2011, but meet the environmental protection requirements of the EU RoHS Directive.

According to the Chinese electronic industry standard SJ/T 11364-2014 and related Chinese government regulations, this product and some of its internal or external components may have an environmentally friendly use period mark, depending on the component and component manufacturer, the mark lifespan on the product and its components may vary. The expiration date on the component takes precedence over any conflicted or different UFUP labels on the product.



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.