



正面

Wireless Speakerphone




User Manual


What's in the box




Wireless Speakerphone X 1



Expansion Microphone X 2




USB Cable X 1




User Manual X 1

Overview




Easy Set-Up

1. On/off

Long press ON/OFF  for 2s, device will be turn on/off, with beep notice.


2. Connect to speak 200 USB & BT

2.1 Connect by Bluetooth
Press Bluetooth button for 2 seconds to start Bluetooth pairing mode. It will be alternate white and blue flashing light.
2. Turn on the Bluetooth on your device and choose to connect with the Speakerphone. After connected, it will be white flashing light and with hint tone.
While Bluetooth disconnected, light will be blue with hint tone.




2.2 Connect by USB

Connect Speak 200 USB & BT with computer by USB cable. After connection, the green circle light will increase clockwise one by one showing charging status. Green circle light will be on in full when charging completed.




2.3 Connect by Wireless Receiver



Connect the USB wireless receiver to your computer, and start Bluetooth pairing mode on speakerphone. Wait for about 10 seconds until the pairing is completed, then the speakerphone is connected and ready to go.





3. Audio source switching function

When device is connected by Bluetooth and USB simultaneously, short press / tap the Bluetooth button  to switch between Bluetooth and USB transmission.



4. Answer /end calls

Press  button to answer calls, press  button to end calls.

5. Volume increase/decrease

When volume increase  /decrease  , the green lights will on/off one by one.When adjustment completed, lights will off after 4s.


6. Mute

6.1 Press Mute  , microphone audio input will stop.
6.2 Long press the mute key  for about 2s to switch Microphone short-distance mode: Microphone short-distance mode is for eliminating surrounding noise automatically and only voice within radius range of 1.5 meters will be picked up and transmitted. Also speaker volumn will be adjusted automatically according to surrounding noise. VoiceCap model is only suggested in open space.
Please disable this function when in conference rooms.

7. Auto Power Of


When device is not connected by Bluetooth or USB in 15mins, it will shut down automatically.

8. Power indicator

When device is not connected by USB, short press / tap power button  , the green circle light will indicate power condition.


反面

会议全向麦克风




用户手册


包装清单




会议全向麦克风X1



拓展麦克风X2




USB数据线 X 1



用户手册 X 1

产品概览







快速安装指南

1. 开/关机

长按电源键1.5秒, 开机或者关机, 并配提示音, 开机按键白色灯常亮, (开机前已经配对并未断开时, 提示蓝牙已连接。)


2. 连接SPEAK 200 USB&BT设备

2.1 蓝牙连接
长按蓝牙键2秒启动蓝牙配对模式, 此时  白蓝灯交替闪烁, 打开手机蓝牙或者电脑蓝牙, 选择SPEAK 200 USB&BT蓝牙名称连接, 连接完成后,  白色交替闪烁, 并配提示音。断开蓝牙后  蓝灯常亮, 并配提示音。




2.2 USB连接

用USB连接线将SPEAK 200 USB&BT与电脑连接当充电或者短按电源键时, 以绿色光作为充电/电量指示。




2.3 接收器连接 (选配)



将USB接收器先插入电脑USB口, 再将设备开机, 打开蓝牙配对模式, 等待15秒左右, 配对完成。





3. 音源切换功能

当蓝牙和USB声卡同时连接, 短按/轻触  , 切换到蓝牙或者USB声卡。



4. 电话接听/挂断功能

通话状态时, 按下  通话键, 电话挂断。
电话呼入时, 按下  通话键, 接听电话。

5. 音量调节功能

调音量  或者  时灯圈亮绿灯, 每加减一个等级绿灯就亮一个或灭一个, 调完4秒后全灭。


6. 麦克风静音功能

6.1 短按/轻触静音键  , 禁止麦克风声音输入。
6.2 长按静音键  2s左右进行音区模式切换到近距离模式: 麦克风近距离模式可自动消除周围嘈杂的噪音, 仅将拾音范围 (半径1.5m) 的声音传给对方, 而且可以根据周围的噪音自动调整扬声器音量。
在开放空间使用本产品时, 请启用; 在会议室内使用时, 请禁用。

7. 自动关机功能

蓝牙和USB没连接状态下, 15分钟后自动关机。

8. 电量指示功能

USB断开的状态下, 短按/轻触电源键  , 绿色灯圈会指示电量情况。

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.