


SP-4236 PS4/PS3 Wireless Game Controller User Manual

Product Features

1. Dual shock motor, 256-level precision 3D joysticks
2. With 6-axis Motion Sensor
3. 2-Points Touch Pad support both touch and press action
4. Support both PS3 and PS4 console
5. With 3.5mm headphone jack and microphone
6. With wake-up function when the console at sleep mode by press home button
7. With additional L3 R3 buttons at the back of the controller
8. This game controller does not support PS VITA TV

Buttons Descriptions





Connection Methods

Connect the Play Station console to this controller with the USB charging cable, after the LED indicator light turns on, press the home button to get into the login page and select your user account, the connection procedure is completely finished, now you can pull out the USB charging cable and enjoy the Bluetooth wireless connection. there is no requirement of the USB cable for the next Bluetooth connection.

Support Multiplayer game

Under the multiplayer game status, press the PS button and then the RGB led bar will light on in blue, red, green, pink order to distinguish the user`s login order (1P :Blue 2P: Red 3P: Green 4P: Pink)

Warm tips

- 1) Do not expose the product to strong light.
- 2) Do not beat the product vigorously.
- 3) Do not use or store this product in a hot or humid environment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.