

产品包材图档




PRODUCT INTRODUCTION



LED LIGHT INSTRUCTIONS

HOW TO CHARGE









APPLICABLE DEVICES

PRODUCT SPECIFICATION

PACKING LIST

Wireless Charger*1, Type-C quick charge cable*1, User manual*1

1. If you're experiencing interrupted or slow charging, check the following: (1) The back of your phone should not have any metal, pop sockets, or credit cards. (2) Put the phone in the center of the charging surface (this lets the charging coil in you phone lineup with the one inside the wireless charger). (3) The wireless charging coil on Sony phones is located slightly below center. (4) Phone cases should be no thicker than 5 mm for effective charging. (5) Check whether the adapter is QC3.0 fast charger.

2. If you're failing to charge your device, please try out the following:

3. If you're using the recommended wireless charger with the QC3.0 Adapter and have removed any potential charging obstructions, but are still experiencing issues, try this:

(1) Replacing the cable connecting your wireless charger.

(2) Rebooting your phone.

(3) Unplug the adapter and reinsert.

Charging is still slow. The mobile phone itself or the external receiving coil allows the wireless charging current to be different, or the application running consumes a lot of power when the mobile phone is charging. It is recommended to reduce or close the application.

5. The phone is charging intermittently, or the indicator light flashes.

7. The charger does not work.

WARNING

If the charging current is not enough, please use a adapter with sufficient 18W above.

8. If there are another problems, please contact our after-sales for solution.

All products brands and trademarks are property of their respective owners.

6. Charging fever.

It is normal for the receiving coil or transmitter board to generate heat during wireless charging. If the wireless charger is too hot, please take your phone off it, when the wireless charger is cooled down, please charge it again.

Do not put metal debris or magnetic cards on the charging area. If the product does not work due to overheating, please take off the phone and charge it again when it is cooled down.

FCC STATEMENT

FCC RADIATION EXPOSURE