




PSD NVNT ax20 6535MHz Ant2




PSD NVNT ax20 6695MHz Ant2






PSD NVNT ax20 6855MHz Ant2



PSD NVNT ax20 6875MHz Ant2





PSD NVNT ax20 6995MHz Ant2




PSD NVNT ax20 7115MHz Ant2





PSD NVNT ax40 5965MHz Ant1



PSD NVNT ax40 6205MHz Ant1





PSD NVNT ax40 6405MHz Ant1



PSD NVNT ax40 6445MHz Ant1





PSD NVNT ax40 6485MHz Ant1



PSD NVNT ax40 6565MHz Ant1



PSD NVNT ax40 6685MHz Ant1



PSD NVNT ax40 6845MHz Ant1





PSD NVNT ax40 6885MHz Ant1




PSD NVNT ax40 6965MHz Ant1







PSD NVNT ax40 7085MHz Ant1



PSD NVNT ax40 5965MHz Ant2





PSD NVNT ax40 6205MHz Ant2



PSD NVNT ax40 6405MHz Ant2





PSD NVNT ax40 6445MHz Ant2



PSD NVNT ax40 6485MHz Ant2





PSD NVNT ax40 6565MHz Ant2



PSD NVNT ax40 6685MHz Ant2





PSD NVNT ax40 6845MHz Ant2




PSD NVNT ax40 6885MHz Ant2





PSD NVNT ax40 6965MHz Ant2



PSD NVNT ax40 7085MHz Ant2



PSD NVNT ax80 5985MHz Ant1



PSD NVNT ax80 6225MHz Ant1






PSD NVNT ax80 6385MHz Ant1




PSD NVNT ax80 6465MHz Ant1







PSD NVNT ax80 6625MHz Ant1




PSD NVNT ax80 6705MHz Ant1





PSD NVNT ax80 6785MHz Ant1



PSD NVNT ax80 6945MHz Ant1






PSD NVNT ax80 7025MHz Ant1



PSD NVNT ax80 5985MHz Ant2






PSD NVNT ax80 6225MHz Ant2



PSD NVNT ax80 6385MHz Ant2




PSD NVNT ax80 6465MHz Ant2




PSD NVNT ax80 6625MHz Ant2



PSD NVNT ax80 6705MHz Ant2



PSD NVNT ax80 6785MHz Ant2





PSD NVNT ax80 6945MHz Ant2



PSD NVNT ax80 7025MHz Ant2





**A.6. Emission Mask**

Condition	Mode	Frequency (MHz)	Antenna	Sub Band	Worst EIB Frequency (MHz)	Level (dB)	Limit (dB)	Verdict
NVNT	ax20	5955	Ant1	Band1	5987.67	-50.71	-40	Pass
NVNT	ax20	6175	Ant1	Band1	6141.7	-45.54	-40	Pass
NVNT	ax20	6415	Ant1	Band1	6447.74	-48.68	-40	Pass
NVNT	ax20	6435	Ant1	Band1	6468.36	-48.25	-40	Pass
NVNT	ax20	6475	Ant1	Band1	6509.48	-48.02	-40	Pass
NVNT	ax20	6515	Ant1	Band1	6553.45	-46.98	-40	Pass
NVNT	ax20	6535	Ant1	Band1	6569.48	-45.33	-40	Pass
NVNT	ax20	6695	Ant1	Band1	6656.97	-45.15	-40	Pass
NVNT	ax20	6855	Ant1	Band1	6819.96	-46.9	-40	Pass
NVNT	ax20	6875	Ant1	Band1	6836.52	-45.87	-40	Pass
NVNT	ax20	6995	Ant1	Band1	7032.06	-48.54	-40	Pass
NVNT	ax20	7115	Ant1	Band1	7146.07	-47.59	-40	Pass
NVNT	ax20	5955	Ant2	Band1	5994.82	-47.39	-40	Pass
NVNT	ax20	6175	Ant2	Band1	6138.73	-45.7	-40	Pass
NVNT	ax20	6415	Ant2	Band1	6450.2	-47.94	-40	Pass
NVNT	ax20	6435	Ant2	Band1	6400.25	-48.73	-40	Pass
NVNT	ax20	6475	Ant2	Band1	6509.61	-47.95	-40	Pass
NVNT	ax20	6515	Ant2	Band1	6547.35	-47.49	-40	Pass
NVNT	ax20	6535	Ant2	Band1	6571.69	-45.48	-40	Pass
NVNT	ax20	6695	Ant2	Band1	6655.72	-45.62	-40	Pass
NVNT	ax20	6855	Ant2	Band1	6818.55	-47.17	-40	Pass
NVNT	ax20	6875	Ant2	Band1	6841.05	-46.01	-40	Pass
NVNT	ax20	6995	Ant2	Band1	7027.53	-48.68	-40	Pass
NVNT	ax20	7115	Ant2	Band1	7146.39	-47.91	-40	Pass
NVNT	ax40	5965	Ant1	Band1	6026.28	-45.52	-40	Pass
NVNT	ax40	6205	Ant1	Band1	6125.45	-43.67	-40	Pass
NVNT	ax40	6405	Ant1	Band1	6336.94	-46.64	-40	Pass
NVNT	ax40	6445	Ant1	Band1	6384.52	-46.48	-40	Pass
NVNT	ax40	6485	Ant1	Band1	6545.54	-46.23	-40	Pass
NVNT	ax40	6565	Ant1	Band1	6626.63	-44.7	-40	Pass
NVNT	ax40	6685	Ant1	Band1	6623.98	-43.98	-40	Pass
NVNT	ax40	6845	Ant1	Band1	6783.78	-45.44	-40	Pass
NVNT	ax40	6885	Ant1	Band1	6823.62	-46.15	-40	Pass
NVNT	ax40	6965	Ant1	Band1	7035.18	-46.82	-40	Pass







NVNT	ax40	7085	Ant1	Band1	7159.27	-46.44	-40	Pass
NVNT	ax40	5965	Ant2	Band1	6026.41	-45.52	-40	Pass
NVNT	ax40	6205	Ant2	Band1	6143.11	-43.62	-40	Pass
NVNT	ax40	6405	Ant2	Band1	6336.94	-46.59	-40	Pass
NVNT	ax40	6445	Ant2	Band1	6514.34	-46.09	-40	Pass
NVNT	ax40	6485	Ant2	Band1	6546.54	-45.78	-40	Pass
NVNT	ax40	6565	Ant2	Band1	6626.6	-43.43	-40	Pass
NVNT	ax40	6685	Ant2	Band1	6623.78	-43.77	-40	Pass
NVNT	ax40	6845	Ant2	Band1	6778.89	-45.04	-40	Pass
NVNT	ax40	6885	Ant2	Band1	6817.7	-45.74	-40	Pass
NVNT	ax40	6965	Ant2	Band1	7026.31	-47.76	-40	Pass
NVNT	ax40	7085	Ant2	Band1	7146.82	-47.33	-40	Pass
NVNT	ax80	5985	Ant1	Band1	6126.82	-43.78	-40	Pass
NVNT	ax80	6225	Ant1	Band1	6096.81	-41.77	-40	Pass
NVNT	ax80	6385	Ant1	Band1	6258.34	-43.19	-39.93	Pass
NVNT	ax80	6465	Ant1	Band1	6337.45	-42.61	-39.95	Pass
NVNT	ax80	6625	Ant1	Band1	6500.2	-41.56	-40	Pass
NVNT	ax80	6705	Ant1	Band1	6830.95	-41.75	-40	Pass
NVNT	ax80	6785	Ant1	Band1	6650.41	-43.21	-40	Pass
NVNT	ax80	6945	Ant1	Band1	7073.38	-44.53	-40	Pass
NVNT	ax80	7025	Ant1	Band1	7151.72	-44.9	-40	Pass
NVNT	ax80	5985	Ant2	Band1	6112.81	-43.03	-40	Pass
NVNT	ax80	6225	Ant2	Band1	6096.42	-42.12	-40	Pass
NVNT	ax80	6385	Ant2	Band1	6258.79	-43.32	-40	Pass
NVNT	ax80	6465	Ant2	Band1	6339.24	-42.72	-40	Pass
NVNT	ax80	6625	Ant2	Band1	6497.7	-41.78	-40	Pass
NVNT	ax80	6705	Ant2	Band1	6577.06	-42.01	-39.98	Pass
NVNT	ax80	6785	Ant2	Band1	6655.72	-42.73	-40	Pass
NVNT	ax80	6945	Ant2	Band1	7072.74	-44.44	-39.95	Pass
NVNT	ax80	7025	Ant2	Band1	7153.38	-44.93	-40	Pass

Test Graphs


Power spectral mask NVNT ax20 5955MHz




Power spectral mask NVNT ax20 6175MHz




Power spectral mask NVNT ax20 6415MHz




Power spectral mask NVNT ax20 6435MHz




Power spectral mask NVNT ax20 6475MHz




Power spectral mask NVNT ax20 6515MHz




Power spectral mask NVNT ax20 6535MHz




Power spectral mask NVNT ax20 6695MHz




Power spectral mask NVNT ax20 6855MHz




Power spectral mask NVNT ax20 6875MHz




Power spectral mask NVNT ax20 6995MHz




Power spectral mask NVNT ax20 7115MHz



Power spectral mask NVNT ax20 5955MHz




Power spectral mask NVNT ax20 6175MHz







Power spectral mask NVNT ax20 6415MHz




Power spectral mask NVNT ax20 6435MHz




Power spectral mask NVNT ax20 6475MHz




Power spectral mask NVNT ax20 6515MHz




Power spectral mask NVNT ax20 6535MHz




Power spectral mask NVNT ax20 6695MHz




Power spectral mask NVNT ax20 6855MHz




Power spectral mask NVNT ax20 6875MHz




Power spectral mask NVNT ax20 6995MHz




Power spectral mask NVNT ax20 7115MHz




Power spectral mask NVNT ax40 5965MHz




Power spectral mask NVNT ax40 6205MHz




Power spectral mask NVNT ax40 6405MHz




Power spectral mask NVNT ax40 6445MHz



Power spectral mask NVNT ax40 6485MHz




Power spectral mask NVNT ax40 6565MHz







Power spectral mask NVNT ax40 6685MHz




Power spectral mask NVNT ax40 6845MHz




Power spectral mask NVNT ax40 6885MHz




Power spectral mask NVNT ax40 6965MHz




Power spectral mask NVNT ax40 7085MHz




Power spectral mask NVNT ax40 5965MHz




Power spectral mask NVNT ax40 6205MHz




Power spectral mask NVNT ax40 6405MHz




Power spectral mask NVNT ax40 6445MHz




Power spectral mask NVNT ax40 6485MHz




Power spectral mask NVNT ax40 6565MHz




Power spectral mask NVNT ax40 6685MHz




Power spectral mask NVNT ax40 6845MHz




Power spectral mask NVNT ax40 6885MHz



Power spectral mask NVNT ax40 6965MHz




Power spectral mask NVNT ax40 7085MHz







Power spectral mask NVNT ax80 5985MHz




Power spectral mask NVNT ax80 6225MHz




Power spectral mask NVNT ax80 6385MHz




Power spectral mask NVNT ax80 6465MHz




Power spectral mask NVNT ax80 6625MHz




Power spectral mask NVNT ax80 6705MHz




Power spectral mask NVNT ax80 6785MHz




Power spectral mask NVNT ax80 6945MHz




Power spectral mask NVNT ax80 7025MHz




Power spectral mask NVNT ax80 5985MHz




Power spectral mask NVNT ax80 6225MHz




Power spectral mask NVNT ax80 6385MHz




Power spectral mask NVNT ax80 6465MHz




Power spectral mask NVNT ax80 6625MHz



Power spectral mask NVNT ax80 6705MHz




Power spectral mask NVNT ax80 6785MHz






Power spectral mask NVNT ax80 6945MHz



Power spectral mask NVNT ax80 7025MHz





**A.7. Contention Based Protocol**

**a. Contention Based Protocol Calibration**

Condition	Mode	Frequency (MHz)	Antenna	AWGN Location	AWGN Frequency (MHz)	Injected Power (dBm)	Gain (dBi)	Path Loss (dB)	Adjusted Power (dBm)	Limit (dBm)
NVNT	ax20	6135	Ant1	Center	6135	-62.29	3.51	0	-65.8	-62
NVNT	ax20	6455	Ant1	Center	6455	-62.23	3.51	0	-65.74	-62
NVNT	ax20	6535	Ant1	Center	6535	-62.14	3.51	0	-65.65	-62
NVNT	ax20	6935	Ant1	Center	6935	-62.82	3.51	0	-66.33	-62
NVNT	ax40	6125	Ant1	Low	6110	-62.35	3.51	0	-65.86	-62
NVNT	ax40	6125	Ant1	High	6140	-62.47	3.51	0	-65.98	-62
NVNT	ax40	6445	Ant1	Low	6430	-62.36	3.51	0	-65.87	-62
NVNT	ax40	6445	Ant1	High	6460	-62.31	3.51	0	-65.82	-62
NVNT	ax40	6605	Ant1	Low	6590	-62.14	3.51	0	-65.65	-62
NVNT	ax40	6605	Ant1	High	6620	-62.2	3.51	0	-65.71	-62
NVNT	ax40	6925	Ant1	Low	6910	-62.5	3.51	0	-66.01	-62
NVNT	ax40	6925	Ant1	High	6940	-62.83	3.51	0	-66.34	-62
NVNT	ax80	6145	Ant1	Low	6110	-62.27	3.51	0	-65.78	-62
NVNT	ax80	6145	Ant1	Center	6145	-62.48	3.51	0	-65.99	-62
NVNT	ax80	6145	Ant1	High	6180	-62.31	3.51	0	-65.82	-62
NVNT	ax80	6465	Ant1	Low	6430	-62.27	3.51	0	-65.78	-62
NVNT	ax80	6465	Ant1	Center	6465	-62.25	3.51	0	-65.76	-62
NVNT	ax80	6465	Ant1	High	6500	-62.39	3.51	0	-65.9	-62
NVNT	ax80	6625	Ant1	Low	6590	-62.3	3.51	0	-65.81	-62
NVNT	ax80	6625	Ant1	Center	6625	-62.22	3.51	0	-65.73	-62
NVNT	ax80	6625	Ant1	High	6660	-62.45	3.51	0	-65.96	-62
NVNT	ax80	6945	Ant1	Low	6910	-62.14	3.51	0	-65.65	-62
NVNT	ax80	6945	Ant1	Center	6945	-62.4	3.51	0	-65.91	-62
NVNT	ax80	6945	Ant1	High	6980	-62.04	3.51	0	-65.55	-62



Test Graphs

Contention Based Protocol Calibration NVNT ax20 6135MHz Interfere 6135 MHz



Contention Based Protocol Calibration NVNT ax20 6455MHz Interfere 6455 MHz





Contention Based Protocol Calibration NVNT ax20 6535MHz Interfere 6535 MHz



Contention Based Protocol Calibration NVNT ax20 6935MHz Interfere 6935 MHz





Contention Based Protocol Calibration NVNT ax40 6125MHz Interfere 6110 MHz



Contention Based Protocol Calibration NVNT ax40 6125MHz Interfere 6140 MHz





Contention Based Protocol Calibration NVNT ax40 6445MHz Interfere 6430 MHz




Contention Based Protocol Calibration NVNT ax40 6445MHz Interfere 6460 MHz





Contention Based Protocol Calibration NVNT ax40 6605MHz Interfere 6590 MHz



Contention Based Protocol Calibration NVNT ax40 6605MHz Interfere 6620 MHz





Contention Based Protocol Calibration NVNT ax40 6925MHz Interfere 6910 MHz



Contention Based Protocol Calibration NVNT ax40 6925MHz Interfere 6940 MHz







Contention Based Protocol Calibration NVNT ax80 6145MHz Interfere 6110 MHz



Contention Based Protocol Calibration NVNT ax80 6145MHz Interfere 6145 MHz





Contention Based Protocol Calibration NVNT ax80 6145MHz Interfere 6180 MHz



Contention Based Protocol Calibration NVNT ax80 6465MHz Interfere 6430 MHz





Contention Based Protocol Calibration NVNT ax80 6465MHz Interfere 6465 MHz



Contention Based Protocol Calibration NVNT ax80 6465MHz Interfere 6500 MHz





Contention Based Protocol Calibration NVNT ax80 6625MHz Interfere 6590 MHz



Contention Based Protocol Calibration NVNT ax80 6625MHz Interfere 6625 MHz





Contention Based Protocol Calibration NVNT ax80 6625MHz Interfere 6660 MHz



Contention Based Protocol Calibration NVNT ax80 6945MHz Interfere 6910 MHz






Contention Based Protocol Calibration NVNT ax80 6945MHz Interfere 6945 MHz



Contention Based Protocol Calibration NVNT ax80 6945MHz Interfere 6980 MHz





**b. Contention Based Protocol Mechanism**

Condition	Mode	Frequency (MHz)	Antenna	AWGN Location	AWGN Frequency (MHz)	Test Time	Is Detected	Verdict
NVNT	ax20	6135	Ant1	Center	6135	1	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	2	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	3	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	4	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	5	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	6	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	7	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	8	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	9	Yes	Pass
NVNT	ax20	6135	Ant1	Center	6135	10	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	1	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	2	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	3	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	4	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	5	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	6	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	7	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	8	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	9	Yes	Pass
NVNT	ax20	6455	Ant1	Center	6455	10	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	1	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	2	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	3	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	4	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	5	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	6	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	7	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	8	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	9	Yes	Pass
NVNT	ax20	6535	Ant1	Center	6535	10	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	1	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	2	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	3	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	4	Yes	Pass



NVNT	ax20	6935	Ant1	Center	6935	5	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	6	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	7	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	8	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	9	Yes	Pass
NVNT	ax20	6935	Ant1	Center	6935	10	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	1	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	2	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	3	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	4	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	5	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	6	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	7	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	8	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	9	Yes	Pass
NVNT	ax40	6125	Ant1	Low	6110	10	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	1	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	2	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	3	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	4	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	5	No	Fail
NVNT	ax40	6125	Ant1	High	6140	6	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	7	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	8	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	9	Yes	Pass
NVNT	ax40	6125	Ant1	High	6140	10	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	1	No	Fail
NVNT	ax40	6445	Ant1	Low	6430	2	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	3	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	4	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	5	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	6	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	7	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	8	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	9	Yes	Pass
NVNT	ax40	6445	Ant1	Low	6430	10	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	1	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	2	Yes	Pass





NVNT	ax40	6445	Ant1	High	6460	3	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	4	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	5	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	6	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	7	No	Fail
NVNT	ax40	6445	Ant1	High	6460	8	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	9	Yes	Pass
NVNT	ax40	6445	Ant1	High	6460	10	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	1	No	Fail
NVNT	ax40	6605	Ant1	Low	6590	2	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	3	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	4	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	5	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	6	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	7	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	8	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	9	Yes	Pass
NVNT	ax40	6605	Ant1	Low	6590	10	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	1	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	2	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	3	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	4	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	5	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	6	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	7	No	Fail
NVNT	ax40	6605	Ant1	High	6620	8	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	9	Yes	Pass
NVNT	ax40	6605	Ant1	High	6620	10	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	1	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	2	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	3	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	4	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	5	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	6	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	7	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	8	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	9	Yes	Pass
NVNT	ax40	6925	Ant1	Low	6910	10	No	Fail



NVNT	ax40	6925	Ant1	High	6940	1	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	2	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	3	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	4	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	5	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	6	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	7	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	8	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	9	Yes	Pass
NVNT	ax40	6925	Ant1	High	6940	10	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	1	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	2	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	3	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	4	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	5	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	6	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	7	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	8	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	9	Yes	Pass
NVNT	ax80	6145	Ant1	Low	6110	10	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	1	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	2	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	3	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	4	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	5	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	6	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	7	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	8	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	9	Yes	Pass
NVNT	ax80	6145	Ant1	Center	6145	10	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	1	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	2	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	3	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	4	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	5	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	6	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	7	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	8	Yes	Pass



NVNT	ax80	6145	Ant1	High	6180	9	Yes	Pass
NVNT	ax80	6145	Ant1	High	6180	10	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	1	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	2	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	3	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	4	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	5	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	6	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	7	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	8	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	9	Yes	Pass
NVNT	ax80	6465	Ant1	Low	6430	10	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	1	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	2	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	3	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	4	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	5	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	6	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	7	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	8	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	9	Yes	Pass
NVNT	ax80	6465	Ant1	Center	6465	10	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	1	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	2	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	3	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	4	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	5	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	6	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	7	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	8	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	9	Yes	Pass
NVNT	ax80	6465	Ant1	High	6500	10	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	1	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	2	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	3	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	4	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	5	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	6	Yes	Pass



NVNT	ax80	6625	Ant1	Low	6590	7	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	8	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	9	Yes	Pass
NVNT	ax80	6625	Ant1	Low	6590	10	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	1	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	2	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	3	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	4	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	5	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	6	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	7	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	8	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	9	Yes	Pass
NVNT	ax80	6625	Ant1	Center	6625	10	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	1	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	2	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	3	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	4	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	5	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	6	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	7	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	8	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	9	Yes	Pass
NVNT	ax80	6625	Ant1	High	6660	10	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	1	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	2	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	3	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	4	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	5	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	6	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	7	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	8	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	9	Yes	Pass
NVNT	ax80	6945	Ant1	Low	6910	10	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	1	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	2	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	3	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	4	Yes	Pass



NVNT	ax80	6945	Ant1	Center	6945	5	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	6	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	7	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	8	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	9	Yes	Pass
NVNT	ax80	6945	Ant1	Center	6945	10	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	1	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	2	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	3	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	4	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	5	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	6	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	7	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	8	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	9	Yes	Pass
NVNT	ax80	6945	Ant1	High	6980	10	Yes	Pass




Test Graphs

Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_1




Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_2






Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_3



Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_4






Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_5




Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_6








Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_7




Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_8






Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_9




Contention Based Protocol NVNT ax20 6135MHz Interfere 6135 MHz\_10






Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_1




Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_2






Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_3




Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_4






Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_5



Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_6






Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_7




Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_8






Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_9




Contention Based Protocol NVNT ax20 6455MHz Interfere 6455 MHz\_10






Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_1




Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_2








Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_3




Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_4






Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_5



Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_6






Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_7



Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_8






Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_9




Contention Based Protocol NVNT ax20 6535MHz Interfere 6535 MHz\_10








Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_3



Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_4






Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_5



Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_6





Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_7




Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_8








Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_9




Contention Based Protocol NVNT ax20 6935MHz Interfere 6935 MHz\_10






Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_1



Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_2






Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_3




Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_4



Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_5




Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_6







Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_7




Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_8



Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_9




Contention Based Protocol NVNT ax40 6125MHz Interfere 6110 MHz\_10








Contention Based Protocol NVNT ax40 6125MHz Interfere 6140 MHz\_3



Contention Based Protocol NVNT ax40 6125MHz Interfere 6140 MHz\_4











Contention Based Protocol NVNT ax40 6125MHz Interfere 6140 MHz\_7



Contention Based Protocol NVNT ax40 6125MHz Interfere 6140 MHz\_8






Contention Based Protocol NVNT ax40 6125MHz Interfere 6140 MHz\_9




Contention Based Protocol NVNT ax40 6125MHz Interfere 6140 MHz\_10






Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_1




Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_2




Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_3



Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_4



Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_5




Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_6






Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_7



Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_8





Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_9



Contention Based Protocol NVNT ax40 6445MHz Interfere 6430 MHz\_10

