




Band Edge NVNT ac40 5230MHz High Ant1




Band Edge NVNT ac40 5270MHz Low Ant1




Band Edge NVNT ac40 5310MHz High Ant1




Band Edge NVNT ac40 5510MHz Low Ant1




Band Edge NVNT ac40 5670MHz High Ant1




Band Edge NVNT ac40 5755MHz Low Ant1




Band Edge NVNT ac40 5795MHz High Ant1




Band Edge NVNT ac80 5210MHz Low Ant1




Band Edge NVNT ac80 5290MHz High Ant1




Band Edge NVNT ac80 5530MHz Low Ant1




Band Edge NVNT ac80 5610MHz High Ant1




Band Edge NVNT ac80 5775MHz High Ant1




Band Edge NVNT n20 5180MHz Low Ant1




Band Edge NVNT n20 5240MHz High Ant1




Band Edge NVNT n20 5260MHz Low Ant1




Band Edge NVNT n20 5320MHz High Ant1




Band Edge NVNT n20 5500MHz Low Ant1




Band Edge NVNT n20 5700MHz High Ant1




Band Edge NVNT n20 5745MHz Low Ant1




Band Edge NVNT n20 5825MHz High Ant1




Band Edge NVNT n40 5190MHz Low Ant1




Band Edge NVNT n40 5230MHz High Ant1




Band Edge NVNT n40 5270MHz Low Ant1




Band Edge NVNT n40 5310MHz High Ant1




Band Edge NVNT n40 5510MHz Low Ant1




Band Edge NVNT n40 5670MHz High Ant1



Band Edge NVNT n40 5755MHz Low Ant1



Band Edge NVNT n40 5795MHz High Ant1




22.6 FREQUENCY STABILITY


Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5180	Ant1	5180	0	0	25	Pass
NVNT	a	5200	Ant1	5200	0	0	25	Pass
NVNT	a	5240	Ant1	5240	0	0	25	Pass
NVNT	a	5260	Ant1	5260.02	20000	3.8	25	Pass
NVNT	a	5280	Ant1	5280	0	0	25	Pass
NVNT	a	5320	Ant1	5320	0	0	25	Pass
NVNT	a	5500	Ant1	5500	0	0	25	Pass
NVNT	a	5600	Ant1	5600	0	0	25	Pass
NVNT	a	5700	Ant1	5700	0	0	25	Pass
NVNT	a	5745	Ant1	5745	0	0	25	Pass
NVNT	a	5785	Ant1	5785	0	0	25	Pass
NVNT	a	5825	Ant1	5825	0	0	25	Pass
NVNT	ac20	5180	Ant1	5180	0	0	25	Pass
NVNT	ac20	5200	Ant1	5200	0	0	25	Pass
NVNT	ac20	5240	Ant1	5240	0	0	25	Pass
NVNT	ac20	5260	Ant1	5260.04	40000	7.6	25	Pass
NVNT	ac20	5280	Ant1	5280.04	40000	7.58	25	Pass
NVNT	ac20	5320	Ant1	5320.02	20000	3.76	25	Pass
NVNT	ac20	5500	Ant1	5500.04	40000	7.27	25	Pass
NVNT	ac20	5600	Ant1	5600.04	40000	7.14	25	Pass
NVNT	ac20	5700	Ant1	5700.04	40000	7.02	25	Pass
NVNT	ac20	5745	Ant1	5745.04	40000	6.96	25	Pass
NVNT	ac20	5785	Ant1	5785.06	60000	10.37	25	Pass
NVNT	ac20	5825	Ant1	5825.04	40000	6.87	25	Pass
NVNT	ac40	5190	Ant1	5190	0	0	25	Pass
NVNT	ac40	5230	Ant1	5230.08	80000	15.3	25	Pass
NVNT	ac40	5270	Ant1	5270.04	40000	7.59	25	Pass
NVNT	ac40	5310	Ant1	5310.04	40000	7.53	25	Pass
NVNT	ac40	5510	Ant1	5510.04	40000	7.26	25	Pass
NVNT	ac40	5590	Ant1	5590	0	0	25	Pass
NVNT	ac40	5670	Ant1	5670.04	40000	7.05	25	Pass
NVNT	ac40	5755	Ant1	5755.04	40000	6.95	25	Pass
NVNT	ac40	5795	Ant1	5795.08	80000	13.81	25	Pass
NVNT	ac80	5210	Ant1	5210	0	0	25	Pass
NVNT	ac80	5290	Ant1	5290	0	0	25	Pass
NVNT	ac80	5530	Ant1	5530	0	0	25	Pass
NVNT	ac80	5610	Ant1	5610	0	0	25	Pass
NVNT	ac80	5775	Ant1	5775	0	0	25	Pass
NVNT	n20	5180	Ant1	5180.02	20000	3.86	25	Pass
NVNT	n20	5200	Ant1	5200	0	0	25	Pass
NVNT	n20	5240	Ant1	5240	0	0	25	Pass

NVNT	n20	5260	Ant1	5260	0	0	25	Pass
NVNT	n20	5280	Ant1	5280	0	0	25	Pass
NVNT	n20	5320	Ant1	5320.02	20000	3.76	25	Pass
NVNT	n20	5500	Ant1	5500	0	0	25	Pass
NVNT	n20	5600	Ant1	5600	0	0	25	Pass
NVNT	n20	5700	Ant1	5700	0	0	25	Pass
NVNT	n20	5745	Ant1	5745	0	0	25	Pass
NVNT	n20	5785	Ant1	5785	0	0	25	Pass
NVNT	n20	5825	Ant1	5825	0	0	25	Pass
NVNT	n40	5190	Ant1	5190.08	80000	15.41	25	Pass
NVNT	n40	5230	Ant1	5230.08	80000	15.3	25	Pass
NVNT	n40	5270	Ant1	5270.04	40000	7.59	25	Pass
NVNT	n40	5310	Ant1	5310	0	0	25	Pass
NVNT	n40	5510	Ant1	5510.04	40000	7.26	25	Pass
NVNT	n40	5590	Ant1	5590.04	40000	7.16	25	Pass
NVNT	n40	5670	Ant1	5670	0	0	25	Pass
NVNT	n40	5755	Ant1	5755.08	80000	13.9	25	Pass
NVNT	n40	5795	Ant1	5795.04	40000	6.9	25	Pass


Freq. Stability NVNT a 5180MHz Ant1




Freq. Stability NVNT a 5200MHz Ant1




Freq. Stability NVNT a 5240MHz Ant1




Freq. Stability NVNT a 5260MHz Ant1




Freq. Stability NVNT a 5280MHz Ant1



Freq. Stability NVNT a 5320MHz Ant1



Freq. Stability NVNT a 5500MHz Ant1



Freq. Stability NVNT a 5600MHz Ant1