
TRANSFORMERS



TF-T01 Pro 真无线蓝牙耳机 - 使用说明书 -



充电仓



⑤耳机充电触点 / ⑥耳机出音口 / ⑦复位键

- 4. 为避免触电,请在安装或卸载产品时,确保手上没有沾水。 5. 请勿将此产品放置于热源附近或直接暴露在火源附近。

蓝牙版本: 5.4 传输距离: ≥ 10M 喇叭直径: φ10mm

频率范围: 20-20kHz 充电时间: 约 1.5 小时 音乐时间:约5小时

电池容量: 300mAh/3.7V 充电时间:约1.5小时

. 除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品内的任何零件。 2. 请勿将产品放入水或其他任何液体中,此产品非防水设计

3. 如果有任何液体不小心进入产品内时,请立即断开连接并移开此产品

6. 请勿将本产品放置在有强大电磁力的环境中,否则会导致产品故障。

喇叭阻抗: 32Ω 灵敏度: 108±3dB @1kHz

电池容量: 30mAh/3.7V

额定輸入: 5V === 30mA

额定输入: 5V === 300mA

(所有技术信息以实际性能为准)

恢复出厂设置 1. 耳机在充电仓内,连续按5下复位键清除所有连接记录。 2. 耳机在充电仓内,长按复位键8秒,清除与手机连接记录。

额定输入: 5V === 30mA (耳机)

额定输入: 5V===300mA (充电仓)

给充电仓充电 用 Type-C 充电线连接充电仓到 5V 电源话配器 温馨提示: 耳机电池电量低于 3.3V 开始播报低电提醒 (每 1 分钟提醒 一次), 耳机蓝灯快闪

LED 指示灯与提示音

	指示灯	提示音
	蓝灯快闪	Power on
	蓝灯亮一秒熄灭	Power off
组对	配对成功,主耳蓝灯闪,副耳蓝灯灭	Pairing
成功	主副耳灯灭	Connected
	蓝灯快闪	/
量提示	蓝灯每 5S 闪烁 1 次	Low battery
,	充电中: 蓝灯常亮; 充满电: 蓝灯熄灭	/

充电仓状态

充电仓充电状态

仓给耳机充满电状 充电仓低电状态

指示灯 红灯闪烁 红灯熄灭 入仓检测灯常亮10秒后熄灭	
红灯熄灭 入仓检测灯常亮10秒后熄灭	
入仓检测灯常亮10秒后熄灭	
- #Jorden	
蓝灯熄灭	5.
红灯闪烁5次后熄灭	

方法—: 充电仓取出耳机自动开机 方法二:长按左/右耳机功能键3秒开机。

方法—: 耳机放入充电仓内自动关机

产品操作说明

方法二: 耳机在 3 分钟后没有连接设备则自动关机。

步骤--: 左右耳机配对:从充电仓取出耳机,并自动进行左右配对。 步骤 : 左右耳机自动配对成功后则讲入配对模式 . 耳机等待与设备的连接。

步骤三: 打开设备的蓝牙功能, 选择 "TF-T01 Pro" 进行连接, 3 分钟内未连接设备则自

连接设备成功提示音: "Connected"



常规模式



音乐播放模式



通话模式



■ 游戏/音乐/ANC降噪/通透/普通模式



长按右耳机 MFB 键 2 秒切掉游戏/音乐模式

· 长按左耳机 MFB 键 2 秒切换普诵模式/ANC模式/诵诱模:

产品中有害物质名称及含量

	l		17.0	DOUGH		
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	0	0	0	0	0	0
外売等小 结构件	0	0	0	0	0	0

有宝物质

木表格依据 SI/T11364 的韧宁编制

· 表示有事物所在该部件所有均质材料中的含量均在 GB/T26572 规定限量要求以 X:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB26572 规定的限量要求 表单标记 "X" 的部件,皆因全球技术发展水平限制而无法实现有害物质的替代

印刷电路板组件 *: 包括印刷电路板及其零部件,电子元器件等 根据产品型号不同,您所购买的产品可能不会含有以上所有部件。

FC RoHS C C CO A UK CO

皆不含有6种有毒有害物质或含有但小干限量值、字母 "e" 代表革文字母电 -(electronic); 电子(electrical和环境(environment)的首字母; 环绕的曲线箭

以上保证是我们就产品做出的全部保证,且仅在中国大陆地区境内适用。

本使用手册没有任何形式的担保 立场表达或其他暗示 本使用手册所提到的产品 规格

及信息仅供参考、内容亦会随时更新干网页、恕不另行通知。

保修声明

就本文件附随的产品做如下保证·如产品在您购买日起十一(12)个目"(保修期")内 在正 常使用情况下因质量瑕疵发生损坏,能修理的,免费修理,经厂家确认无法修理的,免费更换。 修理或更换后的产品。在剩余保修期(最短不少于30天)内继续享有保修 购买日以销售发票日期为准、如无法确定购买日、则保修期自产品生产日期起按十三(

如申请保修 请先致电产品服务热线 并按我们指示的方式执行。申请保修时,您需要提 供准确、完整和清晰填写的有效销售发票。以上保证不适用于下列情况

1 超过三包有效期的

- 2 涂改保修卡,产品编码与产品本体不符
- 3. 因误用,滥用或不适当的运输,使用,维护或保管而导致的故障或损坏 4. 因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏:
- 5 拉链 塔扣因受力过大而损坏
- 6 因承载过重造成的脱线或撕裂
- 7 仟何因尖锐物体造成的损坏
- 8. 有烧损或水浸迹象的产品:
- 9 因擅自拆改导致的损坏:
- 10 产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗
- 11. 如产品原有标识标签被更改或损毁。本保证将失效。

产品及随附物料的齐备和外观完好不属于保证范围,您应在接收产品时当场检验并对任何

本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利

服务监督热线:400-885-8808

产品条码/编号/批 TRANSFORMERS

田户姓名

联系电话

通讯地址

联系电话 销售日期

产品编号: 生产日期: 检验员:

邮政编码

电子邮件

产品型号

Dear user this warranty card is a proof of your future warranty application. Please cooperate with the seller to fill it out and keep it properly for future use!

Warranty card

Product barcode/ number/batch

Seller Information	
User Name	
Address	
Telephone	Postal Code
Sale date	Invoice number
Remarks	•

Certificate of Approval Product No: Production Time: OC: _____

TRANSFORMERS

Charging









S size ear cap M size ear cap * L size ear cap

Product diagram



TF-T01 Pro True Wireless BT Earphones ① Charging compartment indicator / ② Type-C charging port / ③ MFB key Instruction manual (4) Headphone indicator/(5) Headphone charging contact/(6) Headphone out port


Packing list

TALESTOOMS









Rated input: 5V === 30mA (Earphone)

1. Do not attempt to disassemble or replace any parts inside the product, except

3. If any liquid accidentally enters the product, please immediately disconnect as

5. Please do not place this product near a heat source or directly expose it to a fire

6. Do not place this product in an environment with strong electromagnetic force,

Frequency range: 20-20kHz

Music time: about 5 hours

Rated input: 5V === 30mA

Battery capacity: 30mAh/3.7V

Charging time: about 1.5 hours

2. Do not put the product into water or any other liquid, as this product is not

4. To avoid electric shock, please ensure that your hands are not wet when

for the operation methods specified in the manual.

designed to be waterproof

Product specifications

Bluetooth version: 5.4

Transmission distance: ≥10

Speaker diameter: ω10mm

Speaker impedance: 32Ω

Sensitivity: 108±3dB @1kHz

Battery capacity: 300mAh/3 7V

Rated input: 5V === 300mA

Charging time: About 1.5 hours

installing or uninstalling the product.

otherwise it may cause product malfunction.

Charging compartment specifications

(All technical information is subject to actual performance)

remove the product.

Rated input: 5V === 300mA (Charging compartment

Type-C charging cable. Reminder: When the battery level of the earphones is below 3.3V, a low battery

Charge the charging compartment and connect it to a 5V power adapter using a

1. When the headset is in the charging bay, press the reset button five times to reminder will be played (once every minute), and the earphone blue light will flash

LED indicator lights and warning sounds

Blue light quick flashing	Power on
The blue light goes off in one second	Power off
Successful pairing, blue light in primary ear flashes, blue light in secondary ear goes out	Pairing
Primary and secondary auricular lights out.	Connected
Blue light quick flashing	/
The blue light flashes once every 5 seconds	Low battery
Charging: The blue light is constantly on; Fully charged: Blue light out	/
	The blue light goes off in one second Successful pairing, blue light in primary ear flashes, blue light in secondary ear goes out Primary and secondary auricular lights out. Blue light quick flashing The blue light flashes once every 5 seconds Charging: The blue light is constantly on; Fully

Charging bin status

State of affairs Indicator light

State of affairs

State of affairs	Indicato	r light	
Charging status of the charging box	Red light	t flashing	sh
charging case is fully charged	Red light	t out	
charging case charges the headset		ehouse detection light will be on for ods and then off	
charging case gives the headset a fu ll y cha	arged state	Blue light out	
charging box is in low power state	Red light	t blinks five times and then turns off	

Factory data reset

- clear all connection records 2. Long press the reset button in the charging compartment for 8 seconds to clear
 - the connection record with the mobile phone.

Product operating instructions

Method 1: Remove the headset from the charging compartment to switch on automatically. Method 2: Long press the left/right headphone function button for 3 seconds to switch on the phone

2.Power off

Method 1: Put the earphones into the charging compartment and automatically Method 2: If the headphones are not connected to the device after 3 minutes, they

will automatically shut down.

Step 1: Pair left and right earphones: Remove the earphones from the charging compartment and automatically pair them left and right. Step 2: After the left and right earphones are automatically paired successfully,

they enter pairing mode and wait for the earphones to connect to the device. Step 3: Turn on the Bluetooth function of the device, select "TF-T01 Pro" to nnect, and if the device is not connected within 3 minutes, it will automatically



uccessfully connected device prompt sound: "Connected"



Conventional mode

Music Mode

Talk mode

Volume +: Click the right earphone MFB key (Beep : dong

dogn)Volume -: Click the left earphone MFB key (Beep :

— Plav/Pause: Double-click left/right headphone MFB button

Previous song: Triple-click left headphone MFB key

Next Song: Triple-click right headphone MFB key

End call: Double tap the left/right headset MFB key

Game/Music /ANC noise reduction/transparent/normal mode

to switch to game/music mode

(Boot default is normal mode)

Answer an incoming call: double-click the left/right

Reject call: Long press the left/right headset MFB key for 2

Long press the MFB button on the right headset for 2 seconds

- Long press the MFB button on the left headset for 2 seconds

switch between Normal mode /ANC mode/Transparent mo

Name and content of harmful substances in the product

Part Name	Harmful substance					
	Pb	Hg	Cd	Cr (VI)	PBB	PBDE
Printed circuit assembly	0	0	0	0	0	0
Small structural parts such as housings	0	0	0	0	0	0

This table is prepared according to the provisions of SJ/T11364 Indicates that the content of the hazardous substance in all homogeneous

materials of the component is below the limit requirements specified in GB/

Printed Circuit Board Components*: Includes printed circuit boards and their

The curved arrows around it indicate recyclability.

Depending on the product model, the product you purchase may not contain a

Does not contain 6 kinds of toxic and harmful substances or

ontains but is less than the limit value, the letter "e" stands for the

English letter electronic: The initials of electrical and environmen

- X: Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements
- Parts marked with "X" in the table cannot be substituted for hazardous
- substances due to the limitations of global technological development. This form is prepared in accordance with the provisions of SI/T11364
 - 7. Any damage caused by sharp objects 8. Products that show signs of burns or flooding.

Warranty Statement

are subject to change without notice.

Email: service@ascxsm.com



parts, electronic components, and so on:

of the above components

TRANSFORMERS

1 Exceeding the validity period of the three packages: 2. Altered warranty card, product code does not match the product body

during the remaining warranty period (at least 30 days).

- 3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or
- 4. Failure or damage caused by force majeure (e.g. earthquake, war, fire, etc.) or accidents

No warranty, representation of position or other implication of any kind is made in this manual.

The products, specifications and information mentioned in this manual are for reference only and

The products attached hereto are warranted as follows: If the product is damaged due to defects

in quality under normal use within twelve (12) months from the date of purchase, the product will

be repaired free of charge if it can be repaired, or replaced free of charge if it cannot be repaired

as confirmed by the manufacturer, and the product will continue to be covered by the warranty

for the remainder of the warranty period (a minimum of not less than 30 days) after the product is repaired or replaced. After repair or replacement, the product will continue to enjoy the warranty

The date of purchase is based on the date of the sales invoice. If the date of purchase cannot be

determined, the warranty period will be calculated on the basis of thirteen (13) months from the

For warranty claims, please call the product service hotline first and follow our instructions. To

claim the warranty, you will need to provide a valid sales invoice that is accurate, complete and

5. Damage to zippers, towers, or buckles due to excessive force.

legibly filled out. The above warranty does not apply to the following.

- 6. Unraveling or tearing due to overloading

- P. Damage caused by unauthorized modification
- 10. Aging, discoloration, wear and tear, cracks and other wear and tear that occurs during normal
- 11. This warranty will be void if the original labeling of the product is altered or destroyed.
- The product and the accompanying materials are complete and intact appearance is not the scope of the warranty, you should receive the product on-site inspection and any discrepancies to raise objections

The above warranty is our entire warranty in respect of the product and applies only within

Nothing in this document affects the rights of consumers which cannot be excluded or restricted

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.