


TF-T28 说明书

尺寸: 73x93mm

材质: 128g铜版纸覆哑膜 风琴折正反印刷

TRANSFORMERS



TF-T28
真无线蓝牙耳机
- 使用说明书 -

包装清单

	充电仓 x1		耳机 x2
	说明书 & 合格证 x1		Type-C 充电线 x1

温馨提示

- 除说明书有特殊标示的操作方式以外, 请勿尝试拆卸或更换产品内的任何零件。
- 请勿将产品放入水或其他任何液体中, 本产品非防水设计。
- 如果有任何液体不小心进入产品内部, 请立即停止使用并移开本产品。
- 为避免触电, 请在安装拆卸或取产品时, 确保手上没有水。
- 请勿将本产品放置于热源附近或直接将暴露在光源附近。
- 请勿将本产品放置于有强大电磁力干扰环境中, 否则会导致产品故障。

产品规格

蓝牙版本: 5.4
接收距离: ≥ 10M
喇叭直径: φ13mm
喇叭阻抗: 32Ω±15%
音乐时间: 约 5 小时
耳机电池容量: 30mAh/3.7V
控制方式: 触摸操作
麦克风: -38dB±1
喇叭功率: 5mW

充电仓规格

电池容量: 200mAh/3.7V
充电时间: ≤ 1.5 小时
额定输入: 5V === 200mA
(所有技术信息均以实际性能为准)

LED 指示灯与提示音

状态	指示灯	提示音
开机	指示灯亮 15 秒	Power on
关机	灯灭	Power off
TWS 配对状态	主耳红灯交替闪烁, 副耳灯灭	Pairing
连接成功	灯灭	Connected
连接失败	主耳红灯交替闪烁, 副耳灯亮	Disconnected pairing
充电仓输出	白灯长亮, 耳机电亮	/
充电仓充电	充电耳机红灯闪烁, 充电仓长亮	/
充电仓充电	充电仓指示灯闪烁	/

产品操作说明

- 开机
方法一: 打开耳机自动开机;
方法二: 长按耳机功能键 3 秒, 开机。
- 关机
方法一: 耳机放入充电仓内自动关机;
方法二: 耳机在 3 分钟内没有连接设备则自动关机。
- 配对
步骤一: 左右耳机配对, 从充电仓取出耳机, 并自动进行左右配对;
步骤二: 左右耳机自动配对成功后进入配对模式, 耳机会与设备的连接;
步骤三: 打开设备的蓝牙功能, 选择 "TF-T28" 进行连接, 3 分钟内未连接设备则自动关机。

触摸操作

- 常规模式
 - 语音助手: 长按左耳机功能键 2 秒启动语音助手
 - 音量加: 单击右耳机功能键 (最大提示音 "吨吨")
 - 音量减: 单击左耳机功能键
- 音乐播放模式
 - 播放/暂停: 双击左/右耳机功能键
 - 上一曲: 三击左耳机功能键
 - 下一曲: 三击右耳机功能键
- 通话模式
 - 接听来电: 双击左/右耳机功能键
 - 结束通话: 双击左/右耳机功能键
 - 拒接来电: 长按左/右耳机功能键 2 秒
- 游戏/音乐模式
 - 游戏模式: 长按左耳机功能键 2 秒 (语音提示: "Game mode")
 - 音乐模式: 长按右耳机功能键 2 秒 (语音提示: "Music mode")

产品中有有害物质名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	○	○	○	○	○	○
外壳小结构件	○	○	○	○	○	○

本表格依据 SJ/T11364 的规定编制。
注: 有害物质指在组件和材料中的含量或在 GB/T26572 规定的限量要求以下。
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T26572 规定的限量要求。
表中标记 "X" 的部件, 皆因全球技术法规限制而无法实现有害物质的替代。

本表格依据 SJ/T11364 的规定编制。
印刷电路组件: 包括印刷电路及其零部件, 电子元器件等;
根据产品型号不同, 您购买的设备可能不包含以上所有部件。

在中华人民共和国境内销售的电子电气产品必须标注此标志, 标志中的数字代表在正常使用状态下的产品的环保使用期限。

保修声明

免责声明
本使用手册没有任何形式的担保、立场表达或其他指示, 本使用手册所提到的产品, 规格及信息仅供参考, 内容亦会随时更新于网页, 恕不另行通知。

保修声明
本文件所提到的产品做出如下保证, 如产品在您购买之日起十二 (12) 个月 ("保修期") 内, 在正常使用条件下出现质量问题, 我们将提供免费维修、免费更换、免费退货, 或者更换、修理或更换后的产品, 在剩余保修期 (最短不少于 30 天) 内继续享有保修。
购买后以销售发票日期为准, 如无销售发票日期, 则保修期自产品生产日期起按十三 (13) 个月计算。
如申请保修, 请先致电产品服务热线, 并按我们指示的方式执行。申请保修时, 您需提供保修卡、完整和清晰填写的有效销售发票, 以上保证不适用于下列情况:
1. 超过三包有效期的;
2. 人为损坏、产品编码与产品主体不符;
3. 因该用、滥用或不适当的运输、使用、维护或保管导致的故障或损坏;
4. 因不可抗力 (如地震、战争、火灾等) 或意外导致的故障或损坏;
5. 运输、装卸或搬运过程中造成的损坏;
6. 因非正常使用造成的故障或损坏;
7. 任何因不可抗力造成的损坏;
8. 有因不可抗力造成的损坏;
9. 因擅自修改导致的损坏;
10. 产品在正常使用过程中发生的老化、褪色、磨损、破裂和其他损坏;
11. 如产品商标标识被更改或损毁, 本保证将无效。

产品及随附物料的外观完好不属于保修范围, 您应在接收产品时当场检查并开任何不符提出抗议。

以上保证是我们对产品做出的全部保证, 且仅在中国大陆地区境内适用, 本文件的任何内容均不影响根据法律规定的保修或限制性的销售者权利。

服务监督热线: 400-885-8808

合格证

产品型号: _____
生产日期: _____
检验员: _____

保修卡

尊敬的用户, 本保修卡是您将来申请保修的凭证, 请您配合销售商填写并妥善保管备用!

用户信息	
用户姓名	电子邮件
联系电话	邮政编码
通讯地址	

产品信息	
产品名称	产品型号
产品条码 / 编号 / 批号	

销售商信息	
用户姓名	
地址	
联系电话	邮政编码
销售日期	发票号码
备注	

做成易撕页

TRANSFORMERS

Warranty card

Dear user, this warranty card is a proof of your future warranty application. Please cooperate with the seller to fill it out and keep it properly for future use!


User information	
User Name	E-mail
Telephone	Postal Code
Address	
mail address	

Products	
product name	Model
Product barcode/number/batch number	

Seller information	
User Name	
Address	
Telephone	Postal Code
Sale date	Invoice number
Remarks	

Certificate of Approval
Product No: _____
Production Time: _____
QC: _____

TRANSFORMERS




TF-T28
True wireless BT Earphones
-User manual-

Packing list

	Charging compartment x1		Earphone x2
	Instruction manual & certificate of conformity x1		Type-C Charging cable x1

Product diagram



Type-C charging port
MFB function keys

Tips

- Do not attempt to disassemble or replace any parts inside the product, except for the operation methods specified in the manual.
- Do not put the product into water or any other liquid, as this product is not designed to be waterproof.
- If any liquid accidentally enters the product, please immediately disconnect and remove the product.
- To avoid electric shock, please ensure that your hands are not wet when installing or uninstalling the product.
- Please do not place this product near a heat source or directly expose it to a fire source.
- Do not place this product in an environment with strong electromagnetic force, otherwise it may cause product malfunction.

Product specifications

Bluetooth version: 5.4
Receiving distance: ≥ 10M
Speaker diameter: φ13mm
Speaker impedance: 32Ω±15%
Music time: about 5 hours
Headphone battery capacity: 30mAh/3.7V
Control method: touch operation
Microphone: -38dB±1
Speaker power: 5mW

Charging compartment specifications

Battery capacity: 200mAh/3.7V
Charging time: ≤ 1.5 H
Rated input: 5V === 200mA
(All technical information is subject to actual performance)

Product operation instructions

- Power on
Method 1: Open the lid and the earphones will automatically turn on;
Method 2: Press and hold the MFB button on the earphones for 3 seconds to turn on the device.
- Power off
Method 1: Put the earphones into the charging compartment and automatically shut them off.
Method 2: If the earphones are not connected to the device within 3 minutes, they will automatically shut down.
- Pairing
Step 1: Pair left and right earphones: Remove the earphones from the charging compartment and automatically pair them left and right.
Step 2: After the left and right earphones are automatically paired successfully, they enter pairing mode and wait for the earphones to connect to the device.
Step 3: Turn on the Bluetooth function of the device, select "TF-T28" to connect, and if the device is not connected within 3 minutes, it will automatically shut down.

LED Indicator lights and warning sounds

State	Pilot lamp	Sound
Power on	Blue light on for 15 s	Power on
Power off	The red light stays on for 1 second and goes off	Power off
TWS pairing status	The red and blue lights in the main ear flicker alternately, while the auxiliary ear lights turn off	Pairing
Connection successful	light off	Connected
Connection disconnected	The red and blue lights in the main ear flicker alternately, while the auxiliary ear lights turn off	Disconnected pairing
Charging compartment output	The white light stays on, and the headphones are fully charged and turned off	/
Charging compartment low power	Charging headset red light blinks, fully charged long on	/
Charging compartment low power	Charging compartment low battery white light flashing	/

Touch operation

- Normal Mode
 - Voice Assistant: Long press the function button on the left ear for 2 seconds to activate the voice assistant
 - Volume increase: click the right earphone function key (maximum prompt sound "long long")
 - Volume reduction: Click the left earphone function button
- Music playback mode
 - Play/Pause: Double click the left/right headphone function keys
 - Previous song: Three clicks on the left earphone function button
 - Next track: Three clicks on the right earphone function button
- Call mode
 - Answer incoming call: Double click the left/right headphone function button
 - End call: Double click the left/right headphone function key
 - Reject incoming call: Long press the left/right headphone function button for 2 seconds
- Game/Music Mode Switching
 - Game mode: Long press the right earphone function button for 2 seconds (Voice prompt: "Game mode")
 - Music mode: Long press the right ear function button for 2 seconds (Voice prompt: "Music mode")

Restore factory settings

- After the headset is turned on and not connected to the device, click any headset function button 5 times in succession to restore the factory settings and shut down.
- When the headset is connected to the device, click any headset function button 5 times continuously, press and hold any headset function button for 10 seconds within 3 seconds, restore the factory settings and turn off the phone.

Name and content of harmful substances in the product

Part Name	Harmful substance					
	Pb	Hg	Cd	Cr (VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as housings	○	○	○	○	○	○

This table is prepared according to the provisions of SJ/T11364.
注: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit requirements specified in GB/T26572.
X: Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements specified in GB/T26572.
Printed Circuit Board Components: Includes printed circuit boards and their parts, electronic components, and so on.
Depending on the product model, the product you purchase may not contain all the above components.

Electrical and electronic products sold in the People's Republic of China must be marked with this symbol, and the number inside the symbol represents the environmental protection use period of the product under normal use.

Warranty Statement

DISCLAIMER
No warranty, representation of position or other implication of any kind is made in this manual. The products, specifications and information mentioned in this manual are for reference only and are subject to change without notice.

Warranty Statement
The products attached hereto are warranted as follows: If the product is damaged due to defects in quality under normal use within twelve (12) months from the date of purchase, the product will be repaired free of charge if it can be repaired, or replaced free of charge if it cannot be repaired as confirmed by the manufacturer, and the product will continue to be covered by the warranty for the remainder of the warranty period (a minimum of not less than 30 days) after the product is repaired or replaced. After repair or replacement, the product will continue to enjoy the warranty during the remaining warranty period (at least 30 days).
The date of purchase is based on the date of the sales invoice. If the date of purchase cannot be determined, the warranty period will be calculated on the basis of thirteen (13) months from the date of manufacture of the product.
For warranty claims, please call the product service hotline first and follow our instructions. To claim the warranty, you will need to provide a valid sales invoice that is accurate, complete and legibly filled out. The above warranty does not apply to the following:
1. Exceeding the validity period of the three packages;
2. Altered warranty card; product code does not match the product body
3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage
4. Failure or damage caused by force majeure (e.g. earthquake, war, fire, etc.) or accidents
5. Damage to zippers, covers, or buckles due to excessive force
6. Unraveling or tearing due to overloading
7. Any damage caused by sharp objects
8. Products that show signs of burns or flooding
9. Damage caused by unauthorized modification
10. Aging, discoloration, wear and tear, cracks and other wear and tear that occurs during normal use of the product
11. This warranty will be void if the original labeling of the product is altered or destroyed.
The product and the accompanying materials are complete and intact appearance is not the scope of the warranty, you should receive the product on-site inspection and any discrepancies to raise objections.
The above warranty is our entire warranty in respect of the product and applies only within mainland China.
Nothing in this document affects the rights of consumers which cannot be excluded or restricted under the law.
Service Supervisor Hotline: 400-885-8808

TRANSFORMERS

做成易撕页

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.