
TF-Y12说明书

成品尺寸: 511*93mm, 单页尺寸73*93mm





Instruction manual

- 1. Except for the operation methods specifically marked in the manual, do not try to disassemble or replace any parts in the product.

 2. Do not put the product in the water or any others liquid, the product is not
- 3. If any liquid accidentally enters the product, please disconnect and remove the
- To avoid electric shock, please make sure that there is no water on your hands when
- installing or uninstalling the product.
- otherwise it will cause product malfunction.

--- Double dick: TWS pairing

--- Long press for 3 seconds: Next song --- Short press: Volume up Long press for 3 seconds:
 Previous song
 Short press: Volume down When the speaker is not in use, $long\ press\ the$ " $\textcircled{\scriptsize 0}$ " key to power off to prevent

Low power alarm and automatic shutdown function: When the battery power is less than 10%, the speaker will sound a prompt tone, and the speaker should be charged in time. When the battery power is less than 3%, the speaker will automatically shutdown.

- Indicator light status
 Charging indicator light: The red light stays on when charging, and the red light goes out when fully charged.

Common problems and solutions Unable to power on Check whether the built-in battery of the speaker is charge The music plays whether the connection distance is out of range or whether there is an obstacle between the speaker and the phone the speaker and the phone that there is an obstacle between the speaker and the phone that the phone

: Indicates that the content of the hazardous substance in all homogeneous

- materials of the part is below the limit requirements specified in GB/T 26572. materials of the part is below the limit requirements specified in USP1 265/2.

 **Indicates that the content of the hazardous substance in at least one homogeneou material of the part exceeds the limit requirements specified in GB/T 26572.

 Note: 1. The parts marked with "×" on the table are unable to achieve the replacemer of harmful substances due to limitations in global technological development;

 2. Printed circuit board components: including printed circuit boards and their
- parts, electronic components, etc; Depending on the product model, the product you purchased may not conta all of the above components.



FE A CE O A K O

Certificate Of Approval

Sales date

Postal code

The power light is not on Check whether the charging port is plugged in

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.