TF-Y16说明书 成品尺寸: 60X84mm 128铜版纸 覆哑膜 双面印刷 钢琴折

TRANSFORMERS

The name and content of harmful

	Harmful Substances						
Part Names	Pb	Hg	Cd	Cr(VI)	PBB	PBDE	
Printed circuit assembly	0	0	0	0	0	0	
Small structural parts such as shell	0	0	0	0	0	0	

his form is compiled in accordance with SJ/T 11364 Complete that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.

X:Indicates that the hazardous substance at least in a certain omogeneous material of the part exceeds The limit requirements

iomogeneous material of the part exceeds the limit requirements ipecified in GB/T 26572. The parts marked with "X" on the form are all harmful due to the mitations of alobal technological development. Substitution of substances

Printed circuit board components: Including printed circuit boards and their parts, electronic components, etc.and depending on the product model, the earbuds you purchased may not contain all the above components.



Does not contain 6 kinds of toxic and harmful substances or contains but is less than the limit value, the letter "e" stands for the English letter electronic; The initials of electrical and environment; The curved arrows around it indicate recyclability.



Warranty statement

Disclaimer
This user manual does not have any form of guarantee, position expression or
other implication. The mentioned products, specifications and information are for
reference only, and the content will also be updated on the web at any time
without additional separate notice

Warranty statement:
The product attached to this document is guaranteed as follows:If the product is twelver (12) months from the date of purchasef "Warranty Period") under normal conditions of use due to quality defects damaged, can be repaired. Free reading control of the product of the purchase date cannot be determined, the warranty period shall be 13 (13) months of the product service halling the product of the product service halling first and if you apply in the product service halling first and second to the determined the product in the product service halling first and second in the product service halling first and second to the product service halling first and second of the product service halling first and second or occurrence product service halling first and second occurrence products service and second occurrence products second occurrence produ

to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantes does not apply to the fallowing situations:
1. Exceeding the validity period of the three packs:
2. Altering the warranty card and product acide does not match the product body;
3. Causes caused by misuse abuse or improper transportation, use, maintenance or storage obstades or damage;
4. Failure or damage caused by force majeure (such as earthquake, war, disasteret.c) or accelerations;
4. Failure or damage caused by shore an experience of the control of the

Service supervision hotline: 400-885-8808

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consum rights that cannot be excluded or restricted under the law profit.

TRANSFORMERS



TF-Y16 WIRFLESS SPEAKER Instruction manual

8 6

Packing list -0+

micro LISB Charging cable *1



Instructions and

Product specification

Effective distance: ≥ 10M Horn diameter: ϕ 45mm Impedance: 4 O Signal to noise ratio: ≥ 90dB Distortion: ≤ 5%

Frequency response: 20Hz-10KHz Rated input: 5V === 500mA

Rated capacity of lithium battery: 800mAh Rated power: 4.3W

Charging time: approximately 2 hours

Usage time: approximately 3.5 hours Waterproof Level: IPX5

1 Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the

2,Don't put the speaker in the water or any others liquid.The speaker are not waterproof. 3.If any liquid enters the product by accidentally,please disconnect

and remove the connection immediately.

4.Please make sure that there is no water on your hands when 5.Do not put the product near by the heat source or expose it to the

fire source directly.

6. Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction

Keys and functions



O Power Button -- Power On/Off

Single press the power button. Long press the power button machine On/Off.

🥎 -- Answer/Hang Up -- Reject the cal

Single press the power button. Single press the power button. Double press the power button.

-- Call Back the Last Contact ☐ Volume down / Previous Song

-- Single press to reduce the volume -- Long press 1.5 second to play the previous song.

-- Single press to increase the volume
-- Long press for 1.5 seconds to play the next song.

Low power alarm: When the battery power is less than 10%, the

Product operation instructions

Wireless use method

Press and hold the "O" key for about 3 seconds to power on.
 The prompt sound will sound and the blue light will flash quickly.

 \bullet Open Wireless device Settings, search for Wireless connection name "TF-Y16" and click Connect, Bluetooth connection success prompt sound, blue light long on; When you use the speaker again, turn on the Wireless between the speaker and the smart device, and it will automatically connect back.

 Wireless automatic connection function: After successful Wireless connection when the effective distance is exceeded, it will be automatically disconnected, and after returning to the effective distance, the Wireless speaker and smart device will be automatically connected.

• Wireless mode: Connected state, the blue light is on for a long time,and the blue light blinks slowly when playing music.

Pairing status: The blue indicator blinks quickly

. Charging indicator: charging red light on, full red light off.

Common problems and solutions

breakdown	solution		
Failed to pair multiple connections	Turn off the speaker and restart		
The music plays staccato	Whether the connection distance is out of range or there is an obstacle between the speaker and the phone		
Play without sound	Check that the speaker is at its lowest volume		
Unable to charge	Check whether the built-in battery of the speaker is charged		
The power light is off	Check that the charging port is plugged in		

Warranty Service

User info							
User name		Email					
Contact number		Postal code					
Mailing address							
Product infor	mation						
Product name		Product number					
Product barcode /	Serial number / Batch number						

Manufacturer: Shenzhen Demicea Trading Co., Ltd-Malulaturar John State Communication (Malulaturar Malulaturar Malu Street, Longgang District, Shenzhen, China, 518000

> Certificate of Approval Production Time:

> > 5

反面

speaker will sound a prompt tone, and the speaker should be charged in time, when the power is less than 3%, the machine will automatically

TWS mode: Automatically initiate TWS mode upon startup, establish TWS connection within 15 seconds. If there has a TWS connection record, and it will automatically pair within 5 seconds. To Turn off the speaker to disable TWS mode

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.