



正面

包装清单

	耳机 *2
	Type-C充电线 *1
	充电仓 *1
	说明书与保修卡 *1

耳机规格

蓝牙版本: V5.4
传输距离: ≥10m
扬声器单元: Φ10mm
耳机阻抗: 32±15%Ω
频响范围: 20Hz~20kHz
灵敏度: -58±3dB
待机时间: ≈20小时
播放时间: ≈5小时
电池容量: 40mAh
充电时间: ≈1.5小时
额定输入: 5V⎓40mA

充电仓规格

充电时间: ≈2小时
电池容量: 320mAh
额定输入: 5V⎓500mA

产品示意图

产品操作说明

①开机: 长按耳机触摸区域3秒。方法2: 耳机在充电盒时打开充电盒上盖, 蓝灯长亮1秒
(语音提示音: "Power on")

②关机: 方法1: 开机状态无连接3分钟后自动关机。方法2: 耳机放入充电盒, 关闭充电盒盖子后自动关机充电。
(语音提示音: "power off")

③蓝牙配对: 步骤一: 开机后自动进入蓝牙配对
步骤二: 打开智能设备的蓝牙列表, 搜索"TF-T10"并连接
步骤三: 左右耳机出现不配对时, 请恢复出厂设置, 放回充电仓再打开自动配对
(语音提示音: "connected")

温馨提示

- 除说明书有特殊标注的操作方式以外, 请尝试拆卸或更换产品内的任何零件。
- 请勿将产品放入水或其他任何液体中。产品非防水设计。
- 如果有任何液体不小心进入产品内, 请立即断开连接并移开产品。
- 为避免触电, 请在安装或卸载产品时, 确保手上没有沾水。
- 请勿将此产品放置于热源附近或直接暴露于热源附近。
- 请勿将本产品放置在有强大电磁力的环境中, 否则会导致产品故障。

进入设备配对状态: 主耳蓝灯快闪, 副耳熄灭 →

LED指示灯状态

开机	耳机指示灯呈蓝灯长亮1秒
关机	蓝灯长亮1秒后熄灭
连接设备	耳机指示灯熄灭
断开连接	主耳机蓝灯快闪, 副耳机熄灭
耳机低电量	耳机蓝灯快闪
耳机充电	蓝灯长亮
充电仓充电	指示灯呈红灯闪烁
充电仓放电中	蓝灯长亮4秒后熄灭
充电仓低电量	蓝灯连续闪烁4次
清除配对	蓝灯长亮1秒后熄灭
游戏模式	蓝灯每15秒闪1次

触摸操作

■ 常规模式	语音助手: 长按左功能键2秒启动/关闭 音量加: 单击右功能键 音量减: 单击左功能键
■ 音乐播放模式	播放/暂停: 双击任意耳机功能键 上一曲: 三击左耳功能键 下一曲: 三击右耳功能键
■ 通话模式	接听/挂断来电: 双击任意耳机功能键 拒接来电: 长按任意耳机功能键2秒
■ 游戏/音乐模式切换	音乐模式: 长按右耳触模键2秒 (语音提示音: "music mode") 游戏模式: 长按右耳触模键2秒 (语音提示音: "game mode")

恢复出厂设置

蓝牙开机未连接状态, 5击完成清除与设备配对信息并自动关机, 蓝灯1秒后熄灭, (语音提示音: "power off")

产品中有害物质名称及含量

部件名称	有害物质 六价铬(Cr(VI)) 多溴联苯(PBB) 多溴二苯醚(PBDE)				
印刷电路组件	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
外壳等小结构件	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

本表数据依据SJ/T11364的规定编制
O表示该有害物质在该部件所有均质材料中的含量均在
GB/T26572规定的限量要求以下。
X表示该有害物质至少在该部件的某一均质材料中的含量超出
GB/T26572规定的限量要求。
表中标记“X”的部件, 均因全球技术发展水平限制而无法实现有害
物质的替代。

本表数据依据SJ/T11364的规定编制
印刷电路组件*: 包括印刷电路板及其零部件, 电子元器件等,
根据产品型号不同, 您所购买的产品可能不会含有以上所有部件

保修声明

免责声明
本使用手册没有任何形式的担保, 立场表达或其他暗示, 本使用手册所提到的产品、规格
及信息仅供参考, 内容会随时更新于网页, 不另行通知。

保修声明
就本文件所涉及的产品做如下保证: 如产品在您购买之日起十二(12)个月内(“保修期”)内, 在
正常使用情况下因质量瑕疵发生损坏, 能修理的, 免费修理; 经厂家确认无法修理的, 免
费更换, 或更换后的产品。在剩余保修期内(最短不少于30天)内继续享有保修。购
买日以销售发票日期为准; 如无法确定购买日, 则保修期自产品生产日期起按十三(13)
个月计算。
如需保修, 请先致电产品服务热线, 并按我们指示的方式执行。申请保修时, 您需要提
供维修单, 产品编号及故障简要说明。
1. 超过三包有效期限;
2. 涂改保单, 产品编码与产品本体不符;
3. 因误用, 滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
4. 因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏;
5. 损坏, 塑料因过度人为损坏;
6. 因承载过重造成的脱线或断裂;
7. 任何因物体撞击造成的损坏;
8. 有烧损或浸没迹象的产品;
9. 因自然改善导致的损坏;
10. 产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损坏。
11. 产品有标识的部件被更改或损毁, 本保证将失效。
产品及随附物的开盒及外观完好不属于保修范围, 您应在接收产品时当场检验并按任何
不合格提出异议。
以上保证是我们就产品做出的全部保证, 且仅在中国大陆地区境内适用。本文件的任何内
容均不影响根据法律规定不能排除或限制的消费者的权利。
服务监督热线: 400-885-8808

保修声明

免责声明
本使用手册没有任何形式的担保, 立场表达或其他暗示, 本使用手册所提到的产品、规格
及信息仅供参考, 内容会随时更新于网页, 不另行通知。

保修声明
就本文件所涉及的产品做如下保证: 如产品在您购买之日起十二(12)个月内(“保修期”)内, 在
正常使用情况下因质量瑕疵发生损坏, 能修理的, 免费修理; 经厂家确认无法修理的, 免
费更换, 或更换后的产品。在剩余保修期内(最短不少于30天)内继续享有保修。购
买日以销售发票日期为准; 如无法确定购买日, 则保修期自产品生产日期起按十三(13)
个月计算。
如需保修, 请先致电产品服务热线, 并按我们指示的方式执行。申请保修时, 您需要提
供维修单, 产品编号及故障简要说明。
1. 超过三包有效期限;
2. 涂改保单, 产品编码与产品本体不符;
3. 因误用, 滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
4. 因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏;
5. 损坏, 塑料因过度人为损坏;
6. 因承载过重造成的脱线或断裂;
7. 任何因物体撞击造成的损坏;
8. 有烧损或浸没迹象的产品;
9. 因自然改善导致的损坏;
10. 产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损坏。
11. 产品有标识的部件被更改或损毁, 本保证将失效。
产品及随附物的开盒及外观完好不属于保修范围, 您应在接收产品时当场检验并按任何
不合格提出异议。
以上保证是我们就产品做出的全部保证, 且仅在中国大陆地区境内适用。本文件的任何内
容均不影响根据法律规定不能排除或限制的消费者的权利。
服务监督热线: 400-885-8808

保修卡

尊敬的用户, 感谢您选择我们的产品。为了确保您的保修权益, 请将此保修卡填写完整并妥善保管。

用户信息	用户名: _____	电话: _____
联机信息	联机电话: _____	联机邮箱: _____
产品信息	产品名称: _____	产品型号: _____
产品序列号/批次号	Product barcode / Serial number / Batch number	_____
销售信息	名称: _____	地址: _____
联机日期	电话: _____	发货日期: _____
备注	备注: _____	


TF-T10

合格证

产品编号: _____

生产日期: _____

有效期: _____



反面

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name	_____	Email	_____
Contact number	_____	Postal code	_____
Mailing address	_____		

Product information

Product name	_____	Product number	_____
Product barcode / Serial number / Batch number	_____		

Vendor information

Name	_____		
Address	_____		
Contact number	_____	Postal code	_____
Sales date	_____	Invoice number	_____
Remark	_____		

Certificate of Approval

Product No: _____
Production Time: _____
QC: _____

TF-T10 True wireless BT headset Instruction manual

Packing list

	Headphones *2
	Type-C Charging cable *1
	Charging case *1
	Instructions and Warranty card *1

Headset specifications

BT version: V5.4
Transmission distance: ≥10m
Speaker unit: Φ10mm
Horn impedance: 32±15%Ω
Frequency response range: 20Hz~20kHz
Sensitivity: -38±3dB
Standby time: ≈20hours
Running time: ≈5hours
Battery capacity: 40mAh
Charging time: ≈1.5hours
Rated input: 5V⎓40mA

Charging bay specification

Charging time: ≈ 2 hours
Battery capacity: 320mAh
Rated input: 5V⎓300mA

Product operation instructions

① Boot:
Method 1: Open the top cover of the charging case, and the headset will turn on automatically.
Method 2: Hold down the left/right multi-function button for 3 seconds, and keep the white indicator on for 1 second.
(Voice prompt tone: "Power on")
② Shutdown:
Method 1: Put back the charging case, close the upper cover, the earphone automatically turns off and charges, and the red light is steady on.
Method 2: If the device is not connected, the device automatically shuts down after 3 minutes. The red light is on for 1 second and then the device is off.

Tips

- Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the earbuds.
- Don't put the earbuds in the water or any other liquid. The earbuds are not waterproof.
- If any liquid enters the product by accident, please disconnect and remove the connection immediately.
- Please make sure that there is no water on your hands when installing.

LED indicator status

Power on	The headphone indicator turns blue for 1 second
Power Off	The blue light stays on for 1 second and then goes off
Connecting device	Headphone light off
Disconnect	The blue light on the primary earphone blinks quickly, and the secondary earphone is off
Earphone low battery warning	The blue light of the headset blinks quickly
Earphone charging	The blue light keeps on
Charging chamber charging	The indicator is blinking red
Charging bay discharging	Blue light stays on for 4 seconds and goes off
Charging bay low power	The blue light flashes four times
Delete match	Keep the red light on for 1 second
Game mode	The blue light flashes once every 15 seconds

Restore factory settings

If the Bluetooth is not connected when the device is turned on, 5 clicks are completed to clear the pairing information with the device and automatically shut down. The blue light will turn off after 1 second (voice prompt tone: "power off").

Touch operation

■ General mode	Voice Assistant: Press and hold the left function key for 2 seconds to start/stop Volume Increase: Click the right function key Volume Down: Click the left function key
■ Music playback mode	Play/Pause: Double click any headset touch button Previous: Three hits left ear function key Next: Three clicks right ear function key
■ Call mode	Answer/hang up a call: Double click any headset touch button Reject incoming calls: Hold down any earphone touch button for 2 seconds
■ Game/ Music mode switch	Music mode: Press and hold the touch button on your right ear for 2 seconds. (Prompt tone: "music mode") Game mode: Long press the right ear touch button for 2 seconds. (Prompt tone: "game mode")

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	<input type="radio"/>					
Small structural parts such as shell	<input type="radio"/>					

This form is compiled in accordance with SJ/T11364.

O indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit required by GB/T26572.

X indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds the limit requirements specified in GB/T26572.

The parts marked with "X", on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components:
Including printed circuit boards and their parts, electronic components, etc. and depending on the product model, the earbuds you purchased may not contain all of the above components.

Warranty statement

Disclaimer

This user manual does not have any form of guarantee, position expression or other implications. The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement

The product attached to this document is guaranteed as follows: If the product is within (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired. Free repair or replacement of the damaged parts, and the repaired or replaced product can continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale, the ticket date shall prevail if the purchase date cannot be determined, the warranty period shall be 12 months.

If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of the three packs;
2. All the parts of the product and product code does not match the product body;
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage obstacles or damage;
4. Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.)
5. Disconnection or tearing caused by excessive load;
6. Any damage caused by sharp objects;
7. Damage caused by liquid or water damage;
8. Damage caused by unauthorized disassembly;
9. Aging, discoloration, abrasion, rupture and other losses that occur during the use of the product;
10. If the content of the identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law of profit.

Service supervision hotline: 400-885-8808

TF-T10

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.