

# CONNECTED CHEF

KITCHEN TABLE + FOOD PREP STATION

## QUICK START GUIDE

SCAN FOR



MORE INFO

BUTTONS ARE LOCATED ON THE DISPLAY END OF THE CONNECTED CHEF™ KITCHEN TABLET



- Microphone
- Volume Down
- Volume Up
- Power
- USB-C Charging Port

## Get Started

Connect the USB-C charging cable to charge the battery



Press the power button to start the Kitchen Tablet



Start-up approx. 30 seconds

**SLEEP MODE** Tap the power button once to enter sleep mode and tap again to wake.



**POWER OFF & RESTART** Press and hold the power button. Options to Power Off or Restart will appear on the screen.



## Get Setup

Follow setup screens



## Android Help

visit  
<https://support.google.com/android>

Google and Android are trademarks of Google LLC.



## Get Connected

Access to unlimited free content online with millions of cooking and food related websites and videos as well as tutorials and cooking classes, all in one place.

Download your favorite cooking and food apps to store and save your favorite recipes. Connected Chef™ becomes your digital recipe bookshelf and much more.



#ConnectedChef

## ROTATIONAL DISPLAY

Because every kitchen is different, the Connected Chef™ Kitchen Tablet display can be oriented whichever way suits you.

### 1. ENABLE SCREEN ROTATION

To turn rotation on or off, swipe down from the top of the Kitchen Tablet display and tap Auto-rotate.




if Auto-rotate button is not displayed, press



### 2. ROTATE THE KITCHEN TABLET

Lift the Kitchen Tablet and rotate it so the display is oriented the way you want, then tilt the kitchen tablet forward. The display will rotate.




Please note: Some apps may not allow screen rotation.



## CLEANING

### HOW TO CLEAN THE KITCHEN TABLET DISPLAY

Wipe with a damp cloth



Do not submerge in water Not dishwasher safe


### HOW TO CLEAN THE BAMBOO CUTTING BOARD

Remove the Bamboo Cutting Board from the Kitchen Tablet base and hand wash.




Not dishwasher safe

## IN THE BOX



CONNECTED CHEF™ KITCHEN TABLET



BAMBOO CUTTING BOARD



110V/5V 2A POWER ADAPTER



2 METER (6.5 FT) USB-C CABLE

CONNECTED-CHEF.COM

Connected Chef™ is a trademark of Capstone Industries Inc.

## **FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

## **Specific Absorption Rate (SAR) information:**

This Kitchen Tablet + Food Prep Station meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

## **FCC RF Exposure Information and Statement**

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Kitchen Tablet + Food Prep Station (FCC ID: 2BAQRCAP-1815) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for close to the user's body is 0.112W/kg. The device was tested for typical operation near the body while maintaining a distance of 0mm from the back of the phone. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.