




Innovating the Art of Listening

EF600

Balanced Headphone Amplifier and DAC

User Guide



Thank you for choosing the HIFIMAN EF600, our flagship DAC and amplifier that is one of the finest on the market. This Owner's Manual will provide a helpful overview and familiarize you with the product's features and proper usage.

HIFIMAN is a world-famous manufacturer specializing in high-end audiophile-grade products. The company's excellent R&D team features industry professionals with extensive experience in "voicing" high-end headphones and electronics.

Following the success of the EF400, HIFIMAN introduces the EF600, designed for audiophile-grade desktop performance. Featuring HIFIMAN's acclaimed Hymalaya Pro DAC module, the EF600 is designed for use as a pre-amp or completely independent amplifier. Its elegant industrial design makes it a welcome addition to the room, no matter where it is placed.

Hymalaya Pro uses the core technology found in the Hymalaya Max, with the added support of a new FPGA algorithm and 0.01% precision resistors. The sum total is performance that surpasses the PCM1704 in every way.

EF600 supports high resolution bluetooth wireless audio. The upgraded Qualcomm QCC5124 Bluetooth design supports multiple Bluetooth codecs, including aptX-HD, delivering lossless sound quality for audiophile-level sonics.

Table of Contents

Important	03
Specifications	04
In-box Accessories	04
Front Panel Layout	05
Real Panel Layout	06
Bottom Panel Layout	07
HIFIMAN Limited Warranty	08

Important

1. Power voltage may vary in different countries and areas. Before connecting this product to a power source for the first time, please make sure the rated voltage on the panel corresponds to local voltage. If not, the power supply should be turned off and the power cable disconnected before adjusting the voltage selector to make sure the power supply corresponds to the local voltage before reconnecting. The value displayed on the red voltage switch is the current voltage.
2. Firmly grasp the plug when the power cable is being unplugged. Do not pull the cable to unplug.
3. Do not operate with wet or oily hands.
4. This product should not be placed in a dusty, dirty environment. Never expose it to high humidity.
5. The plug should be unplugged if the product will not be used for an extended period.
6. IMPORTANT: Do not reverse the L/R channel while connecting with the audio devices.
7. To avoid hearing loss, always maintain a moderate listening volume when using headphones /earphones.
8. Be careful to ensure the EF600 is used only by adults who understand the proper option. Keep the DAC/Amp away from children. Likewise, high temperatures and potentially damaging chemicals and solvents such as butane lighters, gasoline, insecticides, etc. may cause irreparable damage to the EF600. Items such as a lighter, butane gas tank, air freshener, insecticide, solid alcohol, gasoline and organic solvent etc.
9. This product should not be disassembled or refitted by anyone other than HIFIMAN.
10. In the following situations, please disconnect the power supply from the product and contact HIFIMAN customer service.:
 - A. The power cable or plug is damaged.
 - B. The product has fallen to the ground or liquid has spilled into or on the equipment.
 - C. The product was exposed to an extremely humid environment.
 - D. The product does not seem to operate properly, or there is a noticeable change in performance.

Specifications

Signal to Noise Ratio: 118dB (A Weighted)

Channel Separation: 131dB \pm 3dB

THD+N (Line out) : 0.0014% (-8dB)

Max Power Output: 5.12 WPC@32 Ω balanced/1.8 WPC@32 Ω unbalanced

Codecs: AAC/SBC/aptX/aptX-HD/LDAC

Dimension: see below graphic for all details



In-box Accessories

Power Cable x1

Bluetooth Antenna x1


Note:

Specifications and features are subject to change without notice.


Front Panel Layout



Real Panel Layout



Bottom Panel Layout



HIFIMAN Limited Warranty

Your product is warrantied for a period of one year beginning with the original date of purchase. If you join HIFIMAN on Facebook, your product warranty will be extended for an additional six months. Please contact HIFIMAN customer service if you need any assistance.

The dated sales or delivery receipt is your proof of purchase. You may be required to provide proof of purchase as a condition of receiving warranty service so please keep it handy.

If your product is under warranty and malfunctions occur, please contact HIFIMAN customer service or your authorized dealer. If necessary, and at the discretion of HIFIMAN, the company will provide a warranty repair or replacement of your product.

Caution: do not disassemble or modify the product in any way. Tampering with or modifying your HIFIMAN product will void its warranty.

This Limited Warranty does not apply to :

1. Defective or discolored parts if the damages are caused by fluids, dirt, missing keys, broken plastic parts or improper use.
2. Damage caused by misuse with another product.
3. Use of the product for other than its normal intended use, including, without limitation, failure to use the product in accordance with the supplied "Owner's Guide"
4. Damage caused by accident, abuse, neglect or misuse.
5. If you do not have a valid dated receipt showing proof of purchase.
6. Damage caused by services/repairs or other modifications to the system carried out by anyone other than HIFIMAN or an authorized HIFIMAN distributor or dealer.
7. Damage caused by self-repair or if the unit has been disassembled or modified in any way.

HIFIMAN guarantees your satisfaction and will do everything reasonable to achieve that. If you have any questions or concerns with your product, simply contact your authorized dealer or HIFIMAN directly (if purchased from us) and explain the issue in detail. Should a return be required, a RA# will be issued. Return shipping to HIFIMAN or authorized service facility will be at the owner's expense.

The warranty applies to the first purchaser and is not transferable. Should you need warranty service please contact your authorized HIFIMAN dealer. Or email us directly at customerservice@HIFIMAN.com

If you have any concerns with your product: please contact us to explain the issue in detail. If a return/refund is required, a RA# will be issued. Return shipping to HIFIMAN or authorized service facility is done at the owner's expense.



facebook.com/hifimanelectronics



twitter.com/hifimanofficial



www.hifiman.com



HIFIMAN

Innovating the Art of Listening



Innovating the Art of Listening

Customer Service Tel: 1- 201-443-4626

E-mail: customerservice@HIFIMAN.com

Website: www.HIFIMAN.com



FACEBOOK

Scan QR Code to join
HIFIMAN on facebook

FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.