



THANK YOU

We appreciate your business and would like to thank you for choosing HALO!

Your safety is important to us.
Please read the instructions carefully and utilize the proper precautions before operating this device.

WARNING
Please read the following instructions for safety before use. Improper use may result in fire, property damage or personal injury or death. DO NOT use this product with incompatible components or alter the product in any way.

WARNING
Improper use may result in fire, property damage, or personal injury. Make sure to use the product according to the following safety rules and guidelines.

WARNING
Do not expose the product to any liquid or submerge in water.

SAFETY INSTRUCTIONS

Failure to follow the safety instructions can lead to fire, electrical shock, personal injury, property damage or damage to this product. Please read this entire manual.

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat sources and direct sunlight.
- Do not expose the unit to extremely high or low temperatures.
- Use this product in a location with a temperature of 32° F (0° C) - 104° F (40° C).
- Do not let the unit come into contact with water or liquid of any kind. If the unit becomes wet, immediately unplug it from the power source.
- Do not handle the unit, USB cord or wall charger with wet hands.
- Do not let dust or other debris accumulate on the product and the wall charger.
- Do not use the unit if it has been dropped or damaged in any way.
- Use the specified power source and voltage.
- Make sure the wall charger is inserted all the way into the electrical outlet. When not in use, unplug the wall charger.

PACKING LIST

— 02 —

CONTENTS

SAFETY INSTRUCTIONS 01

PACKAGING LIST 02

OPERATING INSTRUCTIONS 04

TECHNICAL SPECIFICATIONS 06

WARRANTY 07

— 03 —

LED INDICATOR STATUS

Standby: The LED indicator will light up white for one second when the unit is plugged in and go into standby mode.

Charging: The LED indicator will have a slow breathing like effect. This means the charging pad is charging your device safely. The LED will turn off after about five times.

Abnormal: The LED indicator will pulse rapidly, indicating an abnormal or metal obstruction has been detected.

OPERATING INSTRUCTIONS

Step 1: Connect the provided USB-A to USB-C cable to your wall adapter and connect to an outlet.

Step 2: Place the charging pad on a flat surface.

Step 3: Place your device directly onto the center of the charging pad.

See illustrations below for examples of proper placement.

TROUBLESHOOTING

Issue	Cause	Solutions
Device is not charging.	The device might not be on the charging pad properly. The case on the device might be too thick, preventing the device from charging.	Remove the device and replace it onto the charging pad properly. Remove the case from the device before trying to charge again.
The LED indicator is not lighting up.	The charging pad is not getting power.	Disconnect the charging pad from the power source. Make sure the cable and wall adapter are connected properly. Connect the charging pad to another power source.
Flashing LED indicator	Foreign Object Detection (FOD) is triggered. A metal object is detected by the charging pad.	Remove the metal object between your device and the charging pad. If your device case contains metal, then remove your case.

— 04 —

Disposal/recycling
Do not put the device and its accessories in the trash can. Items must be properly handled in accordance with local laws and regulations. For additional information, please see www.epa.gov.

Affirm
Copyrighted equipment. We all rights reserved. All trademarks cited here are the property of their respective owners. The information contained in this agreement is subject to change without notice. HALO is not responsible for technical or editorial errors or omissions contained in this agreement. First Edition: January 2023

FCC Note
Warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 20 centimeters from the device surface at all times, except for non-telephone controls, with transmit time intervals in the order of 8 seconds. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.

ALLIANCE CONSUMER GROUP
700 Henrietta Creek Rd, Rowles, Texas 75282
Direct: 972.343.1026 | Toll-Free: 800.255.6061
www.acgbrands.com

— 05 —

TECHNICAL SPECIFICATIONS

INPUT	DC
DC	QC 9V/2A, 9V/1.67A, 12V/1.5A PD 9V/3A, 9V/2.3A
OUTPUT	Wireless SW7.5W/10W/15W
Transmission Distance	Earbuds: 0.12 inches (3mm) Phone: 0.2 inches (5mm)
Working Frequency	110-205KHz
PRODUCT	Dimensions Weight
	4.35 x 4.35 x 0.40 inches (11.05 x 11.05 x 1.02cm) 0.15lb (66g)

— 06 —

LIMITED WARRANTY

At HALO, we are dedicated to making the best quality products. To back this up, this product is warranted. HALO warrants its products to be free from defects in material and workmanship under normal use. During the first 90 days from date of purchase, HALO will repair or replace the defective product. This warranty does not affect any statutory rights that you may be entitled to. Keep a copy of your purchase receipt as proof of purchase.

FOR ALL QUESTIONS ABOUT THE WARRANTY OR EXCHANGE REQUESTS, CONTACT US.
1-800-255-6061

— 07 —



骑马订 12P 128g铜版纸 120*80mm