Quick instructions

1. Open pairing broadcast

Long press the button (about 2S), and release it after hearing a beep sound [*Broadcasting time is 10 minutes, if it is not paired and bound for 10 minutes, the broadcasting will automatically turn off1.

Open Apple's self built-in " Find My" App;

③ For devices with the words' Find Locator Card ', tap' Connect '. Fill in "Name Item" to name your device and select a emoticon;

(§) Agree to register the device with your Apple ID; (§) Tap 'Finish' to pair successfully.

3. Enable lost mode

① Open Apple's self built-in "Find My" app, click on "Items" at the bottom of the screen. click on the item's name;

② Under "Lost Mode". click "Fnable":

3 Follow the instructions on the screen and click 'Continue' to enter the contact phone or

(4) After clicking "Next" to check the information, please click "Enable" again to complete the

1 Open Apple's self built-in "Find My" app, click on "Items" at the bottom of the screen, and then click on the item's name:

2. Find "Remove Item" at the bottom of the list and tap "Remove" to complete the

5. Entering sleep mode

Long press the button, you will hear 1 beep, 2 beeps, 3 beeps, and 3 beeps, then release the button, and enter the sleep state [Long press the button (about 2S), exit the sleep state and enter the broadcast pairing mode after hearing a beep sound.]

*Restore factory settings: Press and hold the button for a long time, and you will hear 1 beep . 2 beeps, and 3 beeps. Continue to press and hold the button after the beep sound. and release the button after hearing a long beep sound of "beep", and then restore the

FCC Caution: Any changes or modifications not expressly approved by the party responsible forcompliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

The device has been evaluated to meet general RF exposure requirements. The device can be usedin portable exposure conditions without restriction.

This equipment has been tested and found to comply with the limits for a Class B digital device.pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protectionagainst harmful interference in a residential installation. This equipment generates uses and canradiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation of this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the eauipment offand on, the user is encouraged to try to correct the interference by one or more of thefollowingmeasures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver
- Consult the dealer or an experienced radio/TV technician for help

Main Functions

1. Locate your item

When the device and the iphone are beyond the Bluetooth distance, the device cannot be linked in the "Find My" app. Available options: Lost Mode, select Enabled. Enter your contact number etc. If the device is disconnected from your inhone for an extended period of time and there are other iPhones nearby, you will receive notifications and the atest location in your "Find My"app.

2. Play Sound

The iphone and the device are within the Bluetooth range (usually about 20 meters), in the "Find My" APP, click "Play Sound", and the device will make a sound to help you quickly find nearby items

Instructions for device button

After installing the battery, the product will automatically turn on and enter the broadcast pairing mode [*Broadcast time is 10 minutes, if it is not paired and bound for 10 minutes. ne broadcast will automatically turn off].

2.Open pairing broadcast

ress and hold the button for about 2 seconds, hear a beep sound, and then release [*Broadcast time is 10 minutes, if not paired and bound for 10 minutes, the broadcast will

3.Device re-enters pairing state

When the device is removed, it will beep and the pairing broadcast will be on. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and APP cannot be paired at this time. If you need to pair the device, you need to follow the "Turn on the pairing broadcast" and enter the pairing state. At this time, you can re-pair with the

4.Restore factory settings

Long press the button, you will hear 1 beep, 2 beeps, 3 beeps, beeps, beeps, and then continue to press the button to hear a beep Release the button after a long beep, and the

5.Device enters sleep mode

Safety Statement

electric machinery.

certified lower power frequency

or industrial and scientific applications.

Article 12

Long press the button, you will hear 1 beep, 2 beeps, 3 beeps, and 3 beeps, then release the button and enter sleep mode.

According to the management method of low-power electric wave radiation

Without permission, any company, firm or user shall not alter the frequency, increase

the power, or change the characteristics and functions of the original design of the

The application of low power frequency electric machineries shall not affect the

The foregoing legal communication refers to the wireless telecommunication

frequency electric machinery should be able to tolerate the interference of the

navigation safety nor interfere a legal communication, if an interference is found, the

service will be suspended until improvement is made and the interference no longer

operated according to the telecommunications laws and regulations. The low power

electric wave radiation electric machineries and equipment for legal communications

FQA

1. When can the device be located by other iPhone?

When the device is disconnected from the owner's iPhone for a period of time, the device can start to be located by other iPhones, and the owner can start to obtain the location of

2. How to prevent the device from being used for malicious tracking?

When someone else's device sneaks into your belongings and is tracked for longer than a period of time, you will be notified in two ways:

① If you have an Apple device such as iPhone, iPad, or iPod touch, you will get a reminder on the Apple device; this function is available on Apple devices with iOS or iPadOS 14.5 and

2) If you don't have an Apple device, if someone else's Locator Tag leaves its owner and has been following you for a while, it will play music to remind you when it moves. Of course, don't worry if you happen to have a friend with you, or a lot of people on the subway you're taking. Because as long as the device does not leave the owner's side, such a eminder will not be triagered

3. How to protect my privacy?

Where your device is, only you can see it. Your location data and history will never be stored in Apple's and MOYAGOA's servers. Devices passing your device's location data remain anonymous at all times, too, and location data is encrypted every step of the way. As a result, neither Apple nor MOYAGOA knows where your device is, nor the identity of the device that helped find it.

4. How to charge?

Legal notice

The product is equipped with a charging clip to charge slim card finder. Please charge the product according to the frequency of use.

① Pair the slim card finder with the charging clip (the charging probe on the clip corresponds to the charging contact of slim card finder)

(2) When the slim card finder is charging, the light on the charging clip will prompt red: 3 When the slim card finder is fully charged, the light on the charging clip will prompt

*Note: The charging clip must use a 5V 1A (or less than 1A) power adapter to charge the the slim card finder. Otherwise the charging clip may not be able to power the product.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and

requirements. Apple is not responsible for the operation of this device or use of this

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad. iPadOS, Mac, macOS

and watchOS are the trademarks of Apple Inc. IOS is a trademark or registered

trademark of Cisco in the U.S. and other countries and is used under license.

product or its compliance with safety and regulatory standards.



Safe Disposal of Electronics

When your device reaches the end of its life, please dispose of it at your local e-waste center for recycling and proper disposal to protect our environment. Contact your local authorities to find a reputable and certified e-waste disposal center near you.

5. What is the Find My network? And how does it work?

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch, Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or MOYAGOA can view its location

Furopean Union-Disposal InformationThe symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and theenvironment.

Important tips

When pairing a device with Findmy app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions

- ① Change the phone's network, such as switching between WiFi and mobile network
 - 2 Factory reset of the equipment: press and hold the key for a long time, and then hear one prompt tone of "Di", two prompt tones of "Di", three prompt tones of "Di", "Di", and "Di". Continue to press and hold the key for a long time, and then release the key after hearing a long prompt tone of "Di". At this time, the factory status is restored;
 - 3 Re pair with the search app;
- 4 Restart phone

MOYAGOA —Find Locator Card

Product User Manual

