

87
87

Airyou Fly 1 specification

Description of appearance

Wear

Please choose the ear cap that best fits your ears.

The earphone bone is positioned against the gap of the earphone cap and deformed onto the earphone mouth by pulling the earphone cap.

Recharge

Remove the insulation sheet. Make sure the earphones and TYPE-C charging ports are completely dry before charging.

Power on and pair

Open the charging case and the headset will automatically turn on and enter Bluetooth pairing mode. When first connecting, select "Airyou Fly 1" from the Bluetooth list of your device.

Multipoint connection

The headset can connect to two devices at once so you can easily switch between them. When connected to one of your devices, to pair with the other, put on your headphones, then press and hold the touchpads on both headphones for 3 seconds at the same time. Select "Airyou Fly 1" from your device's Bluetooth list to establish a connection.

Key control

x1: Click once
x2: Click twice
x3: Click three times
2s: Hold for 2 seconds

Noise reduction mode

To reduce unwanted ambient noise, enable noise reduction mode.

封面
封底

—正面

LDAC

Experience LDAC quality sound on a device running Android 8.0 or higher

Earphone shutdown

Put the headphones back in the charging case and close the case.

Pairing

Long press the charging box button for 3 seconds to enter the pairing operation.

Factory data reset

Put the headset into the charging case and keep it open. If the headset does not pair with the Bluetooth device, please reset it. Press and hold the button on the charging case for 10 seconds until the LED indicator on the charging case flashes orange slowly 3 times.

Service policy

In the normal use of the product, if the product appears non-human damage had performance failure, the consumer from the date of purchase, the warranty period is 12 months, during the warranty period, enjoy free warranty service. Under any of the following circumstances, consumers shall not enjoy the rights and interests of warranty:

- Artificial damage
- Out of warranty
- No warranty card and valid invoice, except those that can prove that the product is under warranty
- Failure to use, maintain and maintain the parts according to the instructions
- Without the authorization of the company, disassemble and repair the products, or flood or break the products.
- Damage caused by force majeure.

Customer service hotline: 400-8618-616
Shenzhen Quanchi Information Technology Co., Ltd.
Address: 3-805, Guba Building, Gubayuan, Honggang Community, Songgang Street, Bao'an District, Shenzhen

Maintenance and maintenance

Keep the device and its accessories dry. Do not use external heating equipment such as microwave oven or hair dryer to dry the device. Do not set the device and its accessories in an area where the temperature is too high or too low, otherwise it may cause device failure, fire or explosion. Before cleaning and maintenance, please stop using the device and close all applications. Disconnect all connections or cables from other equipment. Do not use strong chemicals, cleaning agents, or strong detergents to clean the equipment or its accessories. Use a clean, dry, soft cloth to wipe the device or its accessories. Do not touch magnetic stripe cards (such as bank cards and phone cards) with the device for a long time. Otherwise, the magnetic stripe cards may be damaged by magnetic fields.

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Airyou Innovations Limited is under license. Other trademarks and trade names are those of their respective owners.

LDAC

LDAC and LDAC logo are trademarks of Sony Corporation.

FCC ID: CMIT-1D

Other parameters:

Frequency range: 2.402-2.4835 GHz
Transmitting power: 10dBm
BT version: Version 5.3
Input parameter: 5V 0.5A

Packing list:

Earbuds: 1 pair
Charging case: 1
Charging cable: 1
Silicone earplugs: 4 pairs (including 1 pair on earplugs)
Manual: 3 copy (including warranty card)
Safety manual: 1

Safety instructions

- Do not use the device in a dusty, wet, dirty place or near a magnetic field. Otherwise, the circuit in the device may fail.
- When you use headphones to listen to music or talk, you are advised to use the minimum volume required to avoid hearing damage. Prolonged exposure to high volumes can cause permanent hearing damage.
- Remember that driving safely is your first duty and do not engage in distracting activities.
- Do not eat, drink, or cover the device with towels or other items. Do not use the device in a closed environment such as a box or bag.
- Do not place batteries or devices near heat sources or exposed fire sources, such as electric heaters, microwave ovens, ovens, water heaters, firelight, candles, or other places that may generate high temperature; otherwise, the devices may fall, catch fire, or explode.
- Do not use external heating devices such as microwave ovens or hair dryers to dry them.
- Use a clean, dry, soft cloth to wipe the device. Stop using the device before cleaning and maintenance.
- Use the device when the temperature ranges from 0°C to 35°C, and store the device and its accessories when the temperature ranges from -20°C to +45°C. When the ambient temperature is too high or too low, device faults may occur.
- Keep the device or its accessories in a cool, ventilated place without direct sunlight.
- The device and its accessories may contain some small parts. Please keep the device and its accessories out of the reach of children.
- Please do not disassemble or modify the equipment and its accessories without authorization; otherwise, the equipment and its accessories will not be covered by our warranty. Please contact our customer service center in case of equipment failure.
- Do not treat the equipment and its accessories as ordinary household garbage. Please comply with the local laws on the disposal of the equipment and its accessories, and support recycling.
- Do not step on, pull, or bend the device cables. Otherwise, the device may not work properly.
- Do not use strong chemicals, cleaning agents or strong detergents to clean the equipment or its metal parts. Use a clean, dry, soft cloth to wipe the equipment or other parts.

The name and content of harmful substances in the product

Component name	Hazardous substance					
	Lead and its compounds (Pb)	Mercury and its compounds (Hg)	Cadmium and its compounds (Cd)	Hexavalent chromium (Cr(VI))	Polychlorinated biphenyls (PCBs)	Polycyclic aromatic hydrocarbons (PAHs)
Plug with	○	○	○	○	○	○
Plastic component	○	○	○	○	○	○
Electronic components	×	○	○	○	○	○
Internal metal board	○	○	○	○	○	○
Metal component	○	○	○	○	○	○
Non-ferrous metal components	○	○	○	○	○	○
Battery component	×	○	○	○	○	○

This form is prepared in accordance with the provisions of SJ/T 11364-2014.
○ indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572-2011.
× indicates that the concentration of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in GB/T 26572-2011.
Note: The existence of these out-of-limit substances is temporarily irreplaceable under the current level of science and technology, and in line with the exemption requirements of EU RoHS for such parts.

10 The number in this label indicates that the environmental protection life of the product under normal use condition is 10 years.

Product warranty card

Product model	SN number
Name	Date of purchase
Address	
Telephone	
Invoice number	
Name (with official seal)	
Address	
Telephone	

Conjunctive syndrome
Date: _____
Inspector: _____

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, you can try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2BAXU-AIRYOUFLY1

—背面