## Remote control instructions:

Emergency stop key: It is only used for emergency stop, never use it as a normal stop key.

Speed/time+: You can increase speed and time by pressing this key. Speed range input upstate(0.6-7.5 mile/h) Speed range in folded state(0.6-2.5 mil/h) Speed adjusting is unavailable in auto mode. The time range is 5-99 minutes under manual mode.

Mode: You can switch different programs by pressing this key(p1-p12, H1-H3), also include time count down the program, distance count down the program, and calorie count down the program.

Speed/time-: You can reduce speed and time by pressing this key. Speed range in put up state(0.6-7.5 mile/h) Speed range in folded state(0.6-2.5 mil/h) Speed adjusting is unavailable in auto mode. The time range is 5-99 minutes under manual mode

Start/stop key: Press this key to start/stop the product, there is a 3 seconds count down before the start. The time range is 5-99 minutes under manual mode.

Remakes: The remote control signal range is 2.5 meters.

## **FCC** compliance statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.