

The Speaker Function Specification

I: Charge

External 5V charge for this speaker, The LED indicator lights up when charging

II: Keys Operation

①	⏻	Long press: Power on/off
	M	Short press to switch the Speaker playing mode: Wireless/USB/TF Card Reading/RADIO
	⏮ ⏪	"Long press: Volume down At the FM Radio mode: Short press to switch to the previous radio channel In the state of MP3 mode: Short press to switch the Previous song"
②	⏭ 🔊	Long press: Volume up At the FM Radio mode: Short press to switch to the next radio channel In the state of Wireless/USB/TF Card Reading mode: Short press to switch the next song
③	▶	In the state of Radio/Wireless/USB/TF Card Reading mode : Short press this button to Play/Pause of the speaker" Speaker in the FM mode: Press and hold the key for searching and saving FM channels automatically When an incoming call comes in, short press to answer the call During a call: Long press to hang up the call Short press the key to switch between phone calls /wireless speaker answers. Wireless Standing: Hold down the key to dial back the previous call

12cm

10cm

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.