

## E039

### 智能触控无线耳机说明书

感谢您购买本公司产品。本产品是一款智能无线耳机，可以让您轻松体验智能数码产品的无线乐趣。使用本产品前请认真阅读本说明书并妥善保管，以备查阅。



### IOS & Android

1. 打开充电仓盖，开机成功。
2. 耳机在开机且未连接手机的状态下会自动配对，组队成功后会有相应的提示音。



3. 打开手机蓝牙搜索 E039 ；



4. 搜索到蓝牙耳机后，点击配对，完成连接。

(注：由于蓝牙耳机的特性，您所在区域的电磁波可能干扰蓝牙的连接，耳机可能出现无声或者断连的情况。)

### 产品参数

- 无线版本：V5.3
- 工作范围：≤10米
- 无线频率：2.402-2.480GHz
- 充电盒容量：500 mAh
- 耳机内置电池：锂电池3.7V,50mAh
- 充电时间：约2小时
- 通话时间：约4小时
- 播放音乐：约7小时（80%音量）
- 充电电压：DC5V

### 按键功能操作

#### 触摸MFB

- 开机：仓内取出耳机开机 //长触摸按键4S
- 关机：耳机放回仓内充电关机(无连接蓝牙3分钟关机) //长触摸按键4S
- 连接手机：耳机开机后，打开手机蓝牙搜索对应设备名：SMA-X07 点击连接
- 播放/暂停音乐：单击左/右耳 Touch 键
- 上一曲：音乐播放状态 三击左耳 Touch 键
- 下一曲：音乐播放状态 三击右耳 Touch 键
- 接听电话：来电时，双击任意耳 Touch 键，可接听来电
- 挂断电话：通话中 双击任意耳 Touch 键，可挂断通话
- 拒接来电：来电时，长按任一耳机 Touch 键约2秒拒接来电
- 打开Siri：长按任意耳机 Touch 键2秒启动
- 恢复出厂设置：开机未连蓝牙状态，快速 6耳机 Touch 键

### 注意事项

- 切勿使用具有腐蚀性的清洁剂清理本产品；
- 切勿让本产品加热或靠近火源，如煮食炉；
- 请调节适当音量，以免造成不适；
- 切勿将本产品弃置于火中，避免发生爆炸；
- 切勿尝试拆开本产品作出任何修改，因为它并不包含任何维修组件；
- 切勿在雨中使用本产品；
- 如果长时期内不打算使用本产品，请您将它储存在干燥的环境中，（不得低于-15°或高于55°存储）并每月至少为耳机充电一次以延长耳机电池寿命；
- 请远离儿童或婴儿可接触范围。

### 客户服务

为了您的权益，请您认真填写，并妥善保管，作为维修前的凭证：


经销商信息 \_\_\_\_\_

产品型号： \_\_\_\_\_ 经销商名称： \_\_\_\_\_  
 联系电话： \_\_\_\_\_ 销售日期： \_\_\_\_\_

用户信息 \_\_\_\_\_

用户姓名： \_\_\_\_\_ 联系电话： \_\_\_\_\_  
 通讯地址： \_\_\_\_\_ 邮箱： \_\_\_\_\_

保修内容	保修日期



## E039

### USER MANUAL

Thank you for purchasing our Wireless Headset, which makes your life more convenient and smart. Please read this manual carefully before using this product and keep it handy for future reference.



### IOS & Android

1. open the charging box , then it will turn on automatic.
- 2.They automatically pairing ,and voice reminds



3. Turn on Bluetooth and search for "E039" (default).



4. Click "E039" to connect until "connected".

Note: Due to the characteristics of the Bluetooth headset, the electromagnetic waves in your area may interfere to the bluetooth connection, the headphones may be silent or disconnected.

### PRODUCT PARAMETER

- Wireless version: V5.3
- Communication scope: ≤10m
- Frequency response: 2.402-2.480GHz
- Charging box battery: 500mAh
- Earpiece battery: 3.7V,50mAh
- Charging time: about 2 hours
- Talking time: about 4 hours
- Play music: about 7 hours
- Charging voltage: DC5V

### Function operation

#### Touch on "MFB"

- Power on: Remove the earphones from the compartment and turn them on//Long press the touch button 4S
- Shutdown: Put the earphones back into the compartment for charging and shutdown (no Bluetooth connection for 3 minutes)//Long press the touch button 4S
- Connect your phone: After turning on the earphones, open your phone's Bluetooth and search for the corresponding device name: SMA-X07. Click to connect
- Play/pause music: Click the left/right ear touch keys
- Previous track: Music playback status: Three clicks on the left ear touch key
- Next track: Music playback status: Three clicks on the right ear touch key
- Answer phone call: When receiving an incoming call, double-click any ear touch button to answer the call
- Hang up call: Double click any ear touch button during a call to hang up the call
- Reject incoming calls: When receiving a call, long press any of the touch buttons on the earphones for about 2 seconds to reject the call
- Open Siri: Long press any earphone Touch button for 2 seconds to start
- Restore factory settings: When turned on without Bluetooth connection, quickly press the 6 headphone touch keys

### SECURITY

For correct and safe use of the earphone, pls. read the following instructions:

- Do not use the earphone at high volume as this can damage your hearing;
- When using the earphone, set it to an appropriate volume to be aware of your environment to ensure safety;
- Avoid using the earphone in dangerous situations or when you are distracted;
- Do not use the earphone under wet conditions;
- Avoid using or storing the headset at temperatures below -15°C or above 55°C to prevent damage of earphone and/or battery;
- Keep the earphone away from small children, toddlers and infants.

### Customer Service

For the sake of your rights and interests, please fill in carefully and make good safekeeping, which is as the voucher for repair:


Dealer's information \_\_\_\_\_

Product Type: \_\_\_\_\_ Dealer's Name: \_\_\_\_\_  
 Tel: \_\_\_\_\_ Sales Date: \_\_\_\_\_

User's information \_\_\_\_\_

User's Name: \_\_\_\_\_ Tel: \_\_\_\_\_  
 Postal Address: \_\_\_\_\_ E-mail: \_\_\_\_\_

Warranty Content	Warranty Date



Product after-sale service commitment table of comparisons.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction