


Wireless remote instruction


Warning

- If the winch is under load, the winch rope is under tension or the drum is in motion, do not engage or release the clutch .
- Never place the winch remote control where it can be activated when the natural coil, drive, or capstan is not in use .
- Never place a wireless winch remote in a place where it can be activated during installation, natural winding, driving, or servicing of a winch, or when the winch is not in use .
- The wireless function is automatically turned off after 2 minutes without any operation.
- Remote control (4082137) operating voltage 3V, receiver operating voltage 12V. Frequency range 433-434MHz. Operating temperature: -40°C to 65°C
- FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:•Reorient or relocate the receiving antenna.•Increase the separation between the equipment and receiver.•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.•Consult the dealer or an experienced radio/TV technician for help.Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.RF Exposure InformationThe device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WINCH OUT




Winch out button:
Press down to control the winch out operation



Wireless start indicator:

When the wireless mode is started, the indicator light is on; When the indicator light is on, the indicator light will blink when you press the control button of the remote control .

WINCH IN



Winch in button:
Press down to control the winch in operation

Wireless start/close button

- Press and hold for 3 seconds to enable or disable wireless mode