

Your CW Watch S5



Set up the Watch





- For Android phones, go to the Google Play.
- For iPhone, go to the App Store.

You can also scan the QR code on the left to quickly go to the Fitbeing app in the app store, and install it.



watch, please do not pair directly within the Bluetooth device list in your phone's system settings. 2. To ensure successful pairing, please grant Fitbeing App permissions to access Bluetooth, Location, and Camera on your phone.

Attentions:

Step 2: Pair with the App

you can start using the watch.

Open the Fitbeing app and select "Set Up a

Device" on the home page. Follow the instructions

1. To prevent connection issues between the app and the

to pair your "CW Watch S5" via Bluetooth. Then

Steps for Use

You can follow these steps to use CW Watch S5: 1 Wear \rightarrow 2 Power On \rightarrow 3 Set up \rightarrow 4 Start Using


The following steps will take approximately 5 to 10 minutes, please schedule a suitable time.


Wear Your Watch

Step 1: Thread the longer band through the first loop of the shorter band.

Step 2: Adjust to a comfortable tightness, then press the holes on the longer band ont the metal pin buckle of the shorter band.


Step 3: Insert the longer band into the second loop of the shorter band and tighten.





2 Power On

Press the Digital Crown until the startup screen appears




Note: If the watch can't power on, it may be because the battery has drained due to long periods of inactivity. Please charge it for approximately 10 minutes and wait for it to power on automatically.

Get Started

Touchscreen Operation

Support full-screen touch (swipe, tap, touch and hold)



Digital Crown Operation

- 1. Press the digital crown to wake up the screen.
- 2. Press the digital crown to enter the app center from the watch face screen. 3. Exit the app

Long press for 8 seconds to force restarting the watch.

Common Functions



Notification Center

Swipe down on the watch face screen.

Control Center

o access the Control Center, swipe up on the watch face screen. Enable features like Silent Mode, Sleep Mode, Always-on Displa and adjust brightness and volume swiftly.

Change the Watch Face

To change the watch face, press and hold the screen for 1 second to access the watch face gallery.

Start

Record Workouts

To start your workout recording, access the Workout app and select a specific

To obtain your exercise trajectory and other data when engaging in outdoor activities, you need to connect the Fitbeing App while your smartwatch is in outdoor mode.


Health Metrics Measurement

When wearing the watch, it automatically measures health data such as heart rate, sleep stress, and activity. You can also view and track this data in the application.

Rotate

1. Toggle between screens or navigate through menus.

2. Adjust the volume of prompt tones and phone calls.






Search CW Watch S5



To switch quickly between the Activity, Heart Rate, Sleep, Recently, Weather, or Workou tiles, swipe left or right on the watch fac screen.





Install New Watch Faces

In the Fitbeing app, navigate to the Face Gallery page to pick up you preferred watch face.


Face Gallery

New Faces >





Photos



Charge the Watch

To charge the watch, connect the charging cable to a USB power source. Attach the other end to the charging contact on the back of the watch. The watch will display a charging icon while it is being charged.

· Make sure the USB charging plug is at the same side as the crown. • Ensure to use a standard USB power source with an output of 5V-1A or above.


• Prior to charging, ensure to clean the charging contacts of the watch to eliminate any lingering sweat or moisture.

Change the Band

Remove band

1. Lift the spring bar from the groove

2. Push and hold the spring bar. 3. Pull it out gently to remove the band.




Install band

1. Insert the metal pin at position "A" in the hole. 2. Push and hold the spring bar.

3. Press the band into the body and release the spring

4. Pull the watch band to confirm the firm installation.



Wear and Care

It is advised to remove the watch for approximately one hour daily. If you experience discomfort or irritation like redness tingling, or a burning sensation, take off the watch and rest your wrist.

To maintain hygiene, regularly clean your watch and wrist, particularly after workouts and sweating. Avoid using hand soap shower gel, dishwashing liquid, or cleaning wipes as they can cause skin irritation. Instead, use mild soap and fresh water to clean the band.

Key Specifications

| Product Name | CW Watch S5 |
|------------------------------|---|
| Display | 1.84 inch AMOLED |
| Resolution | 240 × 296 |
| Battery Capacity | 300 mAh |
| Wireless Connection | Bluetooth 5.3 |
| Water resistance garde | IP68 |
| Body Dimension | 40.55mm × 47.11mm × 10.8mm(w/o HR base |
| Working Temperature | 0°C ~ 50°C |
| Compatible Operating Systems | iOS 13.0 and above, Android 9.0 and above |
| l | |

Wear Your Watch

For optimal data accuracy, please observe the following guidelines while wearing the watch:

1. Wear the watch at a position approximately two finger-widths from your wrist bone.

2. For comfort, adjust the band to allow a finger's width between it and your wrist. This ensures both contact and fit.

$m \times 10.8 mm(w/o HR base)$

Design for Comfortable Wearing

The inner sweat grooves of the band are

Precautions

- · Do not replace the built-in battery yourself as it may pose a safety risk
- · Avoid forcibly opening the watch case, as it may cause short circuits and overheating.
- · Keep the watch away from environments exceeding 60°C to prevent batte leakage or explosion.
- While the product complies with IP68 waterproof standards, it is not recommended for activities such as bathing, diving, or water skiing that involve high temperatures, steam, or rapid water flow.
- Note that the waterproof performance may be compromised if the produ structure is damaged.

· Be aware that firmware upgrades can lead to interface and usage changes. Fo detailed information, please refer to the product's upgrade instructions

Help and Guide

Frequently Asked Question

If you encounter any problems while using the product, you can access the "Profile \rightarrow Help" section in th Fitbeing app for assistance.

Scan the QR code on the right to access or visit help.fitbeing.net for assistance.

Product Manual

You can find the complete product manual in Fitbeing app at "My Watch \rightarrow Product Manual".

Scan the QR code on the right to access it, or visit help.fitbeing.net to browse.

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits fo a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device contains licence–exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licenceexempt RSS(s). Operation is subject to the following two conditions:

This device may not cause interference.

2. This device must accept any interference, including interference that may cause undesired operation of the device.

'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux

CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

L'appareil ne doit pas produire de brouillage

L'appareil doit accepter tout brouillage radioélectrique subi, même si le prouillage est susceptible d'en compromettre le fonctionnement.

