

INSTALLATION INSTRUCTION


WS-S06D

WS-S06D

V1.0

Double light source
lamp

Reading Wall



Finish

Material

Matte	Black	/	Matte	White
Aluminum				

TECHNICAL CHARACTERISTICS

Light source: LED Input: 100~277V 50/60Hz


Output(W) :Spotlight 3W Background light 10W

Warm Tips:

1. Please read the instructions carefully before commencing assembly.
2. The installation of luminaire should be undertaken with utmost care and a qualified electrician should carry out the work to ensure compliance with any local wiring regulations.
3. Always ensure that the mains electrical supply is disconnected before installing luminaire.



IP 20





INSTALLATION INSTRUCTION

WS-S06D

4. Ensure the light source is compatible with local voltage and follow any maximum wattage instructions shown on the product itself.

5. Live: Black

Neutral: White


Earth: Normally Green /Bare copper

Option 1

1



2






WS-Lighting
Lighten The Art Around


INSTALLATION INSTRUCTION

WS-S06D




3



4



Option 2






WS-Lighting
Lighten The Art Around

INSTALLATION INSTRUCTION


WS-S06D

1


2



3



4






WS-Lighting
Lighten The Art Around

INSTALLATION INSTRUCTION

WS-S06D

4





INSTALLATION INSTRUCTION

WS-S06D

FCC Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.