

1 Intended Use

The Remote Control is supplied as an accessory of the General Light Siderea for its control.


















The remote control allows to:

- switch on and off
- dimming
- set up lighting scenarios

according to the specification described in §2.



2 Remote Control Functions

| Buttons | Functions | | |
|--|---|--|---|
|  | On/Off: switching on/turning off the lamp. On switching on, the last scenario selected will be recalled |  | Scenario 3: 3rd level of illumination, maximum + upper LEDs |
|  | Programming button; allows access to "overwrite" and "Reset" functions. |  | Scenario 4: 4th level of illumination, maximum + upper LEDs |
|  | Scenario 1: 1st level of illumination, maximum + upper LEDs (min.) |  | Scenario 5: 5th level of illumination, maximum + upper LEDs (max.) |
|  | Scenario 2: 2nd level of illumination, maximum + upper LEDs |  | Adjustment to lower LEDs; variation in intensity of 0% to 100%. An increase/reduction in intensity depends on the time for which the button is pressed by the user. |
|  | Company Logo, no function | | |
|   | Overwriting scenario: Modification of the level of illumination over an existing scenario. Procedure: <ol style="list-style-type: none"> 1. Set the desired level of illumination. 2. Press the two indicated buttons at the same time for 3 secs.; that of the scenario to be modified and the programming button, the green LED flashes 3. Release the buttons as soon as the blue light is steady. Note: The Modification is possible on all 5 scenarios | | |
|   | Restore initial settings (erases all settings) Procedure: <ol style="list-style-type: none"> 1. Prolonged pressing of the two buttons for some 5 secs., the green light flashes. 2. Release the buttons as soon as the green light is steady. | | |
|     | Modify the coding of the remote control; create a new code for communicating between the remote control and the lamp. <ol style="list-style-type: none"> 1. This function must be only be used in the event that it is necessary to pair a new remote control in the place of the one in use. Procedure: <ol style="list-style-type: none"> 1. Remove power to the lamp. 2. Restore power and within 60 seconds, proceed with points 3 and 4 3. Prolonged pressing of the two buttons for some 5 secs., the green light flashes. 4. Release the buttons as soon as the green light is steady. 5. When the green Siderea LED flashes rapidly, press the programming button | | |

3 Replacement Of The Remote-Control Battery

The battery is accessed through a hatch at the back of the remote control. Exchange it for one with the same characteristics, observing the indicated polarity:

MOD: LR-23A/12V

4 Technical Specifications

Remote control battery : LR-23A/12V

Transmitter frequency : 315 MHz

FCC ID: 2BC9L-540050

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.