

Fast User Manual

1. Can be used as a magnetic wireless charging power bank, compatible with iPhone 12-15 and Iwatch series.

2. Can be used as an ordinary wireless charging power bank supply, compatible with all mobile phones that support Qi protocol.Support OP, HW, XM, SAM, etc. Support wireless charging function mobile phone.

3. Can be used as a portable power bank, compact and lightweight, easy to carry, supports 99% mobile phone charging.

4. It is both a wireless charger and a mobile phone holder.

Note: Wireless charging function instructions


- Place your phone on the wireless charger and press the button to turn on the wireless charging function.
- When using the charger to charge the power bank, when the input is in the fast charging state, then turn on wireless charging, can be wireless fast charging.

Product Features

- 15W wireless output, magnetic wireless fast charging
- Brand new three-in-one, 10000mAh + wireless charging + magnetic suction
- PD 20W+22.5W fast charging, high efficiency charging
- Can be charged and discharged at the same time, mobile phone and power bank can be fast fully charged together
- LED indicator light accurately displays battery power
- High-quality polymer battery, safe and worry-free

Packing list

- power bank, user manual, charging cable x1



Product specifications

Product name	Magnetic wireless charging power bank
Model	T3Pro
Capacity	10000mAh
Type-C input	DC 5V-3A/9V-2A
Type-C output	DC 5V-3A/9V-2.22A/12V-1.67A
USB output	DC 5V-4.5A/4.5V-5A/9V-2A/12V-1.5A
Wireless output	mobile phone: 15W (Max) Iwatch: 2.5W (Max) airpods: 3W(Max)
Battery type	polymer battery
Working temperature range	-10℃~40℃



Battery indicator light description

The battery indicator light makes it easy for you to control the power and functions of the power bank

1. Check the remaining power:



Click the button: If one white light is on, it means the power is within 25%. If two white lights are on, it means the power is within 50%. If three white lights are on, it means that the power is within 75%. If four white lights are on, it means that the power is within 100%. When the last light of the indicator light flashes, the power is below 5%. Please charge as soon as possible.

2. Check the charging function:



After clicking the button, during use, the fifth light turns green, indicating that the power bank has turned on the fast charging function. If the fifth light blue light is always on, it means that the wireless charging function of the power bank is working normally.



Note:

- If it is left unused for a long time, please charge the battery at least once every 3 months.
- During use, the device will become slightly hot, but it is normal for it not to hot your hand.
- Please keep the product dry and do not scrub with chemical cleaning agents.
- Please care for the environment and recycle it at designated locations. Please do not discard it randomly.
- Do not allow children or people who are not qualified to use this device alone to use this device. This device must be used under adult supervision.
- Do not collide with, disassemble by yourself, or wade in water, get wet, or squeeze the equipment.
- Never apply the DC power supply designed to output to equipment that does not meet the output parameter requirements, as it may cause malfunction or fire.



Frequently asked questions and solutions

- When the power bank cannot be charged:
 - Please check whether the power adapter is suitable and whether the connecting cable and adapter are normal.
 - It is recommended to use a suitable brand of power adapter to charge it.
- When the power bank cannot charge other devices:
 - The power of the mobile power supply is too low, please recharge it.
 - The voltage of the device being charged is not compatible with the output voltage of the mobile power supply. Please check the charging voltage of the device being charged.
 - The connection method between the device being charged and the mobile power supply is incorrect, and whether the connecting cable and adapter are normal.
 - If the internal circuit of the power bank fails, please contact the after-sales service department of the local dealer.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.