

70x70mm



## JXLCAM

### User Manual

#### INSTALL APP

Use your mobile phone to scan the following QR code. Select the IOS or Android version according to the mobile phone system to install the APP name: JXL CAM.




JXLCAM

#### DEVICE BOOT

Turn on the device, the red indicator is always on (some models will have a tone), and the device enters the pending state.

#### DEVICE CONNECTION


1. The device is connected to the power supply and sounds a sound. If there is no tone, reset the device again.
2. Turn on the mobile phone WiFi to connect to the device hotspot. (Each device has a unique WiFi name, and the format is unified as "CAM...")
- Open the software JXLCAM and follow the following diagram:



1. Click Add Camera



3. Connect to 2.4G wifi and enter your password




2. Click AP to add a camera




4. Connect the camera



5. Connect the device ID starting with C A M



6. See the Camera preview page on the home page



7. Click Preview to enter the monitoring interface

#### STORAGE CARD

1. If you need to store the video content, you need to install a TF card, please be sure to install the memory card when the device is turned off.
2. The device supports a memory card with a maximum capacity of 128G. When the TF card is installed and the mobile phone is disconnected, the device will automatically start recording, and the video will be automatically packaged in sections. When the capacity of the TF card is insufficient, the oldest video will be automatically deleted, and the recording will be looped; the TF card recording file will automatically be recorded according to the year, month and day, Time to save hierarchically.
3. When the mobile APP is connected to the device, it will automatically exit the recording.

#### NOTE:

- (1) If the TF card is abnormal on the playback page, please check the status of the TF card, power off and remove the card and format it before reinstalling ;
- (2) TF card specification should be above C4 standard.

#### NOTE:

- (1) When the device fails to configure the network, please check whether the router and WiFi password are configured correctly (the device does not support 5G WiFi). After confirming that it is correct, you can press and hold the reset button for about 5 seconds until the device indicator flashes quickly, restore the factory settings, and the Re-distribute the network.
- (2) When the software homepage shows that the device is offline, you can check whether the device is normally powered on, and click the refresh icon in the upper right corner to refresh.
- (3) The device name and password can be customized. The initial password of the device is: admin

#### RELATED PARAMETERS:

PROJECT	PARAMETER
Application	JXLCAM
Video format	AVI
Video encoding	M-JPEG
Video resolution	640*480,1280*720,1920*1080
Video frame rate	30 frames
Playback software	Mainstream video playback software
Image Format	JPG
Charging voltage	110V—240V
Interface Type	Micro USB
Storage support	Maximum support 128G
Support system	Android/IOS

#### FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.