
# RC TOYS

No.:Q150

if it is not used for a long

# Instruction of 2.4G Armored-Warrior Twistable and Amphibious Car

#### About remote controller



One-key twist Auto demo push left joystick forward + right joystick

2 x 1.5V AA battery (Battery not Included) push left joystick forward + right joystick right: turn right

The pairing of remote controller. First turn on the remote. When the light is flashing, turn on the car. and then the light of remote is off, meaning the pairing is done.

### Watch controller(To be purchased separately)



3. One-key twist

Short press for twist / Long press 2x1.5V AAA batteries(Not Included)

Short press to switch on, and press again for


seconds to ndicator light

The pairing of weich controller: When the car and controller are pairing, long press for 2 seconds. The indicator feather slowly when short cress the switch of the wetch controller. Then to steady on, meaning the pairing is successful. During the operation, short press the awitch once, the watch controller will stop working. Press again


+ € 1.6V "MA"

The remote controller uses


## 4. Remote control operation



1.Forward, Backward Push left joystick up to make the car go forward. Push left joystick down to make the car go backward.




3. Battery installation of the car




Attention for Charging via USB

crewdriver to oper the battery cover

- Battery should be fully charged for the first time using. The battery will still self-discharge when not in use. If not in use for a long time, please ensure that the battery has about half of the power to preven overdischarge damage. Overcharging can shorten battery life.
- Please regularly check the cord, plug, casing and other accessories and stop using before being repaired if any damages are found.
  3.Do not connect the toys with the power that is not recommended. Charging conditions:Connect the USB smart charging cable with the
- Please use appropriate adapter instead of fast charger for charing.
  Please use the right adapter for charing.lnput: 100-240V~50/60Hz
  0.2A; output: 5.0V === 500mA 0.5-1.5A.
- 6.Charging notes: To charge the battery, please connect the battery with smart USB charging cable, which has access to power media. with USB interface, such as:desktop, laptop, mobile power, USB socket. Alternatively, you can use a USB adapter to connect with the
- Please remove the battery for the remote control truck and the remote controller if they are not expected to use for a long period of time.




2.Turn left, Turn right Push left joystick up and right joystick left to make the car turn left. Push left joystick up and right joystick right to make the car turn right.




4.Auto Demo

Play with the Watch Controller




1.Forward and Backward

It will move forward when your fist horizontally tilts forward and move backward when your fist horizontally tilts backward.



3. One-key twist



Tilt to the Right

Tilt the fist forward, then left, to make the car turn left,

Tilt the fist forward, then right, to make the car turn right.

Turn right

4. Auto demo

Tilt Forward

2.Turn left, turn right


## 6. Battery Storage

- 1. Do not fully charge the battery before keeping it for a long time, otherwiseit would result in the passivation, which speeds up the process of self-discharge.
- 2. Place the battery in dry indoor space with appropriate temperature between 10°C-30°C.

\*Please read through this manual before operation and keep it properly for future reference.

3. Conduct a charge cycle every other 3 months to keep it active and perform well.







Notes:1. When playing in the water, you must be accompanied by an adult. Avoid drowning risks.

- 2. It is forbidden to play in waters with large waves to avoid insufficient power of the car.
- 3. After the car plays in the water, clean the dust and water on the car with a rag.
- 4. When the car power is low, the controller light will flash slowly, then please take the car back in time, especially when playing in the water, to avoid being too far away from the shore without enough time to take it back.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the

(1) this device may not cause harmful interference, and

following two conditions:

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the followingmeasures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- "CAUTION: Any changes or modifications not expressly approved could void the user's authority to operate the equipment."

The device has been evaluated to meet general RF exposure requirement.

USA Adress: 5354 Irwindale Ave Unit A Irwindale CA 91706

Tel: 626-330-1988