

www.myinnostyle.com

Warranty

The effective warranty period for INNOSTYLE chargers is 12-24 months, depending on model purchased*. Return and replacement services are provided for faulty products. Warranties apply to products purchased only from INNOSTYLE and not from third parties.

*See Extended Warranty for further details.

Customer Service

Email: support@myinnostyle.com

Please Read before Use



1. While in use, the surface of the charger may feel warm to the touch- this is normal, and not a cause for alarm- you may continue to use it without concern. Our products meet strict international safety standards.
2. Keep the charger away from liquids, heat sources, and flammable items, as well as toxic and corrosive substances. The storage and operating environment of the product must be between 0-40°C.
3. Do not modify, disassemble, open, drop, crush, puncture or otherwise damage the charger. Desist from using damaged products.
4. It is recommended that you disconnect your device(s) from the charger after charging has completed.
5. It is advised that the charger be unplugged from the wall socket when no longer in use.
6. Products are intended to be used only in non-tropical climate conditions and at altitudes lower than 2000m above sea level.
7. Do not expose this charger to high temperatures and store this charger in a dry environment away from direct sunlight.
8. Misuse, dismantling, or mishandling of this product which fails to comply with this manual may result in damage to your connected device(s) or to the charger itself. In the event of damage to a product resulting from such actions, INNOSTYLE is not liable for compensation, replacement, or repair of said products.
9. To maintain peak performance, the battery should be fully charged and depleted at least once every three months.
10. Under normal circumstances, battery performance can be expected to decline slightly over a period of several years.

Packaging Content

- * 1 x MagStation 3-in-1
- * 1 x USB-C to USB-C Cable
- * 1 x User Manual



innostyle
USER MANUAL

MagStation 3-in-1

Product Overview





USB-C Input

LED Status Indications

1. Flashing white: Foreign objects detected
2. Blink 3 times and turn off: Connected to power
3. Solid white for 30 seconds and turn off: Charging

Please Note 

- * Power adapter not included. For optimal use, Power Delivery chargers of 20W or greater are required.
- * Not compatible with non-MagSafe phone cases.
- * Maximum charging per device is as follows: 7.5W for iPhone 12-14 series, 3W for Apple watch, and 5W for AirPods.
- * Place AirPods case on the center of the base to ensure consistent charging.

Compatible Models

Phones

iPhone 14 / iPhone 14 Plus / iPhone 14 Pro / iPhone 14 Pro Max / iPhone 13 / 13 Mini / 13 Pro / 13 Pro Max / iPhone 12 / 12 mini / 12 Pro / 12 Pro Max.

Apple Watch

Apple Watch Ultra & Series 8 / 7 / SE / 6 / 5 / 4 / 3 / 2 / 1.

AirPods

AirPods Pro 2 / 1 & AirPods 3 / 2 / 1 with wireless charging cases.

75 mm

65 mm

195 mm