
433M remote control instruction manual

Pictures of objects:



Parameters:

Product Model: SA00004-1

Operating voltage: DC3V (one 2032 button battery)

Operating current: less than 20mA when transmitting

Operating frequency: 433.92MHz

Operating Temperature:-30 $^{\circ}$ C \sim 70 $^{\circ}$ C

operation life:>10000times

Standby current: less than 1 μ A

Size: 61.5mm*29mm*12mm

Remote control response time: <5ms

Instructions for operation:

1: Press the ON button, the indicator light is red, send signal, open the machine, release to stop sending.

2: Press the OFF key, the indicator light is red, send signal, close the machine, release to stop sending.

3: When the emission indicator light is slightly bright, it indicates that the battery voltage is low, and it is necessary to replace a new battery.

Application production scene:

1: wireless mouse.

2: remote control toys.

3: Smart furniture., etc.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular

installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the device and receiver.
- --Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment