


HY-1说明书

成品尺寸:50*70mm 80g双胶纸 风琴折


注:印刷内容去掉成品线



使用指南


开放式气传导运动蓝牙耳机

产品概述



1.MFB键 2.耳机指示灯 3.Type-C充电口 4.LED呼吸灯

配对方式



兼容市场上带蓝牙功能98%的数码产品

注意事项

产品质量保修卡

使用指南

产品概述

1.MFB键 2.耳机指示灯 3.Type-C充电口 4.LED呼吸灯

配对方式

- 关机状态, 长按 MFB 键约 2 秒, 当耳机指示灯出现红蓝交替闪烁, 耳机进入配对状态并发出“配对中”或“Pairing”提示音。
- 打开设备上的蓝牙, 搜索耳机配对名, 点击配对连接并发出“连接成功”或“connect”提示音。
- 首次蓝牙配对成功之后使用, 不需要进行配对, 只要长按多功能键 2 秒至耳机开机 (蓝灯闪 3 下), 就会自动回连和耳机最后一次配对成功的手机。

功能操作

- 开机:** 关机状态, 长按 MFB 键约 2 秒, 白灯快闪三次, 并发出“开机”或“Power on”提示音。
- 关机:** 开机状态, 长按 MFB 键约 4 秒, 蓝灯闪三次 / 呼吸灯关闭, 并发出“关机”或“Power off”提示音。
- 配对方式:** 关机状态, 长按 MFB 键约 2 秒, 当耳机指示灯出现红蓝交替闪烁, 耳机进入配对状态, “配对中”或“Pairing”提示音。打开设备上的蓝牙, 搜索相应耳机配对名, 点击配对连接并发出“连接成功”或“connect”提示音。
- 首次蓝牙配对成功之后使用, 不需要进行配对, 只要长按多功能键 2 秒至耳机开机 (蓝灯闪 3 下), 就会自动回连和耳机最后一次配对成功的手机。**
- 打开 / 关闭呼吸灯:** 开机状态下 双击 MFB 键, 开启 / 关闭呼吸灯。
- 接听 / 挂断电话:** 单击 MFB 键接听电话, 单击 MFB 键挂断电话。
- 拒接来电:** 长按 MFB 键约 2 秒拒接来电。
- 播放 / 暂停音乐:** 连接成功后, 音乐播放时单击 MFB 键播放音乐, 再次单击 MFB 键暂停播放。
- 下一曲:** 连接状态下, 三击 MFB 键切换下一曲。
- 一拖二功能:** 先配对连接第一台手机, 然后关闭耳机重新进入配对, 用第二台手机配对连接完成后, 再在第一台手机点击连接过的配对名, 这样 1 台耳机就连上 2 部手机。
- 语音切换:** 在配对状态下, 四击 MFB 按键, 白蓝灯交替闪烁。
- 语音助手:** 长按 MFB 键约 2 秒松开进入语音助手, 单击退出语音助手。
- 耳机充电:** 充电时耳机红灯常亮, 充满后蓝牙耳机蓝灯常亮。注意请使用原厂专配电线, 充电电压不能高于 5V。

规格参数

- 耳机电池容量: 75mAh
- 充电时间: 1.5H
- 待机时间: 130H
- 充电方式: Type-C 5V/1A
- 传输距离: >=10米

注意事项

- 切勿使用具有腐蚀性的清洁剂清理本产品。
- 切勿让本产品加热或靠近火源, 如煮食炉。
- 切勿让本产品长时间受阳光直接照射。
- 切勿将本产品放置于火中, 避免发生爆炸。
- 切勿尝试拆开本产品作出任何修改, 因为它并不包含任何维修组件。
- 切勿在雨中使用本产品。
- 如果长期内不打算使用本产品, 请您将它储存在干燥的环境中, 并每月至少为耳机充电一次以延长寿命, 避免极端的温度和灰尘。


注意

- 针对可拆卸电池的产品, 请务必回收或妥善处理, 针对不可拆卸电池的产品, 禁止拆解。
- 如果电池使用不当, 就有可能爆炸或泄漏, 从而造成烧伤和其它人身伤害; 如果电池泄漏, 应小心并根据当地的电池处理相关法律和规定要求立即弃置电池。

产品质量保修卡

*在接受服务时必须提供此保修卡, 请妥善保管!


| | |
|---------|--|
| 产品型号 | |
| 商品产地 | |
| 用户姓名 | |
| 销售地点 | |
| 销售日期 | |
| 销售商名称 | |
| 销售商联系电话 | |
| 维修记录 | |



User Guide


Bluetooth headset

Product overview



1.MFB 2.LED Indicator Light 3.Type-C 4.LED Breathing Light

Earphone Pairing



Compatible with 98% products with Bluetooth function

Specifications

PRODUCT QUALITY WARRANTY CARD

User Guide

Product overview

1.MFB 2.LED Indicator Light 3.Type-C 4.LED Breathing Light

Earphone Pairing

- When the earphone is turned off, press and hold the MFB button for about 2 seconds to power on, when the earphone indicator flashes red and blue alternately, the earphone enters the pairing state and emits a "Pairing" tone.
- Turn on Bluetooth on the device, search for earphone pairing name, click the pairing name to connection and sound "connect".
- After first successful pairing, you do not need to pair again. Just long press the MFB button for 2 seconds to turn on the earphone (the blue light flashes 3 times), then the earphone will automatically connect back to the device that was successfully paired last time.

Function operation

- Power on:** When the earphone is off, long press the MFB button for about 2 seconds to power on, the white light flashes 3 times quickly, and the "Power on" prompt tone is emitted.
- Power off:** When the earphone is powered on, long press the MFB button about for 4 seconds to power off, the blue light flashes 3 times, the breathing light is turned off, and the "Power off" prompt tone is emitted.

Specifications

- Battery capacity: 75mAh
- Charge Time: 1.5H
- Standby time: 130H
- Charging Port: Type-C
- Operating Range: >=10m

PRODUCT QUALITY WARRANTY CARD

*This warranty card must be provided when receiving the service, please keep it properly!

| | |
|-------------------------|--|
| Model | |
| Commodity origin | |
| User name | |
| Sales location | |
| Sale date | |
| Seller's name | |
| Seller's contact number | |
| Repair Record | |

Specifications

- Battery capacity: 75mAh
- Charge Time: 1.5H
- Standby time: 130H
- Charging Port: Type-C
- Operating Range: >=10m

Matters needing attention

- Do not use corrosive cleaning agents to clean the product.
- Do not allow this product to heat or be near fire sources, such as cooking stoves.
- Do not expose this product to direct sunlight for a long time.
- Do not dispose of this product in fire to avoid explosion.
- Do not attempt to disassemble this product for any modification, as it does not contain any repair components.
- Do not use this product in the rain.
- If you do not intend to use this product for a long time, please store it in a dry environment and monthly Charge your headphones at least once to extend their life and avoid extreme temperatures and dust.

Warning

- Batteries must be recycled or properly disposed when the product Batteries could be removed. Do not disassemble the battery when the product Batteries could not be removed.
- If the battery is not used properly, it may explode or leak, causing burns and other injuries. If the battery leaks, be careful and dispose of the battery immediately in accordance with local laws and regulations on battery handling.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.