

Polaring

P7 Pro



Android HDMI


1080P Projector

Product List


| | |
|--|----|
| Function Overview | 01 |
| Remote Control Instructions | 02 |
| Connect To WIFI | 03 |
| BT Settings | 04 |
| Screen Mirroring Function for IOS System - - - - | 05 |
| Screen Mirroring Function for Android | 06 |
| Input Source | 07 |
| Packing List | 08 |
| Warranty Card | 09 |

Function Overview

Button illustrate




Remote Control Instructions




Note : Battery is not included


Connect To WIFI



1. Select "SETTING" on the main interface




2. Select "WIFI Connection"




3. Select "Search the Web"

4. Select the network you want to connect to

BT Setting




1. Select "SETTING" on the main interface




2. Select "BT Setting"

3.Set "BT Status" to "On" and select "Available Device" to search for Bluetooth audio devices to connect.


Screen Mirroring Function for IOS System



1.On the main page, select "MCAST"




2.Choose "Wireless Connection with IOS"




3. Follow the steps on the screen

(The operation steps of the same screen on the mobile phone are as above)

Screen Mirroring Function for Android



1. Click "MCAST" on the Main Page



2. Choose "Wireless Connection with Android&Windows"


3. Follow the steps on the screen

(The operation steps of the same screen on the mobile phone are as above)

Input Source



1. On the main page, select "SOURCE"



2. Select the corresponding video port for playback according to the actual access signal source

Packing List




Projector



Remote



User Manual



Power Cable

Warranty Card

| | | |
|---------------------|-------------------------------------|--|
| User Info | Username | |
| | Contact Number | |
| | Zip Code | |
| | Mailing Address | |
| Product Information | Product Name | |
| | Product Number | |
| | Product Serial Number | |
| Sales Information | Sales Unit | |
| | Contact Number | |
| | Zip Code | |
| | Address | |
| | Sale Date | |
| | Installation And Commissioning Date | |
| | Invoice Number | |

| | |
|------------------|------------------------------|
| Delivery Date: | Maintenance Staff Signature: |
| Cause of Lssue: | |
| Troubleshooting: | |
| Service Point: | Delivery Date: |

| | |
|------------------|------------------------------|
| Delivery Date: | Maintenance Staff Signature: |
| Cause of Lssue: | |
| Troubleshooting: | |
| Service Point: | Delivery Date: |

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.