

KM009说明书
 尺寸:105*148.5mm
 材质:70书纸单黑风琴折

105 mm

148.5 mm

Kpmare

Wireless Keyboard
 And Mouse Combo KM009




The USB Receiver is in the Mouse

EN

Product Specification



Connection:2.4G Wireless Connection
 Receiver type:USB Nano Receiver
 Standby hours: 900 hours
 Working time: 180 hours of typing
 Working distance: 10 meters from the receiver without obstruction
 power: Two AAA batteries for keyboard
 One AA batteries for mouse(NOT INCLUDE)

You will receive




-01-

How to set up



-02-



FAQ:

Q1: What should I do if the keyboard become sticky after a period of usage?
 A1: This usually happens due to low power. Please replace the battery on the keyboard and try again.
 Q2: What should I do if I can't type with the keyboard?
 A2: First, please make sure whether the keyboard can be turned on. If you can't turn on the keyboard, please change the battery and try again. If it still won't work, please contact us if you can turn on the keyboard just it won't type, please try repairing the keyboard with the USB receiver.
 Q3: What should I do if my mouse stopped working?
 A3: First, please confirm whether the mouse can be turned on. If you can't successfully turn on the mouse, change the battery and try again.

-03-

WARNING

Do not expose this product to water, prevent liquid from entering product. Water or humidity may cause short-circuit and damage this keyboard.
 Do not drop or hit this product. Shocks may damage the components inside.
 Do not put this product near extreme heat or fire.
 Do not try to disassemble or modify this product on your own.

WARRANTY COVERAGE

1. 30-day unconditional money-back guarantee. If you are not completely satisfied with this product for any reason, we will gladly refund your purchase price within 30 days of purchase (from the date of retail purchase).
 2. 1-year limited warranty. ONE (1) YEAR from the date of retail purchase, if a hardware defect arises (not due to personal alterations or attempted repairs) and a valid claim is received within the warranty period.

NOTE

1. The multimedia keys are for Win8 and Win10. For other systems, there may be no for some combi keys.

kpmare@yeah.net

We will deal with your problem as soon as possible.

-04-




Indicator Function Instruction



Instruction of the Multi-function keys

press F1-F12 keys directly,you can only use the functions of F1-F12. For using these multimedia functions,you need tou press and hold the button"FN" first,and then press the corresponding function button. Switch between two systems FN+Q=WIN FN+W=MAC



How to repair the keyboard to the USB receiver

Step 1.Insert the USB receiver and place the keyboard as closely possible to the USB receiver.
Step 2,Press and hold the keyboard "ESC" + "=" keys together to pair again.



How to repair the mous to the USB receiver

Step1:Take out the battery and USB receiver, reload the battery and plug the receiver into the computer for the mouse for a full reset.
Step2: Press and hold the Left button and the Right button with Scroll button with together to pair again.



FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.