

## Vibrator

### Nature of Product

Product Name	Vibrator	Product Material	ABS+Silica Gel
Product Size	119*105*66.6MM	Product Color	Red/Purple
Max Noise	<50 db	Power Supply Mode	USB recharging
Input Voltage	3-7V	Input Current	1A
Main Function Level	Frequency of Vibration:10		

### Packing list

G-spot Vibrator \* 1; Instruction Booklet \* 1; USB Cable \* 1

### Notice for USE

1. Please read this User manual carefully before use and follow the instructions.
2. Please recharge the product for the initial use.
3. Minors under the age of 18 is forbidden to use this product.
4. Please keep the product clean after use. Do not use corrosive cleaner.

### Charging:

Please Charge the product with a matched USB cable  
Input Voltage:3-7V ; Input Current: 1-2A

Please use a charger with matching parameters for charging.  
Charging with a mismatched charger may affect the current, which will reduce product life or damage the product.  
When charging, the indicator light flashes. After the vibrator gets fully charged, the indicator light is on. The product is equipped with built-in current protection. When charging, the product will automatically enter the protection state ; the product cannot be used at this time. After fully charged, the product will automatically return to normal state and it can be used again.

## Usage Methods

### Remote control




ON/OFF Button;  
Frequency  
ConversionButton

Remote Control/  
Frequency  
Conversion Butto

## Vibrator

Magnetically charged



### Operating Instruction

#### ① Vibrator

1. Under the turned off status, press 1.5 seconds to turn on
2. There are 10 frequency for your choice when you turned on.
3. The vibrator will be powered off when you pressed 1.5 seconds under power on status.

#### ② Remote control

1. When the vibrator is on, turn on the remote control, short press for choosing frequency ,press 1.5 seconds for standing by.

### Cautions

1. The product is equipped with a built-in polymer lithium battery. Do not disassemble the battery to avoid damage to the product.
2. After using the product, keep it in a dry and ventilated place. The product should be kept away from children.
3. The product is equipped with a built-in polymer lithium battery. Do not discard the product casually when the product's life comes to an end. This is conducive to environment protection.

## Vibrator

### Nature of Product

Product Name	Vibrator	Product Material	ABS+Silica Gel
Product Size	119*105*66.6MM	Product Color	Red/Purple
Max Noise	<50 db	Power Supply Mode	USB recharging
Input Voltage	3-7V	Input Current	1A
Main Function Level	Frequency of Vibration:10		

### Operating Instruction

#### ① Vibrator

1. Under the turned off status, press 1.5 seconds to turn on
2. There are 10 frequency for your choice when you turned on.
3. The vibrator will be powered off when you pressed 1.5 seconds under power on status.

#### ② Remote control

1. When the vibrator is on, turn on the remote control, short press for choosing frequency ,press 1.5 seconds for standing by.

### Cautions

1. The product is equipped with a built-in polymer lithium battery. Do not disassemble the battery to avoid damage to the product.
2. After using the product, keep it in a dry and ventilated place. The product should be kept away from children.
3. The product is equipped with a built-in polymer lithium battery. Do not discard the product casually when the product's life comes to an end. This is conducive to environment protection.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.