

# User Manual


Meet Your DIY Aurora Sunrise  
Alarm Clock





# Contents





## General Information

	Key Information	02
	Package Contents	03
	Display Icon Guide	04
	Getting to Know Your Aurora Clock	05

## Getting Started

	Plugging In	07
	Powering On and Off	07


## Setting the time

	Time Configuration	08
	Adjusting Display Brightness	09




## Light mode

	Aurora Light	10
	Rainbow Light	10
	Soft Night Light	10
	Backlight	10




## Music Mode

	Gentle Music, Nursery Rhymes, and Natural Sounds	11
---	--	----





## Sleep Aid and Bluetooth

	Sleep Aid (Faster Sleep)	12
	Bluetooth	12
	Sleep Aid with Bluetooth	12

## Aurora Sunrise Alarm

	Aurora Sunrise Alarm Clock Settings	13
	Snoozing	14
	Turning the Alarm Off	15

## Additional Options

	Resetting Your Aurora Clock	15
	Storage	15
	Disposal	15
	Trouble Shooting	15

# General Information

---



## Key Information

### Safety Guidelines

Before you start using your Aurora Sunrise Alarm Clock, please make sure to read and follow these safety instructions to avoid any potential risks of fire, electrical shock, or personal injuries:

1. The Aurora Clock is intended solely for home use and similar environments, such as hotels. Commercial or outdoor use is not recommended.
2. It is crucial to place this device on a stable, non-slippery surface to prevent any accidental damage.
3. Do not operate this device in wet or moist areas, such as bathrooms, near showers, or swimming pools, as this can damage the clock and lead to potential safety hazards.
4. Make sure no water spills on or enters the product. Water damage can affect the device's functionality and may cause safety issues.
5. The power adapter should be kept dry at all times. Avoid plugging it in or operating it in damp or wet conditions.
6. Always use the original adapter and USB cable supplied with the clock. Using unauthorized accessories can harm the device's performance and safety.
7. This product is not designed to reduce your sleep time, but rather to enhance the quality of your waking experience. It is important to maintain a healthy sleep schedule and not use this product as a means to cut down on your sleep duration.


### Precautions for Care

Follow these guidelines to maintain the condition and functionality of your product:

1. Clean the product gently with a soft, dry cloth. This helps preserve the product's finish and prevent damage.
2. Refrain from using abrasive cleaning agents, pads, or solvents such as alcohol or acetone, which can harm the product's surface.
3. If the product is not going to be used for an extended period, disconnect the power adapter. Then store it in a secure, dry area where it is protected from physical damage, impacts, or crushing.




# Package Contents




User Manual





Aurora Sunrise Alarm Clock




DIY 3D Cute Animal Kits




Emoji Stickers & Shovel




Color Brushes



Adapter with Cable



Blessing Card




Sleep Training Behavior Chart



# Display Icon Guide

MON TUE WED THU FRI SAT SUN



Alarm 1



Alarm 2




AM



PM




Time setting



Sunrise&Sunset simulation light



Aurora light& Rainbow light



Soft music& Nursery rhymes



Bluetooth



Snooze



Sleep Aid



Natural sounds



MIN



MON-SUN

# Need Help? Sample Support is a Dream.

Contact US at [www.sample.com/Support](http://www.sample.com/Support)  
Email: [support@sample.com](mailto:support@sample.com)




SCAN ME







# Getting to Know Your Aurora Clock

## An Overview of the Product





# 3D Cute Animal Aurora Sunrise Alarm Clock






# Getting Started



## Plugging In




Connect the provided custom power cable to your Aurora Sunrise Alarm Clock, then plug it into an appropriate power outlet.



## Powering On and Off

1. Power can be turned on or off simply by plugging in or unplugging the device.


2. Alternatively, press and hold the  button for 3 seconds to power on or off. Note:



The power-on process includes activation of light and voice features.

# Setting the Time



## Time Configuration

1. Press and hold the  for 2 seconds to initiate the time-setting process.  
Setting Sequence: Hour -> Minute -> 12H/24H Format -> Weekday.



Press and hold



Hour Blinks




Rotate(+/-)




Hour set



Short press



Minute set



Rotate(+/-)



Time set

9



Short press

10

12Hr

12 /24H

11



Rotate(12/24H)

12



Short Press

13




Rotate(Mon-Sun)

14




Finish

## Adjusting Display Brightness

1. Short press the  to adjust the display brightness.  
(Default factory setting at level 3)

There are four levels of time display brightness: Off, Level 1, Level 2, Level 3&Level 4.



# Light Mode






## Aurora Light &




## Rainbow Light


### Turn On/Off

The Aurora Sunrise Alarm Clock features 10 mixed color lights and 8 pure color lights.


1. Short press the  to turn on/off the Aurora light on first use.
2. Press and hold the  to switch to Rainbow light.
3. Once the light has been turned off, it will default to the last light effect used when turned on again. Press and hold the  to switch between Aurora or Rainbow light.



### Switch Lighting Effect

1. Short press the buttons on both sides of the  to change the lighting effect.
2. There are 10 mixed Aurora lights and 8 pure Rainbow lights available.


### Adjust the Brightness

Rotate the  to adjust the light brightness (from L1 to L10).




## Soft Night Light

### Turn On/Off



Short press the  to turn on/off the soft night light.

### Adjust the Brightness

Rotate the  or  to adjust the brightness of the light(L1-L20).



## Backlight

Double-click  to turn on and off the backlight separately. Short press the buttons on both sides of the  to change the lighting effect.

Note: Press and hold both the  and  together for a special surprise. Enjoy the fun!




# Music Mode




## Soft Music & Nursery Rhymes and Natural Sounds


### Turn On/Off

The Aurora Sunrise Alarm Clock comes with 9 Soft Music & Nursery Rhymes and 9 Natural Sounds white noise options.


1. Short press the  to turn on/off the Soft Music & Nursery Rhymes on the first use.
2. Press and hold the  to switch to Natural Sounds.
3. After turning off the music, it will default to the last music type used when turned on again. Press and hold the  to switch between Soft Music & Nursery Rhymes or Natural Sounds.



### Switch the Music

1. Short press the buttons on both sides of the  to switch the music.
2. There are 9 Soft Music & Nursery Rhymes and 9 Natural Sounds available.

### Adjust the Volume

Rotate the  to adjust the volume of the music, ranging from L1 to L15.


# Sleep Aid & Bluetooth

---






## Sleep Aid (Fall Asleep Faster)



### Turn On/Off

1. Short press the  to turn on/off the Sleep Aid function. By default, the sleep time is set to 30 minutes, with pre-selected sleep music and light.

### Sleep Aid Settings

1. Rotate the  to adjust the Sleep Aid time (range: 10-240 minutes).
2. Short press the  to change the music; Short press the  to change the light.

## Bluetooth

1. Bluetooth name: ET07
2. Press and hold the  for 3 seconds to activate the Bluetooth mode.
3. Switch music by using your connected phone.
4. Adjust volume by using your phone or rotate the 



## Sleep Aid with Bluetooth





















1. Turn on the Bluetooth, then activate the Sleep Aid function.











# Aurora Sunrise Alarm



## Aurora Sunrise Alarm Clock Setting

1. Press and hold the  or  button for 2 seconds to initiate the alarm setting process.
2. Setting sequence: Hour → Minute → Alarm sound (S01-S09) → Sound volume (001-015) → Sunrise light (C01) or Aurora light (C02-C11) → Maximum brightness of Sunrise or Aurora light (L01-L25/L01-L10) → Duration of Sunrise or Aurora light → Alarm frequency (Daily, Weekday, Weekend)

1		2		3		4		5	
	Press and hold		Hour Blinks		Rotate(+/-)		Hour set		Short press
6		7		8		9		10	
	Minute set		Rotate(+/-)		Time set		Short press		Sound Blinks
11		12		13		14		15	
	Rotate(+/-)		Sound set		Short press		Volume Blinks		Rotate(+/-)
16		17		18		19		20	
	Sound set		Short press		Light Blinks		Rotate(+/-)		Light set

- |    |   |    |   |    |   |    |   |    |   |
|----|---|----|---|----|---|----|---|----|---|
| 21 |  | 22 |  | 23 |  | 24 |  | 25 |  |
|    | Short press   |    | Brightness Blinks   |    | Rotate(+/-)   |    | Brightness set  |    | Short press   |
| 26 |  | 27 |  | 28 |  | 29 |  | 30 |  |
|    | Light up-Time Blinks  |    | Rotate(+/-)   |    | Light up-Time Blinks  |    | Finish  |    | Alarm Date set<br>(Daily-weekday.weekend)   |


You can choose to wake up with either light or sound by selecting 'OFF' for sound or light during alarm clock setting.



## Alarm and Snoozing

As the Wake-up Light simulates sunrise, it will continue this simulation through the entire setup process until the set brightness level is reached. To ensure the alarm sound is played at the designated time, follow these instructions:


### Snooze

If you desire to snooze, simply tap the  button once. During the pause in the alarm sound, the lamp turns off. After 9 minutes, the alarm will ring again. (Note: The snooze mode has no time limit.)



## Turning the Alarm Off

If you wish to stop the current sound and prevent the next one, click the switch on the corresponding alarm.

By pressing the  button and holding it for 2 seconds, you will hear "stop sound", and this will halt the alarm for that day.

### No Operation

If no action is taken, the alarm sound will last for 30 minutes, after which it will stop automatically without interrupting the next ringing.




# Extra Options

---



## Resetting Your Aurora Clock

You can find the reset button at the bottom of the product.



## Storage

- Clean the clock with a soft cloth.
- Avoid using abrasive cleaning agents, pads, or solvents like alcohol, acetone, etc., as these could damage the clock's surface.
- If the clock is not in use for a prolonged period, unplug the power cord from the wall outlet and store it in a safe, dry place where it won't get crushed or damaged.
- When storing the clock, avoid wrapping the power cord around it.
- The clock does not contain any other user-serviceable components.

## Disposal

Your product was designed and manufactured using high-quality materials and components that can be recycled and reused. Please contact your local waste management facility for information on recycling procedures.

## Trouble Shooting

This section summarizes common problems you may encounter with the clock. If you can't resolve an issue with the given information, please contact us for further assistance.

## **1.The Clock Doesn't Work**

- Check if the adapter is properly inserted into the wall outlet.
- Verify if the plug is properly inserted into the clock.
- In case of a power outage, test the power supply by plugging another appliance into it. If the lamp in the clock doesn't work, contact us for help.

## **2.The Clock Doesn't Respond**

- If the clock doesn't respond to function setting attempts, unplug the adapter, wait a few minutes, and plug it back in. Then press the reset button to return the clock to its factory settings.

## **3.The Lamp Doesn't Turn on During Alarm**

- You may have set the light intensity too low or turned off the alarm function.

## **4.Delayed Lamp Illumination**

- It's normal for the lamp to take about a second to turn on due to the heating time required.

## **5.No Sound During Alarm**

- Check if you've set the volume too low or turned off the alarm function.

## **6.The alarm went off yesterday, but it did not go off today.**

- If the alarm worked one day but not the next, check if you've accidentally turned off the alarm function.

## **7.The Alarm Function Is Active but Doesn't Work**

- You may have set the volume and/or light intensity levels too low, or a prolonged power outage may have reset the clock to factory settings.

## **8.Snooze Mode Doesn't Restart**

- The snooze mode won't reactivate if you press any buttons besides the 'Snooze' button.

## **9.The Light Wakes You Up Too Early**

- You may need to reduce the light intensity level or move the clock farther from your bed.

## **10.The Light Wakes You Up Too Late**

- Ensure that the clock is positioned at the right height, not blocked by your bed or pillow, and placed at an appropriate distance from other appliances.

## **11.The Lamp Flashes**

- Check if the clock's voltage is compatible with your local voltage.

## **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC Radiation Exposure Statement**

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.