



# VIBEZ

## BLUETOOTH HEADPHONES

### USER MANUAL

models: BH137



#### BUTTON OPERATION INSTRUCTIONS

⏻ : Long press 3 seconds to power on/off

**M**: During the music playing, click once to play/pause music. When call comes, click once to answer, long press to reject. When calling, double click to redial the last number.

**V+**: Short press for volume up, long press for previous song.

**V-**: Short press for volume down, long press for next song.

#### LED INDICATOR

The blue light will flash fast under pairing state, when the headphone matches the phone successfully, the blue light is shown still.

In charging mode, the red light is on steadily when charging, and when it's fully charged, the red light will be off.

#### OPERATION DESCRIPTION

Long press ⏻ three seconds, to power on, the blue light flashes fast to go to wireless pairing state.

Please pairing your smart phone by operating Bluetooth preferences and select "**RS VIBEZ**", (no password is needed), when the Bluetooth connection is successfully, only the blue light is shown.

Open your cell phone music player, this product can control the next and previous songs wirelessly, play and pause, answer the phone, redial, etc.

#### MP3 MODE

1. When the headphone is off, insert a MicroSD card, and then turn on the headphone, the headphone will play the music automatically. In Bluetooth mode, insert a MicroSD card, and then the headphone will play the music automatically.
2. Long press back forward and skip forward button to play the songs
3. Press V+ or V- button to obtain the level you want to be.

#### LINE EXTERNAL AUDIO INPUT

In power on mode, plug audio 3.5mm audio cable, and it will turn to AUX LINE IN mode.

#### SPECIFICATIONS

- Battery: 250mAh
- Bluetooth version: JL 5.3
- Bluetooth: A2DP 1.2, AVRCP 1.0, HFP 1.6
- Speaker: 40mm
- Frequency response: 20Hz-20KHz
- Material: ABS+PU+rubber oil
- Impedance: 32Ω
- Play time: 4-6 hours
- Charging time: 1.5-2 hours
- Stand-by time: 32 hours

**Warning:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

**NOTE:** This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.